



Level



Pressure



Flow



Temperature



Liquid
Analysis



Registration



Systems
Components



Services



Solutions

Operating Instructions

Cerabar M **PMC51, PMP51, PMP55**


Deltabar M **PMD55**

Deltapilot M **FMB50/51/52/53**


Process pressure / Differential pressure, Flow / Hydrostatic




Cerabar M




Deltabar M



Deltapilot M





A0023555

Table of contents

1	Safety instructions	4	7.10	Flow measurement (Deltabar M)	79
1.1	Designated use	4	7.11	Level measurement (Deltabar M)	82
1.2	Installation, commissioning and operation	4	7.12	Backup or duplicate device data	93
1.3	Operational and process safety	4			
1.4	Notes on safety conventions and icons	5			
2	Identification	6	8	Maintenance	94
2.1	Product identification	6	8.1	Cleaning instructions	94
2.2	Device designation	6	8.2	Exterior cleaning	94
2.3	Scope of delivery	9	9	Troubleshooting	95
2.4	CE mark, Declaration of Conformity	9	9.1	Messages	95
2.5	Registered labels	9	9.2	Response of output to errors	97
3	Installation	10	9.3	Repair	98
3.1	Incoming acceptance, transport, storage	10	9.4	Repair of Ex-certified devices	98
3.2	Installation conditions	10	9.5	Spare Parts	98
3.3	Installing Cerabar M	11	9.6	Return	98
3.4	Installing Deltabar M	19	9.7	Disposal	98
3.5	Installing Deltapilot M	26	9.8	Software history	99
3.6	Mounting of the profile seal for universal process mounting adapter	31	10	Technical data	101
3.7	Closing the housing cover	31	11	Appendix	102
3.8	Post-installation check	31	11.1	Overview of operating menu	102
4	Wiring	32	11.2	Description of parameters	110
4.1	Connecting the device	32	Index	134	
4.2	Connecting the measuring unit	34			
4.3	Overvoltage protection (optional)	36			
4.4	Post-connection check	37			
5	Operation	38			
5.1	Operating options	38			
5.2	Operation without operating menu	39			
5.3	Operation with an operating menu	41			
6	Integrating transmitter using HART® protocol	51			
6.1	HART process variables and measured values	51			
6.2	Device variables and measured values	52			
7	Commissioning	53			
7.1	Function check	53			
7.2	Commissioning without an operating menu	54			
7.3	Commissioning with an operating menu	57			
7.4	Position zero adjustment	58			
7.5	Level measurement (Cerabar M and Deltapilot M)	59			
7.6	Linearization	69			
7.7	Pressure measurement	73			
7.8	Electrical differential pressure measurement with gauge pressure sensors (Cerabar M or Deltapilot M)	75			
7.9	Differential pressure measurement (Deltabar M)	77			

1 Safety instructions

1.1 Designated use

The **Cerabar M** is a pressure transmitter for measuring level and pressure.

The **Deltabar M** is a differential pressure transmitter for measuring differential pressure, flow and level.

The **Deltapilot M** is a hydrostatic pressure sensor for measuring level and pressure.

The manufacturer accepts no liability for damages resulting from incorrect use or use other than that designated.

1.2 Installation, commissioning and operation

The device is designed to meet state-of-the-art safety requirements and complies with applicable standards and EU regulations. If used incorrectly or for applications for which it is not intended, however, it can be a source of application-related danger, e.g. product overflow due to incorrect installation or configuration. For this reason, installation, connection to the electricity supply, commissioning, operation and maintenance of the measuring system must only be carried out by trained, qualified specialists authorized to perform such work by the facility's owner-operator. The specialist staff must have read and understood these Operating Instructions and must follow the instructions they contain. Modifications and repairs to the devices are permissible only if they are expressly approved in the Operating Instructions. Pay particular attention to the technical data and information on the nameplate.

1.3 Operational and process safety

Alternative monitoring measures have to be taken while configuring, testing or servicing the device to ensure the operational and process safety.



Warning!

Only disassemble the device in pressurless condition!

1.3.1 Hazardous areas (optional)

Devices for use in hazardous areas are fitted with an additional nameplate (→ 6 ff). If using the measuring system in hazardous areas, the appropriate national standards and regulations must be observed. The device is accompanied by separate "Ex documentation", which is an integral part of these Operating Instructions. The installation regulations, connection values and safety instructions listed in this Ex document must be observed. The documentation number of the related Safety Instructions is also indicated on the additional nameplate.




- Ensure that all personnel are suitably qualified.




1.3.2 Functional Safety SIL (optional)







If using devices for applications with safety integrity, the Functional Safety Manual (SD00347P/00/EN) must be observed thoroughly.


1.4 Notes on safety conventions and icons

In order to highlight safety-relevant or alternative operating procedures in the manual, the following conventions have been used, each indicated by a corresponding icon in the margin.

Symbol	Meaning
	Warning! A warning highlights actions or procedures which, if not performed correctly, will lead to serious personal injury, a safety hazard or the destruction of the device.
	Caution! Caution highlights actions or procedures which, if not performed correctly, can lead to personal injury or the incorrect operation of the device.
	Note! A note highlights actions or procedures which, if not performed correctly, can have an indirect effect on operation or trigger an unexpected response on the part of the device.

	Explosion-protected, type-examined equipment If the device has this symbol embossed on its nameplate, it can be used in a hazardous area or a non-hazardous area, depending on the approval.
	Hazardous area This symbol is used in the drawings of these Operating Instructions to indicate hazardous areas. – Devices used in hazardous areas must possess an appropriate type of protection.
	Safe area (non-hazardous area) This symbol is used in the drawings of these Operating Instructions to indicate non-hazardous areas. – Devices used in hazardous areas must possess an appropriate type of protection. Cables used in hazardous areas must meet the necessary safety-related characteristic quantities.

	Direct current A terminal to which DC voltage is applied or through which direct current flows.
	Alternating current A terminal to which alternating voltage (sine-wave) is applied or through which alternating current flows.
	Ground connection A grounded terminal, which as far as the operator is concerned, is already grounded by means of a grounding system.
	Protective ground connection A terminal which must be connected to ground prior to establishing any other connections.
	Equipotential connection A connection that has to be connected to the plant grounding system: This may be a potential equalization line or a star grounding system depending on national or company codes of practice.
	Connecting cable immunity to temperature change Indicates that the connecting cables have to withstand a temperature of 85°C at least.

	Safety instructions Observe the safety instructions in the associated Operating Instructions.
---	---

2 Identification

2.1 Product identification

The following options are available for identification of the measuring device:

- Nameplate specifications
- Order code with breakdown of the device features on the delivery note
- Enter serial numbers from nameplates in W@M Device Viewer (www.endress.com/deviceviewer): All information about the measuring device is displayed.

For an overview of the technical documentation provided, enter the serial number from the nameplates in the W@M Device Viewer (www.endress.com/deviceviewer).

2.2 Device designation

2.2.1 Device identification via the nameplate



Note!

- The MWP (maximum working pressure) is specified on the nameplate. This value refers to a reference temperature of 20°C (68°F) or 100°F (38 °C) for ANSI flanges.
- The pressure values permitted at higher temperatures can be found in the following standards:
 - EN 1092-1: 2001 Tab. 18 ¹⁾
 - ASME B 16.5a – 1998 Tab. 2-2.2 F316
 - ASME B 16.5a – 1998 Tab. 2.3.8 N10276
 - JIS B 2220
- The test pressure corresponds to the over pressure limit (OPL) of the device = $MWP \times 1.5$ ²⁾.
- The Pressure Equipment Directive (EC Directive 97/23/EC) uses the abbreviation "PS". The abbreviation "PS" corresponds to the MWP (maximum working pressure) of the measuring device.

1) With regard to their stability-temperature property, the materials 1.4435 and 1.4404 are grouped together under 13EO in EN 1092-1 Tab. 18. The chemical composition of the two materials can be identical.

2) The equation does not apply for PMP51 and PMP55 with a 40 bar (600 psi) or a 100 bar (1500 psi) measuring cell.

Aluminum housing




Fig. 1: Nameplate

- 1 Device name
- 2 Order code (for re-orders)
- 3 Serial number (for identification)
- 4 Extended order code (complete)
- 5 MWP (maximum working pressure)
- 6 Electronic version (output signal)
- 7 Min./max. span
- 8 Nominal measuring range
- 9 Supply voltage
- 10 Unit of length
- 11 ID number of notified body with regard to ATEX (optional)
- 12 ID number of notified body with regard to Pressure Equipment Directive (optional)
- 13 Approvals
- 14 Device version
- 15 Software version
- 16 Degree of protection
- 17 Wetted materials
- 18 Approval-specific information

Devices suitable for oxygen applications are fitted with an additional nameplate.




Fig. 2: Additional nameplate for devices suitable for oxygen applications

- 1 Maximum pressure for oxygen applications
- 2 Maximum temperature for oxygen applications
- 3 Layout identification of the nameplate

Stainless steel housing, hygienic




Fig. 3: Nameplate for Cerabar M and Deltapilot M

- 1 Device name
- 2 Order code (for re-orders)
- 3 Serial number (for identification)
- 4 Extended order code (complete)
- 5 Nominal measuring range
- 6 MWP (maximum working pressure)
- 7 Length data
- 8 Electronic version (output signal)
- 9 Supply voltage
- 10 Min./max. span
- 11 Wetted materials
- 12 Approval-specific information
- 13 ID number of notified body with regard to ATEX (optional)
- 14 ID number of notified body with regard to Pressure Equipment Directive (optional)
- 15 Approvals
- 16 Software version
- 17 Device version
- 18 Degree of protection

Devices with certificates are fitted with an additional plate.




Fig. 4: Additional nameplate for devices with certificates

- 1 Approval-specific information

2.2.2 Identifying the sensor type

In the case of gauge pressure sensors, the "Pos. zero adjust" parameter appears in the operating menu ("Setup" -> "Pos. zero adjust").

In the case of absolute pressure sensors, the "Calib. offset" parameter appears in the operating menu ("Setup" -> "Calib. offset").

2.3 Scope of delivery

The scope of delivery comprises:

- Device
- Optional accessories

Documentation supplied:

- Operating Instruction BA00382P is available on the Internet.
→ See: www.endress.com → Download
- Brief Operating Instruction: KA01030P Cerabar M / KA01027P Deltabar M / KA01033P Deltapilot M
- Final inspection report
- Additional Safety Instructions for ATEX, IECEx and NEPSI devices
- Optional: factory calibration form, test certificates

2.4 CE mark, Declaration of Conformity

The devices are designed to meet state-of-the-art safety requirements, have been tested and left the factory in a condition in which they are safe to operate. The devices comply with the applicable standards and regulations as listed in the EC Declaration of Conformity and thus comply with the statutory requirements of the EC Directives. Endress+Hauser confirms the conformity of the device by affixing to it the CE mark.

2.5 Registered labels

KALREZ, VITON, TEFLON

Registered label of E.I. Du Pont de Nemours & Co., Wilmington, USA

TRI-CLAMP

Registered label of Ladish & Co., Inc., Kenosha, USA

HART

Registered label of the HART Communication Foundation, Austin, USA

GORE-TEX®

Registered label of W.L. Gore & Associates, Inc., USA

3 Installation

3.1 Incoming acceptance, transport, storage

3.1.1 Incoming acceptance

- Check the packaging and the contents for damage.
- Check the shipment, make sure nothing is missing and that the scope of supply matches your order.

3.1.2 Transport



Caution!

Follow the safety instructions and transport conditions for devices of more than 18 kg (39.69 lbs). Transport the measuring device to the measuring point in its original packaging or at the process connection.

3.1.3 Storage

The device must be stored in a dry, clean area and protected against damage from impact (EN 837-2).

Storage temperature range:

See Technical Information for Cerabar M TI00436P / Deltabar M TI00434P / Deltapilot M TI00437P.

3.2 Installation conditions

3.2.1 Dimensions

→ For dimensions, please refer to the Technical Information for Cerabar M TI00436P / Deltabar M TI00434P / Deltapilot M TI00437P, "Mechanical construction" section.

3.3 Installing Cerabar M



Note!


- Due to the orientation of the Cerabar M, there may be a shift in the zero point, i.e. when the container is empty or partially full, the measured value does not display zero. You can correct this zero point shift → § 40, Section "Function of the operating elements" or → § 58, Section 7.4 "Position zero adjustment".
- For PMP55, please refer to Section 3.3.2 "Installation instructions for devices with diaphragm seals – PMP55", → § 14.
- Endress+Hauser offers a mounting bracket for installing on pipes or walls. → § 16, Section 3.3.5 "Wall and pipe mounting (optional)".

3.3.1 Installation instructions for devices without diaphragm seals – PMP51, PMC51




Note!


- If a heated Cerabar M is cooled during the cleaning process (e.g. by cold water), a vacuum develops for a short time, whereby moisture can penetrate the sensor through the pressure compensation (1). If this is the case, mount the Cerabar M with the pressure compensation (1) pointing downwards.



- Keep the pressure compensation and GORE-TEX® filter (1) free from contamination.
- Cerabar M transmitters without diaphragm seals are mounted as per the norms for a manometer (DIN EN 837-2). We recommend the use of shutoff devices and siphons. The orientation depends on the measuring application.
- Do not clean or touch process isolating diaphragms with hard or pointed objects.
- The device must be installed as follows in order to comply with the cleanability requirements of the ASME-BPE (Part SD Cleanability):



Pressure measurement in gases




P01-PMx5xxxx-11-xx-xx-xx-003

Fig. 5: Measuring arrangement for pressure measurement in gases

- 1 Cerabar M
- 2 shutoff device

- Mount Cerabar M with shutoff device above the tapping point so that condensate which may be present, can flow into the process.

Pressure measurement in steams



P01-PMx5xxxx-11-xx-xx-xx-004

Fig. 6: Measuring arrangement for pressure measurement in steams

- 1 Cerabar M
- 2 shutoff device
- 3 U-shaped siphon
- 4 Circular siphon

- Mount Cerabar M with siphon above the tapping point.
- Fill the siphon with liquid before commissioning.
The siphon reduces the temperature to almost the ambient temperature.

Pressure measurement in liquids




Fig. 7: Measuring arrangement for pressure measurement in liquids

- 1 Cerabar M
2 shutoff device

- Mount Cerabar M with shutoff device below or at the same level as the tapping point.

Level measurement




Fig. 8: Measuring arrangement for level

- Always install the Cerabar M below the lowest measuring point.
- Do not mount the device in the filling curtain or at a point in the tank which could be affected by pressure pulses from an agitator.
- Do not mount the device in the suction area of a pump.
- The calibration and functional test can be carried out more easily if you mount the device downstream of a shutoff device.

PVDF interchangeable threaded boss



Note!

A maximum torque of 7 Nm (5.16 lbs ft) is permitted for devices with a PVDF interchangeable threaded boss. The thread connection may become loose at high temperatures and pressures. This means that the integrity of the thread must be checked regularly and may need to be tightened using the torque given above. Teflon tape is recommended for sealing the 1/2 NPT thread.

3.3.2 Installation instructions for devices with diaphragm seals – PMP55



Note!

- Cerabar M devices with diaphragm seals are screwed in, flanged or clamped, depending on the type of diaphragm seal.
- A diaphragm seal and the pressure transmitter together form a closed, oil-filled calibrated system. The fill fluid hole is sealed and may not be opened.
- Do not clean or touch the process isolating diaphragm of the diaphragm seal with hard or pointed objects.
- Do not remove process isolating diaphragm protection until shortly before installation.
- When using a mounting bracket, sufficient strain relief must be ensured for the capillaries in order to prevent the capillary bending down (bending radius ≥ 100 mm (3.94 in)).
- Please note that the hydrostatic pressure of the liquid columns in the capillaries can cause zero point shift. The zero point shift can be corrected. → 58, Section 7.4 "Position zero adjustment".
- Please observe the application limits of the diaphragm seal filling oil as detailed in the Technical Information for Cerabar M TI00436P, "Planning instructions for diaphragm seal systems" section.



In order to obtain more precise measurement results and to avoid a defect in the device, mount the capillaries as follows:

- Vibration-free (in order to avoid additional pressure fluctuations)
- Not in the vicinity of heating or cooling lines
- Insulate if the ambient temperature is below or above the reference temperature
- With a bending radius of ≥ 100 mm (3.94 in).


Vacuum application

For applications under vacuum, Endress+Hauser recommends mounting the pressure transmitter below the diaphragm seal. This prevents vacuum loading of the diaphragm seal caused by the presence of filling oil in the capillaries.

When the pressure transmitter is mounted above the diaphragm seal, the maximum height difference H1 in accordance with the illustration below left must not be exceeded. The maximum height difference depends on the density of the filling oil and the smallest ever pressure that is permitted to occur at the diaphragm seal (empty container), see illustration below right.




Mounting with temperature isolator



P01-FMx5xxxx-11-xx-xx-xx-008

Endress+Hauser recommends the use of temperature isolators in the event of constant extreme medium temperatures which lead to the maximum permissible electronics temperature of +85°C (+185°F) being exceeded. To minimize the influence of rising heat, Endress+Hauser recommends the device be mounted horizontally or with the housing pointing downwards. The additional installation height also brings about a zero point shift of approx. 21 mbar (0.315 psi) due to the hydrostatic column in the temperature isolator. You can correct this zero point shift. → 40 "Function of the operating elements" or → 58, Section 7.4 "Position zero adjustment".

3.3.3 Seal for flange mounting



P01-FMD7xxxx-11-xx-xx-xx-002

Fig. 11: Mounting the versions with a flange

- 1 Process isolating diaphragm
- 2 Seal




Warning!

The seal is not allowed to press against the process isolating diaphragm as this could affect the measurement result.

3.3.4 Thermal insulation – PMP55

The PMP55 may only be insulated up to a certain height. The maximum permitted insulation height is indicated on the devices and applies to an insulation material with a heat conductivity $\leq 0.04 \text{ W}/(\text{m} \times \text{K})$ and to the maximum permitted ambient and process temperature (→ see table below). The data were determined under the most critical application "quiescent air".




P01-PMx5xxxx-11-xx-xx-xx-010

Fig. 12: Maximum permitted insulation height, here indicated on a PMP55 with a flange

	PMP55
Ambient temperature (T_A)	$\leq 70^\circ\text{C}$ (158°F)
Process temperature (T_P)	Max. 400°C (752°F), depending on the diaphragm seal filling oil used (see TI00436PEN)

3.3.5 Wall and pipe mounting (optional)

Endress+Hauser offers a mounting bracket for installing on pipes or walls (for pipes from 1 1/4" up to 2" diameter).



P01-xMx5xxxx-06-xx-xx-xx-001

Please note the following when mounting:

- Devices with capillary tubes: mount capillaries with a bending radius $\geq 100 \text{ mm}$ (3.94 in).
- In the case of pipe mounting, the nuts on the bracket must be tightened uniformly with a torque of at least 5 Nm (3.69 lbs ft).

3.3.6 Assembling and mounting the "separate housing" version




Fig. 13: "Separate housing" version

- 1 In the case of the "separate housing" version, the sensor is delivered with the process connection and cable ready mounted.
- 2 Cable with connection jack
- 3 Pressure compensation
- 4 Connector
- 5 Locking screw
- 6 Housing mounted with housing adapter, included
- 7 Mounting bracket provided, suitable for pipe and wall mounting (for pipes from 1 1/4" up to 2" diameter)

Assembly and mounting

1. Insert the connector (item 4) into the corresponding connection jack of the cable (item 2).
2. Plug the cable into the housing adapter (item 6).
3. Tighten the locking screw (item 5).
4. Mount the housing on a wall or pipe using the mounting bracket (item 7).
When mounting on a pipe, tighten the nuts on the bracket uniformly with a torque of at least 5 Nm (3.69 lbs ft).
Mount the cable with a bending radius (r) ≥ 120 mm (4.72 in).

3.3.7 PMP51, version prepared for diaphragm seal mount – welding recommendation




Fig. 14: Version XSJ; prepared for diaphragm seal mount

- 1 Hole for fill fluid
- 2 Bearing
- 3 Setscrew
- A1 See the "Welding recommendation" table below

Endress+Hauser recommends welding on the diaphragm seal as follows for the "XSJ - Prepared for diaphragm seal mount" version in feature 110 "Process connections" in the order code up to, and including, 40 bar sensors: the total welding depth of the fillet weld is 1 mm (0.04 in) with an outer diameter of 16 mm (0.63 in). Welding is performed according to the WIG method.

Consecutive seam no.	Sketch/welding groove shape, dimension as per DIN 8551	Base material matching	Welding process DIN EN ISO 24063	Welding position	Inert gas, additives
A1 for sensors ≤ 40 bar (600 psi)		Adapter made of AISI 316L (1.4435) to be welded to diaphragm seal made of AISI 316L (1.4435 or 1.4404)	141	PB	Inert gas Ar/H 95/5 Additive: ER 316L Si (1.4430)

Information on filling

The diaphragm seal must be filled as soon as it has been welded on.


- After welding into the process connection, the sensor assembly must be properly filled with a filling oil and sealed gas-tight with a sealing ball and lock screw.
 - Once the diaphragm seal has been filled, the device display should not exceed 10% of the full scale value of the cell measuring range at the zero point. The internal pressure of the diaphragm seal must be corrected accordingly.
- Adjustment / calibration:
 - The device is operational once it has been fully assembled.
 - Once the device has been switched on, the total reset code (7864) must be entered in the path: "Expert" → "System" → "Management" → "Enter reset code (124)" (see also Section 5.3.7). The electronics then read all the specific sensor data out of the sensor electronics. The device then has to be calibrated to the process measuring range as explained in the Operating Instructions.

3.4 Installing Deltabar M



Note!

Disassembly of the screws with item number (1) is not permissible under any circumstances and will result in loss of warranty.



3.4.1 Installation position



Note!

- Due to the orientation of the Deltabar M, there may be a shift in the measured value, i.e. when the container is empty, the measured value does not display zero. You may correct this zero point shift by a position adjustment in one of the following ways:
 - via the operation keys on the electronics module (→ § 40, "Function of the operating elements")
 - via the operating menu (→ § 58, "Position zero adjustment")
- General recommendations for routing the impulse piping can be found in DIN 19210 "Methods for measurement of fluid flow; differential piping for flow measurement devices" or the corresponding national or international standards.
- Using a three-valve or five-valve manifold allows for easy commissioning, installation and maintenance without interrupting the process.
- When routing the impulse piping outdoors, ensure that sufficient anti-freeze protection is used, e.g. by using pipe heat tracing.
- Install the impulse piping with a monotonic gradient of at least 10%.
- Endress+Hauser offers a mounting bracket for installing on pipes or walls (→ § 24, "Wall and pipe-mounting (option)").


Installation position for flow measurement



Note!

For more information about differential pressure flow measurement refer to following documents:

- Differential pressure flow measurements with orifices: Technical Information TI00422P
- Differential pressure flow measurement with Pitot tubes: Technical Information TI00425P


Flow measurement in gases

P01-PMD55xxx-11-xx-xx-xx-000

Measuring layout for flow measurement in gases

- 1 Deltabar M
- 2 Three-valve manifold
- 3 Shut-off valves
- 4 Orifice plate or pitot tube

- Mount the Deltabar M above the measuring point so that the condensate which may be present, can run off into the process piping.

Flow measurement in steam


P01-PMD55xxx-11-xx-xx-xx-001

Measuring layout for flow measurement in steam

- 1 Condensate traps
- 2 Orifice plate or pitot tube
- 3 Shut-off valves
- 4 Deltabar M
- 5 Separator
- 6 Drain valves
- 7 Three-valve manifold

- Mount the Deltabar M below the measuring point.
- Mount the condensate traps at the same level as the tapping points and at the same distance to the Deltabar M.
- Prior to commissioning, fill the impulse piping to the height of the condensate traps.

Flow measurement in liquids



P01-PMD55xxxx-11-xx-xx-xx-002


Measuring layout for flow measurement in liquids

- 1 Orifice plate or pitot tube
- 2 Shut-off valves
- 3 Deltabar M
- 4 Separator
- 5 Drain valves
- 6 Three-valve manifold

- Mount the Deltabar M below the measuring point so that the impulse piping is always filled with liquid and gas bubbles can run back into the process piping.
- When measuring in media with solid parts, such as dirty liquids, installing separators and drain valves is useful for capturing and removing sediment.

Installation position for level measurement

Level measurement in an open container




P01-PMD55xxxx-11-xx-xx-xx-003

Measuring layout for level measurement in open containers

- 1 The low-pressure side is open to atmospheric pressure
- 2 Shut-off valve
- 3 Deltabar M
- 4 Separator
- 5 Drain valve

- Mount the Deltabar M below the lower measuring connection so that the impulse piping is always filled with liquid.
- The low-pressure side is open to atmospheric pressure.
- When measuring in media with solid parts, such as dirty liquids, installing separators and drain valves is useful for capturing and removing sediment.

Level measurement in a closed container




P01-PMD55xxx-11-xx-xx-004

Measuring layout for level measurement in a closed container

- 1 Shut-off valves
- 2 Deltabar M
- 3 Separator
- 4 Drain valves
- 5 Three-valve manifold

- Mount the Deltabar M below the lower measuring connection so that the impulse piping is always filled with liquid.
- Always connect the low-pressure side above the maximum level.
- When measuring in media with solid parts, such as dirty liquids, installing separators and drain valves is useful for capturing and removing sediment.

Level measurement in a closed container with superimposed steam



P01-PMD55xxx-11-xx-xx-005


Measuring layout for level measurement in a container with superimposed steam

- 1 Condensate trap
- 2 Shut-off valves
- 3 Deltabar M
- 4 Separator
- 5 Drain valves
- 6 Three-valve manifold

- Mount the Deltabar M below the lower measuring connection so that the impulse piping is always filled with liquid.
- Always connect the low-pressure side above the maximum level.
- A condensate trap ensures constant pressure on the low-pressure side.
- When measuring in media with solid parts, such as dirty liquids, installing separators and drain valves is useful for capturing and removing sediment.

Installation position for differential pressure measurement

Differential pressure measurement in gases and steam




P01-PMD55xxx-11-xx-xx-xx-006

Measuring layout for differential pressure measurement in gases and steam

- 1 Deltabar M
- 2 Three-valve manifold
- 3 Shut-off valves
- 4 e.g. filter

- Mount the Deltabar M above the measuring point so that the condensate which may be present, can run off into the process piping.

Differential pressure measurement in liquids



P01-PMD55xxx-11-xx-xx-xx-007

Measuring layout for differential pressure measurement in liquids

- 1 e.g. filter
- 2 Shut-off valves
- 3 Deltabar M
- 4 Separator
- 5 Drain valves
- 6 Three-valve manifold

- Mount the Deltabar M below the measuring point so that the impulse piping is always filled with liquid and gas bubbles can run back into the process piping.
- When measuring in media with solid parts, such as dirty liquids, installing separators and drain valves is useful for capturing and removing sediment.


3.4.2 Wall and pipe-mounting (option)

Endress+Hauser offers a mounting bracket for installing the device on pipes or walls. A bracket with mounting accessories is included with the device if ordered.



Note!

When using a valve block, the block's dimensions must be taken into account.



P01-PMD55xxx-06-xx-xx-xx-004

Mounting bracket for wall and pipe mounting

1 *Adaption plate (+ six screws and six washers)*

2 *Mounting bracket (+ bracket for pipe mounting and two nuts)*


Please note the following when mounting:

- To prevent the mounting screws from scoring, lubricate them with a multi-purpose grease prior to mounting.
- In the case of pipe mounting, the nuts on the bracket must be tightened uniformly with a torque of at least 30 Nm (22.13 lbf ft).
- For installation purposes, only use the screws with item number (2) (see the following diagram).




Note!

Installation of the mounting bracket at the screws with item number (1) is not permissible and will result in loss of warranty.



Typical installation arrangements



A: Impulse line vertical, version V1, alignment 90°
 B: Impulse line horizontal, version H1, alignment 180°
 C: Impulse line horizontal, version H2, alignment 90°
 1: Deltabar M; 2: Adapter; 3: Mounting bracket

3.5 Installing Deltapilot M



Note!


- Due to the orientation of the Deltapilot M, there may be a shift in the zero point, i.e. when the container is empty or partially full, the measured value does not display zero. You can correct this zero point shift → § 40, Section "Function of the operating elements" or → § 58, Section 7.4 "Position zero adjustment".
- The local display can be rotated in 90° stages.
- Endress+Hauser offers a mounting bracket for installing on pipes or walls.
→ § 16, Section 3.3.5 "Wall and pipe mounting (optional)".

3.5.1 General installation instructions




Note!

- Do not clean or touch process isolating diaphragms with hard or pointed objects.
- The process isolating diaphragm in the rod and cable version is protected against mechanical damage by a plastic cap.
- If a heated Deltapilot M is cooled during the cleaning process (e.g. by cold water), a vacuum develops for a short time, whereby moisture can penetrate the sensor through the pressure compensation (1). If this is the case, mount the Deltapilot M with the pressure compensation (1) pointing downwards.



- Keep the pressure compensation and GORE-TEX® filter (1) free from contamination.
- The device must be installed as follows in order to comply with the cleanability requirements of the ASME-BPE (Part SD Cleanability):



3.5.2 FMB50

Level measurement




Fig. 15: Measuring arrangement for level

- Always install the device below the lowest measuring point.
- Do not install the device at the following positions:
 - in the filling curtain
 - in the tank outflow
 - in the suction area of a pump
 - or at a point in the tank that can be affected by pressure pulses from the agitator
- The calibration and functional test can be carried out more easily if you mount the device downstream of a shutoff device.
- Deltapilot M must be included in the insulation for media that can harden when cold.

Pressure measurement in gases

- Mount Deltapilot M with shutoff device above the tapping point so that any condensate can flow into the process.

Pressure measurement in steams


- Mount Deltapilot M with siphon above the tapping point.
- Fill the siphon with liquid before commissioning.
The siphon reduces the temperature to almost the ambient temperature.

Pressure measurement in liquids


- Mount Deltapilot M with the shutoff device below or at the same level as the tapping point.

3.5.3 FMB51/FMB52/FMB53

- When mounting rod and cable versions, make sure that the probe head is located at a point as free as possible from flow. To protect the probe from impact resulting from lateral movement, mount the probe in a guide tube (preferably made of plastic) or secure it with a clamping fixture.
- In the case of devices for hazardous areas, comply strictly with the safety instructions when the housing cover is open.
- The length of the extension cable or the probe rod is based on the planned level zero point. The height of the protective cap must be taken into consideration when designing the layout of the measuring point. The level zero point (E) corresponds to the position of the process isolating diaphragm.
Level zero point = E; top of the probe = L.



3.5.4 Mounting the FMB53 with a mounting clamp



P01-FMBX21xxx-17-xx-xx-xx-004

Fig. 16: Mounting with a mounting clamp

- 1 Extension cable
- 2 Mounting clamp
- 3 Clamping jaws

Mounting the mounting clamp:

1. Mount the mounting clamp (item 2). When selecting the place to fix the unit, take the weight of the extension cable (item 1) and the device into account.
2. Raise the clamping jaws (item 3). Position the extension cable (item 1) between the clamping jaws as illustrated in Figure 16.
3. Hold the extension cable in position (item 1) and push the clamping jaws (item 3) back down. Tap the clamping jaws gently from above to fix them in place.

3.5.5 Seal for flange mounting




Fig. 17: Mounting the versions with a flange

- 1 Process isolating diaphragm
- 2 Seal




Warning!

The seal is not allowed to press against the process isolating diaphragm as this could affect the measurement result.

3.5.6 Wall and pipe mounting (optional)


Mounting bracket

Endress+Hauser offers a mounting bracket for installing on pipes or walls (for pipes from 1 1/4" up to 2" diameter).



In the case of pipe mounting, the nuts on the bracket must be tightened uniformly with a torque of at least 5 Nm (3.69 lbf ft).

3.5.7 Assembling and mounting the "separate housing" version



P01-3Mx5xxxx-11-zz-zz-009

Fig. 18: "Separate housing" version

- 1 In the case of the "separate housing" version, the sensor is delivered with the process connection and cable ready mounted.
- 2 Cable with connection jack
- 3 Pressure compensation
- 4 Connector
- 5 Locking screw
- 6 Housing mounted with housing adapter, included
- 7 Mounting bracket provided, suitable for pipe and wall mounting (for pipes from 1 1/4" up to 2" diameter)

Assembly and mounting

1. Insert the connector (item 4) into the corresponding connection jack of the cable (item 2).
2. Plug the cable into the housing adapter (item 6).
3. Tighten the locking screw (item 5).
4. Mount the housing on a wall or pipe using the mounting bracket (item 7).
When mounting on a pipe, tighten the nuts on the bracket uniformly with a torque of at least 5 Nm (3.69 lbf ft).
Mount the cable with a bending radius (r) \geq 120 mm (4.72 in).

Routing the cable (e.g. through a pipe)

You require the cable shortening kit.

Order number: 71093286

For details on mounting, see SD00553P/00/A6.

3.5.8 Supplementary installation instructions

Seal

- Deltapilot M with a G 1 1/2 thread:
When screwing the device into the tank, the flat seal has to be positioned on the sealing surface of the process connection. To avoid additional strain on the process isolating diaphragm, the thread should never be sealed with hemp or similar materials.
- Deltapilot M with NPT threads:
 - Wrap Teflon tape around the thread to seal it.
 - Tighten the device at the hexagonal bolt only. Do not turn at the housing.
 - Do not overtighten the thread when screwing. Max. torque: 20 to 30 Nm (14.75 to 22.13 lbf ft)

Sealing the probe housing

- Moisture must not penetrate the housing when mounting the device, establishing the electrical connection and during operation.
- Always firmly tighten the housing cover and the cable entries.

3.6 Mounting of the profile seal for universal process mounting adapter

For details on mounting, see KA00096F/00/A3.

3.7 Closing the housing cover



Note!

When closing the housing cover, please ensure that the thread of the cover and housing are free from dirt, e.g. sand. If you feel any resistance when closing the cover, check the thread on both again to ensure that they are free from dirt.

3.7.1 Closing the cover on the stainless steel housing




Fig. 19: Closing the cover

The cover for the electronics compartment is tightened by hand at the housing until the stop. The screw serves as DustEx protection (only available for devices with DustEx approval).

3.8 Post-installation check

After installing the device, carry out the following checks:

- Are all screws firmly tightened?
- Are the housing covers screwed down tight?
- Are all locking screws and vent valves (Deltabar M only) firmly tightened?

4 Wiring

4.1 Connecting the device



Warning!

Risk of electric shock and/or explosion in hazardous areas! In a wet environment, do not open the cover if voltage is present.




Note!

- When using the measuring device in hazardous areas, installation must comply with the corresponding national standards and regulations and the Safety Instructions or Installation or Control Drawings.
- A suitable circuit breaker has to be provided for the device in accordance with IEC/EN 61010.
- Devices with integrated overvoltage protection must be earthed.
- Protective circuits against reverse polarity, HF influences and overvoltage peaks are integrated.

The procedure

1. Check if the supply voltage matches the specified supply voltage on the nameplate.
2. Switch off the supply voltage before connecting the device.
3. Remove housing cover.
4. Guide cable through the gland. Preferably use twisted, screened two-wire cable.
5. Connect device in accordance with the following diagram.
6. Screw down housing cover.
7. Switch on supply voltage.



P01-PMD55xxx-04-xx-xx-xx-010

Electrical connection 4...20 mA HART

- 1 Terminals for supply voltage and signal
- 2 Test terminals
- 3 Grounding terminal
- 4 Supply voltage: 11,5 ... 45 VDC (versions with plug connectors: 35 V DC)
- 5 External ground terminal

4.1.1 Connecting devices with a Harting connector Han7D




Fig. 20: Left: electrical connection for devices with a Harting connector Han7D
Right: view of the connection at the device

4.1.2 Connecting devices with an M12 connector

PIN assignment for M12 connector

	PIN	Meaning
	1	Signal +
	2	Not assigned
	3	Signal -
	4	Earth

4.1.3 Devices with valve connector




Fig. 21: BN = brown, BU = blue, GNYE = green/yellow
Left: electrical connection for devices with a valve connector
Right: view of the connector at the device

4.2 Connecting the measuring unit

4.2.1 Supply voltage



Note!

- When using the measuring device in hazardous areas, installation must comply with the corresponding national standards and regulations and the Safety Instructions or Installation or Control Drawings.
- All explosion protection data are given in separate documentation which is available upon request. The Ex documentation is supplied as standard with all devices approved for use in explosion hazardous areas.

Electronic version	
4 to 20 mA HART, for non-hazardous areas	11.5 to 45 V DC (versions with plug-in connector 35 V DC)

Taking 4 to 20 mA test signal

A 4 to 20 mA test signal may be measured via the test terminals without interrupting the measurement. To keep the corresponding measured error below 0.1%, the current measuring device should exhibit an internal resistance of $< 0.7 \Omega$.

4.2.2 Cable specification

- Endress+Hauser recommends using twisted, shielded two-wire cables.
- Terminals for wire cross-sections 0.5 to 2.5 mm^2 (20 to 14 AWG)
- Cable outer diameter: 5 to 9 mm (0.2 to 0.35 in) depends on the used cable gland (see technical information)

4.2.3 Load




Fig. 22: Load diagram

Supply voltage 11.5 to 45 V DC (versions with plug-in connector 35 V DC) for other types of protection and for uncertified device versions

R_{Lmax} Maximum load resistance
 U Supply voltage



Note!

When operating via a handheld terminal or via a PC with an operating program, a minimum communication resistance of 250Ω must be taken into account.

4.2.4 Shielding/potential equalization

- A normal device cable suffices if only the analog signal is used. A shielded cable is recommended if using the HART protocol. Observe grounding concept of the plant.
- When using in hazardous areas, you must observe the applicable regulations. Separate Ex documentation with additional technical data and instructions is included with all Ex systems as standard. Connect all devices to the local potential equalization.

4.2.5 Connecting Field Xpert SFX100

Compact, flexible and robust industry handheld terminal for remote parametrization and measured value inspection via the HART current output (4-20mA).

For details refer to Operating Instructions BA00060S/04/EN.

4.2.6 Connecting Commubox FXA195


The Commubox FXA195 connects intrinsically safe transmitters with the HART protocol to a computer's USB port. This allows remote operation of the transmitter using Endress+Hauser's FieldCare operating program. Power is supplied to the Commubox through the USB port. The Commubox is also suitable for connection to intrinsically safe circuits. → See Technical Information TI00404F for further information.

4.3 Overvoltage protection (optional)

Devices showing version "NA" in feature 610 "Accessory mounted" in the order code are equipped with overvoltage protection (→ see also Technical Information TI00436P Cerabar M / TI00434P Deltabar M / TI00437P Deltapilot M "Ordering information"). The overvoltage protection is mounted at the factory on the housing thread for the cable gland and is approx. 70 mm (2.76 in) in length (take additional length into account when installing).


The device is connected as specified in the following graphic. For details, see TI001013KEN, XA01003KA3 and BA00304KA2.

4.3.1 Wiring



P01-xMx5xxxx-04-xx-xx-es-006

4.3.2 Installation



P01-xMx5xxxx-04-xx-xx-es-007

4.4 Post-connection check

Perform the following checks after completing electrical installation of the device:



- Does the supply voltage match the specifications on the nameplate?
- Is the device connected as per Section 4.1?
- Are all screws firmly tightened?
- Are the housing covers screwed down tight?

As soon as voltage is applied to the device, the green LED on the electronic insert lights up for a few seconds or the connected local display lights up.

5 Operation







5.1 Operating options

5.1.1 Operation without operating menu

Operating options	Explanation	Graphic illustration	Description
Local operation without device display	The device is operated using the operating keys and DIP switches on the electronic insert.		→  39

5.1.2 Operation with operating menu


Operation with an operating menu is based on an operation concept with "user roles" →  41.

Operating options	Explanation	Graphic illustration	Description
Local operation with device display	The device is operated using the operating keys on the device display.		→  43
Remote operation via HART handheld terminal	The device is operated using the HART handheld terminal (e.g. SFX100).		→  48
Remote operation via FieldCare	The device is operated using the FieldCare operating tool.		→  48

5.2 Operation without operating menu

5.2.1 Position of operating elements

The operating keys and DIP switches are located on the electronic insert in the device.



P01-Mxxxxxxx-19-xx-xx-xx-001

Fig. 23: HART electronic insert

- 1 DIP switch for locking/unlocking parameters relevant to the measured value
- 2 DIP switch for switching damping on/off
- 3 DIP switch for alarm current SW / Alarm Min (3.6 mA)
- 4 DIP switch only for Deltabar M:
Switch 4: "SW/Square root"; used to control the output characteristics
Switch 5: "SW/P2=High"; used to determine the high-pressure side
- 5 Slot for optional local display
- 6 Green LED to indicate successful operation
- 7 Operating keys for lower range value (zero) and upper range value (span)



Function of the DIP switches

Switches	Symbol/ labeling	Switch position	
		"off"	"on"
1		The device is unlocked. Parameters relevant to the measured value can be modified.	The device is locked. Parameters relevant to the measured value cannot be modified.
2	damping τ	Damping is switched off. The output signal follows measured value changes without any delay.	Damping is switched on. The output signal follows measured value changes with the delay time τ . ¹⁾
3	SW/Alarm min	The alarm current is defined by the setting in the operating menu. ("Setup" -> "Extended setup" -> "Curr. output" -> "Output fail mode")	The alarm current is 3.6 mA regardless of the setting in the operating menu.
The following switches only for Deltabar M:			
4	SW/ $\sqrt{\quad}$	The output characteristics is defined by the setting in the operating menu. <ul style="list-style-type: none"> ■ "Setup" -> "Measuring mode" ■ "Setup" -> "Extended Setup" -> "Current output" -> "Linear/Sqroot" 	The measuring mode is "flow" and the output characteristics is "Square root" regardless of the settings in the operating menu.

Switches	Symbol/ labeling	Switch position	
		"off"	"on"
5	SW/P2= High	The high-pressure side is defined by the setting in the operating menu. ("Setup" -> "High Press. Side")	The high-pressure side is allocated to the P2 pressure connection regardless of the setting in the operating menu.

- 1) The value for the delay time can be configured via the operating menu ("Setup" -> "Damping").
Factory setting: $\tau = 2$ s or as per order specifications.

Function of the operating elements

Operating key(s)	Meaning
"Zero" pressed for at least 3 seconds	Get LRV <ul style="list-style-type: none"> ■ "Pressure" measuring mode The pressure present is accepted as the lower range value (LRV). ■ "Level" measuring mode, "In pressure" level selection, "Wet" calibration mode The pressure present is assigned to the lower level value ("Empty calibration"). <p> Note! No function is assigned to the key if level selection = "In height" and/or calibration mode = "Dry"</p> <ul style="list-style-type: none"> ■ "Flow" measuring mode There is no function allocated to the "Zero" key.
"Span" pressed for at least 3 seconds	Get URV <ul style="list-style-type: none"> ■ "Pressure" measuring mode The pressure present is accepted as the upper range value (URV). ■ "Level" measuring mode, "In pressure" level selection, "Wet" calibration mode The pressure present is assigned to the upper level value ("Full calibration"). <p> Note! No function is assigned to the key if level selection = "In height" and/or calibration mode = "Dry"</p> <ul style="list-style-type: none"> ■ "Flow" measuring mode The pressure present is accepted as the maximum pressure ("Max. pressure flow") and allocated to the maximum flow ("max. flow").
"Zero" and "Span" pressed simultaneously for at least 3 seconds	Position adjustment The sensor characteristic curve is shifted such that the pressure present becomes the zero value.
"Zero" and "Span" pressed simultaneously for at least 12 seconds	Reset All parameters are reset to the order configuration.

5.2.2 Locking/unlocking operation

Once you have entered all the parameters, you can lock your entries against unauthorized and undesired access.




Note!

If operation is locked by means of the DIP switch, you can only unlock operation again by means of the DIP switch. If operation is locked by means of the operating menu, you can only unlock operation again using the operating menu.

Locking/unlocking via DIP switches

DIP switch 1 on the electronic insert is used to lock/unlock operation.

→  39, "Function of the DIP switches".

5.3 Operation with an operating menu

5.3.1 Operation concept

The operation concept makes a distinction between the following user roles:

User role	Meaning
Operator	Operators are responsible for the devices during normal "operation". This is usually limited to reading process values either directly at the device or in a control room. If the work with the devices extends beyond value read-off tasks, the tasks involve simple, application-specific functions that are used in operation. Should an error occur, these users simply forward the information on the errors but do not intervene themselves.
Service engineer/ technician	Service engineers usually work with the devices in the phases following device commissioning. They are primarily involved in maintenance and troubleshooting activities for which simple settings have to be made at the device. Technicians work with the devices over the entire life cycle of the product. Thus, commissioning and advanced settings and configurations are some of the tasks they have to carry out.
Expert	Experts work with the devices over the entire product life cycle, but their device requirements are often extremely high. Individual parameters/functions from the overall functionality of the devices are required for this purpose time and again. In addition to technical, process-oriented tasks, experts can also perform administrative tasks (e.g. user administration). "Experts" can avail of the entire parameter set.

5.3.2 Structure of the operating menu

User role	Submenu	Meaning/use
Operator	Language	Only consists of the "Language" parameter (000) where the operating language for the device is specified. The language can always be changed even if the device is locked.
Operator	Display/operat.	Contains parameters that are needed to configure the measured value display (selecting the values displayed, display format, display contrast, etc.). With this submenu, users can change the measured value display without affecting the actual measurement.
Service engineer/ technician	Setup	Contains all the parameters that are needed to commission measuring operations. This submenu has the following structure: <ul style="list-style-type: none"> ■ Standard setup parameters A wide range of parameters, which can be used to configure a typical application, is available at the start. The measuring mode selected determines which parameters are available. After making settings for all these parameters, the measuring operation should be completely configured in the majority of cases. ■ "Extended setup" submenu The "Setup" submenu contains additional parameters for more in-depth configuration of the measurement operation to convert the measured value and to scale the output signal. This menu is split into additional submenus depending on the measuring mode selected.
Service engineer/ technician	Diagnosis	Contains all the parameters that are needed to detect and analyze operating errors. This submenu has the following structure: <ul style="list-style-type: none"> ■ Diagnostic list Contains up to 10 error messages currently pending. ■ Event logbook Contains the last 10 error messages (no longer pending). ■ Instrument info Contains information on the device identification. ■ Measured values Contains all the current measured values ■ Simulation Is used to simulate pressure, level, flow, current and alarm/warning. ■ Reset

User role	Submenu	Meaning/use
Expert	Expert	<p>Contains all the parameters of the device (including those in one of the submenus). The "Expert" submenu is structured by the function blocks of the device. It thus contains the following submenus:</p> <ul style="list-style-type: none"> ■ System Contains all the device parameters that neither affect measurement nor integration into a distributed control system. ■ Measurement Contains all the parameters for configuring the measurement. ■ Output Contains all the parameters for configuring the current output. ■ Communication Contains all the parameters for configuring the HART interface. ■ Application Contains all the parameters for configuring the functions that go beyond the actual measurement (e.g. totalizer). ■ Diagnosis Contains all the parameters that are needed to detect and analyze operating errors.



Note!

For an overview of the entire operating menu: → 102 ff.

Direct access to parameters

The parameters can only be accessed directly via the "Expert" user role.

Parameter name	Description
Direct access (119) Entry Menu path: Expert → Direct access	<p>Enter the direct access code to go directly to a parameter.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ Enter the desired parameter code. <p>Factory setting: 0</p> <p>Note: For direct access, it is not necessary to enter leading zeros.</p>


5.3.3 Operation with a device display (optional)

A 4-line liquid crystal display (LCD) is used for display and operation. The local display shows measured values, dialog texts, fault messages and notice messages.

For easy operation the display can be taken out of the housing (see figure steps 1 to 3). It is connected to the device through a 90 mm (3.54 in) cable.

The display of the device can be turned in 90° stages (see figure steps 4 to 6).


Depending on the orientation of the device, this makes it easy to operate the device and read the measured values.



P01-Mxxxxxxx-19-xx-xx-xx-008

Functions:




- 8-digit measured value display including sign and decimal point, bargraph for 4 to 20 mA HART as current display
- Three keys for operation
- Simple and complete menu guidance as parameters are split into several levels and groups
- Each parameter is given a 3-digit parameter code for easy navigation
- Possibility of configuring the display to suit individual requirements and preferences, such as language, alternating display, contrast setting, display of other measured values such as sensor temperature etc.
- Comprehensive diagnostic functions (fault and warning message etc.)









P01-Mxxxxxxx-07-xx-xx-xx-002

The following table illustrates the symbols that can appear on the local display. Four symbols can occur at one time.

Symbol	Meaning
	Lock symbol The operation of the device is locked. To unlock the device, → 49, Locking/unlocking operation.
	Communication symbol Data transfer via communication
	Square root symbol Active measuring mode "Flow measurement" The root flow signal is used for the current output.
	Error message "Out of specification" The device is being operated outside its technical specifications (e.g. during warmup or cleaning processes).




Symbol	Meaning
	Error message "Service mode" The device is in the service mode (during a simulation, for example).
	Error message "Maintenance required" Maintenance is required. The measured value remains valid.
	Error message "Failure detected" An operating error has occurred. The measured value is no longer valid.

Operating keys on the display and operating module

Operating key(s)	Meaning
	<ul style="list-style-type: none"> – Navigate downwards in the picklist – Edit the numerical values and characters within a function
	<ul style="list-style-type: none"> – Navigate upwards in the picklist – Edit the numerical values and characters within a function
	<ul style="list-style-type: none"> – Confirm entry – Jump to the next item – Selection of a menu item and activation of the editing mode
	Contrast setting of local display: darker
	Contrast setting of local display: brighter
	ESC functions: <ul style="list-style-type: none"> – Exit the edit mode for a parameter without saving the changed value. – You are in a menu at a selection level. Each time you press the keys simultaneously, you go up a level in the menu.






Parameters with a picklist


Example: selecting "Deutsch" as the language of the menu.

Local display	Operation
 <p style="text-align: right; font-size: small;">P01-PMD55xxx-19-xx-xx-xx-002</p>	<p>"English" is set as the menu language (default value). A ✓ in front of the menu text indicates the active option.</p>
 <p style="text-align: right; font-size: small;">P01-PMD55xxx-19-xx-xx-xx-001</p>	<p>Select "Deutsch" with "+" or "-".</p>
 <p style="text-align: right; font-size: small;">P01-PMD55xxx-19-xx-xx-xx-000</p>	<ol style="list-style-type: none"> 1. Confirm your choice with "E". A ✓ in front of the menu text indicates the active option. ("Deutsch" is now selected as the menu language.) 2. Exit the edit mode for the parameter with "E".

User-definable parameters





Example: setting "Set URV" parameter from 100 mbar (1.5 psi) to 50 mbar (0.75 psi).

Local display	Operation
 <p style="text-align: right; font-size: small;">P01-PMD55xxx-19-xx-xx-xx-003</p>	<p>The local display shows the parameter to be changed. The value highlighted in black can be changed. The "mbar" unit is specified in another parameter and cannot be modified here.</p>
 <p style="text-align: right; font-size: small;">P01-PMD55xxx-19-xx-xx-xx-004</p>	<ol style="list-style-type: none"> 1. Press "+" or "-" to get to the editing mode. 2. The first digit is highlighted in black.
 <p style="text-align: right; font-size: small;">P01-PMD55xxx-19-xx-xx-xx-005</p>	<ol style="list-style-type: none"> 1. Use "+" to change "1" to "5". 2. Confirm "5" with "E". The cursor jumps to the next position (highlighted in black). 3. Confirm "0" with "E" (second position).
 <p style="text-align: right; font-size: small;">P01-PMD55xxx-19-xx-xx-xx-006</p>	<p>The third position is highlighted in black and can now be edited.</p>
 <p style="text-align: right; font-size: small;">P01-PMD55xxx-19-xx-xx-xx-007</p>	<ol style="list-style-type: none"> 1. Switch to the "-" symbol with the "-" key. 2. Use "E" to save the new value and exit the editing mode. → See next graphic.

Local display	Operation
 <p style="text-align: right; font-size: small;">P01-PMD55xxx-19-xx-xx-xx-008</p>	<p>The new value for the upper range value is 50.0 mbar (0.75 psi).</p> <ul style="list-style-type: none"> - You exit the edit mode for the parameter with "E" . - You can get back to the editing mode with "+" or "-".

Accepting the pressure present

Example: setting position adjustment

Local display	Operation
 <p style="text-align: right; font-size: small;">P01-PMD55xxx-19-xx-xx-xx-009</p>	<p>The pressure for position adjustment is present at the device.</p>
 <p style="text-align: right; font-size: small;">P01-PMD55xxx-19-xx-xx-xx-010</p>	<p>Use "+" or "-" to switch to the "Confirm" option. The active option is highlighted in black.</p>
 <p style="text-align: right; font-size: small;">P01-PMD55xxx-19-xx-xx-xx-011</p>	<p>Accept the pressure present as position adjustment with the "E" key. The device confirms the adjustment and goes back to the "Pos. zero adjust" parameter.</p>
 <p style="text-align: right; font-size: small;">P01-PMD55xxx-19-xx-xx-xx-009</p>	<p>Exit the edit mode for the parameter with "E" .</p>

5.3.4 Operation via SFX100

Compact, flexible and robust industry handheld terminal for remote parametrization and measured value inspection via the HART current output (4-20mA).

For details refer to Operating Instructions BA00060S/04/EN.

5.3.5 Operation via FieldCare

FieldCare is an Endress+Hauser asset management tool based on FDT technology. With FieldCare, you can configure all Endress+Hauser devices as well as devices from other manufacturers that support the FDT standard. Hardware and software requirements you can find on the internet: www.endress.com → select your country → Search: FieldCare → FieldCare → Technical Data.

FieldCare supports the following functions:


- Configuration of transmitters in online/offline mode
- Loading and saving device data (upload/download)
- Documentation of the measuring point
- Offline parametrization of transmitters

Connection options:

- HART via Commubox FXA195 and the USB port of a computer
- HART via Fieldgate FXA520




Note!

- →  35, Section 4.2.6 "Connecting Commubox FXA195".
- In "Level expert" measuring mode, the configuration data which were generated by FDT upload cannot be saved back again (FDT download); they are used solely to document the configuration.
- Further information on FieldCare can be found on the Internet (<http://www.endress.com>, Download → Search for: FieldCare).
- As not all internal device dependencies can be mapped in offline operation, the consistency of the parameters must be checked before the parameters are transmitted to the device.

5.3.6 Locking/unlocking operation

Once you have entered all the parameters, you can lock your entries against unauthorized and undesired access.

Locked operation is indicated as follows:

- By the  symbol on the onsite display
- The parameters are grayed out in FieldCare and the HART handheld terminal, which means they cannot be edited. Indicated in the corresponding "Locking" parameter.


Parameters which refer to how the display appears, e.g. "Language" and "Display contrast", can still be altered.



Note!

If operation is locked by means of the DIP switch, you can only unlock operation again by means of the DIP switch. If operation is locked by means of the operating menu, you can only unlock operation again using the operating menu.

The "Operator code" parameter is used to lock and unlock the device.


Parameter name	Description
Operator code (021) Entry Menu path: Setup → Extended setup → Operator code	Use this function to enter a code to lock or unlock operation. User input: <ul style="list-style-type: none"> ■ To lock: Enter a number ≠ the release code (value range: 1 to 9999). ■ To unlock: Enter the release code.  Note! The release code is "0" in the order configuration. Another release code can be defined in the "Code definition" parameter. If the user has forgotten the release code, the release code can be visible by entering the number "5864". Factory setting: 0

The release code is defined in the "Code definition" parameter.

Parameter name	Description
Code definition (023) Entry Menu path: Setup → Extended setup → Code definition	Use this function to enter a release code with which the device can be unlocked. User input: <ul style="list-style-type: none"> ■ A number between 0 and 999 Factory setting: 0

5.3.7 Resetting to factory settings (reset)

By entering a certain code, you can completely, or partially, reset the entries for the parameters to the factory settings¹⁾. Enter the code by means of the "Enter reset code" parameter (menu path: "Expert" → "System" → "Management" → "Enter reset code").

There are various reset codes for the device. The following table illustrates which parameters are reset by the particular reset codes. Operation must be unlocked to reset parameters (→  49).



Note!

Any customer-specific configuration carried out at the factory is not affected by a reset (customer-specific configuration remains). If you want to change the customer-specific configuration carried out at the factory, please contact Endress+Hauser Service.

As no separate service level is provided, the order code and serial number may be changed without a specific unblocking code (e.g. after replacing the electronics).


Reset code ¹⁾	Description and effect
62	PowerUp reset (warm start) <ul style="list-style-type: none"> ■ The device is restarted. ■ Data are read back anew from the EEPROM (processor is initialized again). ■ Any simulation which may be running is ended.
333	User reset <ul style="list-style-type: none"> ■ This code resets all the parameters apart from: <ul style="list-style-type: none"> – Device tag (022) – Linearization table – Operating hours (162) – Event logbook – Current trim 4mA (135) – Current trim 20mA (136) – Lo trim sensor (131) – Hi trim sensor (132) ■ Any simulation which may be running is ended. ■ The device is restarted.
7864	Total reset <ul style="list-style-type: none"> ■ This code resets all the parameters apart from: <ul style="list-style-type: none"> – Operating hours (162) – Event logbook – Lo trim sensor (131) – Hi trim sensor (132) ■ Any simulation which may be running is ended. ■ The device is restarted.

1) To be entered in "System" → "Management" → "Enter reset code" (124)



Note!

After a "Total reset" in FieldCare you have to press the "refresh" button in order to ensure that the measuring units are also reset.

1) The default value for the individual parameters is indicated in the parameter description (→  110 ff)

6 Integrating transmitter using HART® protocol

Version data for the device

Firmware version	01.00.zz	<ul style="list-style-type: none"> ■ On the title page of the Operating instructions ■ On nameplate ■ Firmware Version parameter Diagnostics → Instrument info → Firmware-Version
Manufacturer ID	17 (0x11)	Parameter Manufacturer Id Diagnostics → Instrument info → Manufacturer ID
Device type ID	Cerabar M: 25 (0x19) Deltabar M: 33 (0x21) Deltapilot M: 35 (0x23)	Parameter Device ID Diagnostics → Instrument info → Device ID
HART protocol revision	6.0	—
Device revision	1	<ul style="list-style-type: none"> ■ On transmitter nameplate ■ Device revision parameter Diagnostics → Instrument info → Device revision

The suitable device description file (DD) for the individual operating tools is listed in the table below, along with information on where the file can be acquired.

Operating tools

Operating tool	Reference sources for device descriptions (DD and DTM)
FieldCare	<ul style="list-style-type: none"> ■ www.endress.com → Download-Area ■ CD-ROM (contact Endress+Hauser) ■ DVD (contact Endress+Hauser)
AMS Device Manager (Emerson Process Management)	www.endress.com → Download-Area
SIMATIC PDM (Siemens)	www.endress.com → Download-Area
Field Communicator 375, 475 (Emerson Process Management)	Use update function of handheld terminal

6.1 HART process variables and measured values

The following numbers are assigned to the process variables in the factory:

Process variable	Pressure	Flow (Deltabar only)		Level	
		Linear	Square root	Linear	Table active
First process variable (Primary Variable)	0 - Measured pressure	0 - Measured pressure	5 - Flow	8 - Level before linearization	9 - Tank content
Second process variable (Secondary Variable)	2 - Druck n. Lagekor	5 - Flow	0 - Measured pressure	0 - Measured pressure	8 - Level before linearization
Third process variable (Tertiary Variable)	3 - Sensor pressure	6 - Totalizer 1	6 - Totalizer 1	2 - Corrected press.	0 - Measured pressure
Fourth process variable (Quaternary Variable)	Deltabar M: 251 - None Apart from Deltabar M: Sensor temp.				



Note!

The assignment of the device variables to the process variable is displayed in the **Expert → Communication → HART output** menu.

The assignment of the device variables to the process variable can be changed using HART command 51. An overview of the possible device variables can be found in the following section.

6.2 Device variables and measured values

The following measured values are assigned to the individual device variables:

Device-Variable Code	Device variable	Measured value	Operating mode	Devices
0	PRESSURE_1_FINAL_VALUE	Meas. pressure	all	all
1	PRESSURE_1_AFTER_DAMPING	Pressure af. damp	all	all
2	PRESSURE_1_AFTER_CALIBRATION	Corrected press.	all	all
3	PRESSURE_1_AFTER_SENSOR	Sensor pressure	all	all
4	MEASURED_TEMPERATURE_1	Sensor temp.	all	Not Deltabar M
5	FLOW_AFTER_SUPPRESSION	Flow	Flow only	Not Deltabar M
6	TOTALIZER_1_FLOAT	Totalizer 1	Flow only	Not Deltabar M
7	TOTALIZER_2_FLOAT	Totalizer 2	Flow only	Not Deltabar M
8	MEASURED_LEVEL_AFTER_SIMULATION	Level before Lin.	Level only	all ¹⁾
9	MEASURED_TANK_CONTENT_AFTER_SIMULATION	Tank content	Level only	all ¹⁾
10	CORRECTED_MEASUREMENT_DENSITY	Process density	Level only	all ¹⁾
11	MEASURED_TEMPERATURE_3	Electronics Temp	all	Not Deltabar M
12	HART_INPUT_VALUE	HART Input Value	Not selectable as output	
251	None (no device variable is mapped)		all (but only allowed for Quaternary)	

1) Cerabar M: with Level measurement option



Note!

The device variables can be queried from a HART® master using HART® command 9 or 33.

7 Commissioning



Warning!

- If a pressure smaller than the minimum permitted pressure or greater than the maximum permitted pressure is present at the device, the following messages are output in succession:
 1. "S140 Working range P" or "F140 Working range P" ²⁾
 2. "S841 Sensor range" or "F841 Sensor range" ²⁾
 3. "S971 Adjustment" ²⁾



Note!

The device is configured for the Pressure measuring mode as standard. The measuring range and the unit in which the measured value is transmitted correspond to the specifications on the nameplate.

7.1 Function check

Carry out a post-installation and a post-connection check as per the checklist before commissioning the device.


- "Post-installation check" checklist → Chap. 3.8
- "Post-connection check" checklist → Chap. 4.4

²⁾ depending on the setting in the "Alarm behavior" (050) parameter

7.2 Commissioning without an operating menu



7.2.1 Pressure measuring mode

If no local display is connected, the following functions are possible by means of the keys on the electronic insert:

- Position adjustment (zero point correction)
- Setting lower range value and upper range value
- Device reset →  40



Note!


- Operation must be unlocked. →  49, "Locking/unlocking operation"
- The device is configured for the "Pressure" measuring mode as standard. You can switch measuring modes by means of the "Measuring mode" parameter. →  57, "Measuring mode selection"
- The pressure applied must be within the nominal pressure limits of the sensor. See information on the nameplate.



Warning!


If the measuring mode is changed, the span setting (URV) must be verified and, if necessary, reconfigured.

Carrying out position adjustment. ¹⁾		Setting lower range value.		Setting upper range value.	
Pressure is present at device.		Desired pressure for lower range value is present at device.		Desired pressure for upper range value is present at device.	
↓		↓		↓	
Press the "Zero" and "Span" keys simultaneously for at least 3 s.		Press the "Zero" key for at least 3 s.		Press the "Span" key for at least 3 s.	
↓		↓		↓	
Does the LED on the electronic insert light up briefly?		Does the LED on the electronic insert light up briefly?		Does the LED on the electronic insert light up briefly?	
Yes	No	Yes	No	Yes	No
↓	↓	↓	↓	↓	↓
Applied pressure for position adjustment has been accepted.	Applied pressure for position adjustment has not been accepted. Observe the input limits.	Applied pressure for lower range value has been accepted.	Applied pressure for lower range value has not been accepted. Observe the input limits.	Applied pressure for upper range value has been accepted.	Applied pressure for upper range value has not been accepted. Observe the input limits.

1) Observe warning on commissioning (→  53)



7.2.2 Level measuring mode

The following functions are possible by means of the keys on the electronic insert:

- Position adjustment (zero point correction)
- Setting the lower and upper pressure value and assigning to the lower and upper level value
- Device reset →  40



Note!


- The "Zero" and "Span" keys only have a function with the following setting:
 - "Level selection" = "In pressure", "Calibration mode" = "Wet"
 The keys have no function in other settings.
- The device is configured for the "Pressure" measuring mode as standard. You can switch measuring modes by means of the "Measuring mode" parameter. →  57, "Measuring mode selection"
 - The following parameters are set to the following values at the factory:
 - "Level selection" = "In pressure"
 - "Calibration mode": wet
 - "Output unit": %
 - "Empty calib.": 0.0
 - "Full calib.": 100.0
 - "Set LRV": 0.0 (corresponds to 4 mA value)
 - "Set URV": 100.0 (corresponds to 20 mA value)
- Operation must be unlocked. →  49, "Locking/unlocking operation".
- The pressure applied must be within the nominal pressure limits of the sensor. See information on the nameplate.



Warning!


If the measuring mode is changed, the span setting (URV) must be verified and, if necessary, reconfigured.

Carrying out position adjustment. ¹⁾		Setting lower pressure value.		Setting upper pressure value.	
Pressure is present at device.		Desired pressure for lower pressure value ("empty pressure") is present at device.		Desired pressure for upper pressure value ("full pressure") is present at device.	
↓		↓		↓	
Press the "Zero" and "Span" keys simultaneously for at least 3 s.		Press the "Zero" key for at least 3 s.		Press the "Span" key for at least 3 s.	
↓		↓		↓	
Does the LED on the electronic insert light up briefly?		Does the LED on the electronic insert light up briefly?		Does the LED on the electronic insert light up briefly?	
Yes	No	Yes	No	Yes	No
↓	↓	↓	↓	↓	↓
Applied pressure for position adjustment has been accepted.	Applied pressure for position adjustment has not been accepted. Observe the input limits.	The pressure present was saved as the lower pressure value ("empty pressure") and assigned to the lower level value ("empty calibration").	The pressure present was not saved as the lower pressure value. Observe the input limits.	The pressure present was saved as the upper pressure value ("full pressure") and assigned to the upper level value ("full calibration").	The pressure present was not saved as the upper pressure value. Observe the input limits.

1) Observe warning on commissioning (→  53)



7.2.3 Flow measuring mode (Deltabar M only)

The following functions are possible by means of the keys on the electronic insert:

- Position adjustment (zero point correction)
- Set the maximum pressure value and assign it to the maximum flow value
- Device reset →  40



Note!


- The operation must be unlocked. →  40, "Locking/unlocking operation".
- The device is configured for the "Pressure" measuring mode as standard. You can switch measuring modes by means of the "Measuring mode" parameter. →  57, "Selecting the language, measuring mode and pressure unit".
- DIP switch 4 (SW/√) on the electronics insert can be used to switch to the "Flow" measuring mode. In this case, the "Measuring mode" parameter is adjusted automatically.
- The "Zero"- key does not have any function in the "Flow" measuring mode.
- The pressure applied must be within the nominal pressure limits of the sensor. See information on the nameplate.



Warning!







If the measuring mode is changed, the span setting (URV) must be verified and, if necessary, reconfigured.

Carry out position adjustment. ¹⁾		Setting maximum pressure value.	
Pressure is present at device.		Desired pressure for the maximum pressure value ("Max. Press. Flow") is present at device.	
↓		↓	
Press the "Zero" and "Span" keys simultaneously for at least 3 s.		Press the "Span" key for at least 3 s.	
↓		↓	
Does the LED on the electronic insert light up briefly?		Does the LED on the electronic insert light up briefly?	
Yes	No	Yes	No
↓	↓	↓	↓
Applied pressure for position adjustment has been accepted.	Applied pressure for position adjustment has not been accepted. Observe the input limits.	The pressure present was saved as the maximum pressure value ("Max. Press. Flow") and assigned to the maximum flow value ("Max. Flow").	The pressure present was not saved as the maximum pressure value. Observe the input limits.

1) Observe warning concerning the commissioning (page →  53).

7.3 Commissioning with an operating menu

Commissioning comprises the following steps:


1. Function check (→  53)
2. Selecting the language, measuring mode and pressure unit (→  57)
3. Position adjustment (→  58)
4. Configuring measurement:
 - Pressure measurement (→  73 ff)
 - Level measurement (→  59 ff)
 - Flow measurement (→  59 ff)

7.3.1 Selecting the language, measuring mode and pressure unit

Language selection

Parameter name	Description
Language (000) Selection Menu path: Main menu → Language	Select the menu language for the local display. Options: <ul style="list-style-type: none"> ■ English ■ Another language (as selected when ordering the device) ■ Possibly a third language (language of the manufacturing plant) Factory setting: English

Measuring mode selection


Parameter name	Description
Measuring mode (005) Selection Menu path: Setup → Measuring mode	Select the measuring mode. The operating menu is structured differently depending on the measuring mode selected.  Warning! If the measuring mode is changed, the span setting (URV) must be verified in the "Setup" operating menu and, if necessary, reconfigured. Options: <ul style="list-style-type: none"> ■ Pressure ■ Level ■ Flow Factory setting: Pressure

Pressure unit selection

Parameter name	Description
Press. eng. unit (125) Selection Menu path: Setup → Press. eng. unit	Select the pressure unit. If a new pressure unit is selected, all pressure-specific parameters are converted and displayed with the new unit. Options: <ul style="list-style-type: none"> ■ mbar, bar ■ mmH₂O, mH₂O, inH₂O ■ ftH₂O ■ Pa, kPa, MPa ■ psi ■ mmHg, inHg ■ kgf/cm² Factory setting: mbar or bar depending on the sensor nominal measuring range, or as per order specifications

7.4 Position zero adjustment

The pressure resulting from the orientation of the device can be corrected here.

Parameter name	Description
Corrected press. (172) Display Menu path: Setup → Corrected press.	Displays the measured pressure after sensor trim and position adjustment.  Note! If this value is not equal to "0", it can be corrected to "0" by the position adjustment.
Pos. zero adjust (007) (Deltabar M and gauge pressure sensor) Selection Menu path: Setup → Pos. zero adjust	Position zero adjustment – the pressure difference between zero (set point) and the measured pressure need not be known. Example: – Measured value = 2.2 mbar (0.033 psi) – You correct the measured value via the "Pos. zero adjust" parameter with the "Confirm" option. This means that you assign the value 0.0 to the pressure present. – Measured value (after pos. zero adjust) = 0.0 mbar – The current value is also corrected. Options ■ Confirm ■ Abort Factory setting: Abort
Calib. offset (192) / (008) (absolute pressure sensor) Entry	Position adjustment – the pressure difference between set point and the measured pressure must be known. Example: – Measured value = 982.2 mbar (14.73 psi) – You correct the measured value with the value entered (e.g. 2.2 mbar (0.033 psi)) via the "Calib. offset" parameter. This means that you are assigning the value 980.0 (14.7 psi) to the pressure present. – Measured value (after calib. offset) = 980.0 mbar (14.7 psi) – The current value is also corrected. Factory setting: 0.0

7.5 Level measurement (Cerabar M and Deltapilot M)

7.5.1 Information on level measurement



Note!

You have a choice of two methods for calculating the level: "In pressure" and "In height". The table in the "Overview of level measurement" section that follows provides you with an overview of these two measuring tasks.

- The limit values are not checked, i.e. the values entered must be appropriate for the sensor and the measuring task for the device to be able to measure correctly.
- Customer-specific units are not possible.
- There is no unit conversion.
- The values entered for "Empty calib./Full calib.", "Empty pressure/Full pressure", "Empty height/Full height" and "Set LRV/Set URV" must be at least 1% apart. The value will be rejected, and a warning message displayed, if the values are too close together.

7.5.2 Overview of level measurement

Measuring task	Level selection	Measured variable selection	Description	Measured value display
Calibration is performed by entering two pressure-level value pairs.	"In pressure"	Via the "Output unit" parameter: %, level, volume or mass units.	<ul style="list-style-type: none"> – Calibration with reference pressure (wet calibration), see → 60 – Calibration without reference pressure (dry calibration), see → 62 	The measured value display and the "Level before lin" parameter display the measured value.
Calibration is performed by entering the density and two height-level value pairs.	"In height"		<ul style="list-style-type: none"> – Calibration with reference pressure (wet calibration), see → 64 – Calibration without reference pressure (dry calibration), see → 66 	

7.5.3 "In pressure" level selection Calibration with reference pressure (wet calibration)

Example:

In this example, the level in a tank should be measured in "m". The maximum level is 3 m (9.8 ft). The pressure range is set to 0 to 300 mbar (4.5 psi).

Prerequisite:

- The measured variable is in direct proportion to the pressure.
- The tank can be filled and emptied.



Note!



The values entered for "Empty calib./Full calib." and "Set LRV/Set URV" and the pressures present at the device must be at least 1% apart. The value will be rejected, and a warning message displayed, if the values are too close together. Further limit values are not checked, i.e. the values entered must be appropriate for the sensor and the measuring task for the measuring device to be able to measure correctly.

Description	
1	Perform "position adjustment". → 58
2	Select the "Level" measuring mode via the "Measuring mode (005)" parameter. Menu path: Setup → Measuring mode
3	Select the "In pressure" level mode via the "Level selection" parameter. Menu path: Setup → Extended setup → Level → Level selection.
4	Select a pressure unit via the "Press eng. unit" parameter, here "mbar" for example. Menu path: Setup → Press. eng. unit

P01-Mxxxxxxx-19-xx-xx-xx-003

Fig. 24: Calibration with reference pressure – wet calibration

1 See Table, Step 8.
2 See Table, Step 9.

	Description	
5	Select a level unit via the "Output unit" parameter, here "m" for example. Menu path: Setup → Extended setup → Level → Output unit	 <p style="text-align: right; font-size: small;">P01-xxxxxxx-05-xx-xx-xx-011</p>
6	Select the "Wet" option via the "Calibration mode" parameter. Menu path: Setup → Extended setup → Level → Calibration mode	
7	If calibration is performed with a medium other than the process medium, enter the density of the calibration medium in the "Adjust density" parameter. Menu path: Setup → Extended setup → Level → Adjust density	
8	The pressure for the lower calibration point is present at the device, here 0 mbar for example. Select the "Empty calib." parameter. Menu path: Setup → Extended setup → Level → Empty calib. Enter the level value, here 0 m for example. The pressure value present is assigned to the lower level value by confirming the value.	 <p style="text-align: right; font-size: small;">P01-xxxxxxx-05-xx-xx-xx-014</p>
9	The pressure for the upper calibration point is present at the device, here 300 mbar (4.5 psi) for example. Select the "Full calib." parameter. Menu path: Setup → Extended setup → Level → Full calib. Enter the level value, here 3 m (9.8 ft) for example. The pressure value present is assigned to the upper level value by confirming the value.	
10	Set the level value for the lower current value (4 mA) by means of "Set LRV". Menu path: Setup → Extended setup → Current output → Set LRV	<p><i>Fig. 25: Calibration with reference pressure – wet calibration</i></p> <ol style="list-style-type: none"> 1 See Table, Step 8. 2 See Table, Step 9. 3 See Table, Step 10. 4 See Table, Step 11.
11	Set the level value for the upper current value (20 mA) by means of "Set URV". Menu path: Setup → Extended setup → Current output → Set URV	
12	If calibration was performed with a medium other than the process medium, specify the density of the process medium in the "Process density" parameter. Menu path: Setup → Extended setup → Level → Process density	13 Result: The measuring range is set for 0 to 3 m (9.8 ft).



Note!

1. The measured variables %, level, volume and mass are available for this level mode. See → 116 "Output unit (025)".

7.5.4 "In pressure" level selection Calibration without reference pressure (dry calibration)

Example:

In this example, the volume in a tank should be measured in liters. The maximum volume of 1000 liters (264 US gal) corresponds to a pressure of 450 mbar (6.75 psi). The minimum volume of 0 liters corresponds to a pressure of 50 mbar (0.75 psi) since the device is mounted below the start of the level measuring range.

Prerequisite:

- The measured variable is in direct proportion to the pressure.
- This is a theoretical calibration i.e. the pressure and volume values for the lower and upper calibration point must be known.



Note!

- The values entered for "Empty calib./Full calib.", "Empty pressure/Full pressure" and "Set LRV/Set URV" must be at least 1% apart. The value will be rejected, and a warning message displayed, if the values are too close together. Further limit values are not checked, i.e. the values entered must be appropriate for the sensor and the measuring task for the measuring device to be able to measure correctly.
- Due to the orientation of the device, there may be pressure shifts in the measured value, i.e. when the container is empty or partly filled, the measured value is not zero. For information on how to perform position adjustment, see → 58, "Position zero adjustment".

Description	
1	Select the "Level" measuring mode via the "Measuring mode" parameter. Menu path: Setup → Measuring mode
2	Select the "In pressure" level mode via the "Level selection" parameter. Menu path: Setup → Extended setup → Level → Level selection
3	Select a pressure unit via the "Press eng. unit" parameter, here "mbar" for example. Menu path: Setup → Press. eng. unit
4	Select a level unit via the "Output unit" parameter, here "l" (liters) for example. Menu path: Setup → Extended setup → Level → Output unit

P01-Mxxxxxxx-19-xx-xx-xx-004

Fig. 26: Calibration without reference pressure – dry calibration

1 See Table, Steps 6 and 7.
2 See Table, Steps 8 and 9.

Description	
5	Select the "Dry" option via the "Calibration mode" parameter. Menu path: Setup → Extended setup → Level → Calibration mode
6	Enter the volume value for the lower calibration point via the "Empty calib." parameter, here 0 liters for example. Menu path: Setup → Extended setup → Level → Empty calib.
7	Enter the pressure value for the lower calibration point via the "Empty pressure" parameter, here 50 mbar (0.75 psi) for example. Menu path: Setup → Extended setup → Level → Empty pressure
8	Enter the volume value for the upper calibration point via the "Full calib." parameter, here 1000 liters (264 US gal) for example. Menu path: Setup → Extended setup → Level → Full calib.
9	Enter the pressure value for the upper calibration point via the "Full pressure" parameter, here 450 mbar (6,75 psi) for example. Menu path: Setup → Extended setup → Level → Full pressure
10	"Adjust density" contains the factory setting 1.0 but this value can be changed if required. The value pairs subsequently entered must correspond to this density. Menu path: Setup → Extended setup → Level → Adjust density
11	Set the volume value for the lower current value (4 mA) via the "Set LRV" parameter. Menu path: Setup → Extended setup → Current output → Set LRV
12	Set the volume value for the upper current value (20 mA) via the "Set URV" parameter. Menu path: Setup → Extended setup → Current output → Set URV
13	If calibration was performed with a medium other than the process medium, specify the density of the process medium in the "Process density" parameter. Menu path: Setup → Extended setup → Level → Process density
14	Result: The measuring range is set for 0 to 1000 l (264 US gal).




Fig. 27: Calibration with reference pressure – wet calibration

- 1 See Table, Step 6.
- 2 See Table, Step 7.
- 3 See Table, Step 8.
- 4 See Table, Step 9.
- 5 See Table, Step 11.
- 6 See Table, Step 12.



Note!

- 1. The measured variables %, level, volume and mass are available for this level mode. See → 116 "Output unit (025)".

7.5.5 "In height" level selection Calibration with reference pressure (wet calibration)

Example:

In this example, the volume in a tank should be measured in liters. The maximum volume of 1000 liters (264 US gal) corresponds to a level of 4.5 m (15 ft). The minimum volume of 0 liters corresponds to a level of 0.5 m (1.6 ft) since the device is mounted below the start of the level measuring range.

The density of the medium is 1 g/cm³ (1 SGU).

Prerequisite:

- The measured variable is in direct proportion to the pressure.
- The tank can be filled and emptied.




Note!


The values entered for "Empty calib./Full calib.", "Set LRV/Set URV" and the pressures present at the device must be at least 1% apart. The value will be rejected, and a warning message displayed, if the values are too close together. Other limit values are not checked, i.e. the values entered must be appropriate for the sensor and the measuring task for the device to be able to measure correctly.

	Description	
1	Perform position adjustment. See → 58.	<p style="text-align: right; font-size: small;">P01-Mxxxxxxx-19-xx-xx-xx-007</p> <p><i>Fig. 28: Calibration with reference pressure – wet calibration</i></p> <p>1 See Table, Step 10. 2 See Table, Step 8. 3 See Table, Step 9.</p>
2	Select the "Level" measuring mode via the "Measuring mode" parameter. Menu path: Setup → Measuring mode	
3	Select the "In height" level mode via the "Level selection" parameter. Menu path: Setup → Extended setup → Level → Level selection	
4	Select a pressure unit via the "Press eng. unit" parameter, here mbar for example. Menu path: Setup → Press. eng. unit	
5	Select a level unit via the "Output unit" parameter, here "l" (liters) for example. Menu path: Setup → Extended setup → Level → Output unit	


Description	
6	Select a level unit via the "Height unit" parameter, here "m" for example. Menu path: Setup → Extended setup → Level → Height unit
7	Select the "Wet" option via the "Calibration mode" parameter. Menu path: Setup → Extended setup → Level → Calibration mode
8	The pressure for the lower calibration point is present at the device, here "50 mbar" (0.75 psi) for example. Enter the volume value for the lower calibration point via the "Empty calib." parameter, here 0 liters for example. (The pressure currently measured is displayed as the height, here 0.5 m (1.6 ft) for example.) Menu path: Setup → Extended setup → Level → Empty calib.
9	The pressure for the upper calibration point is present at the device, here "450 mbar" (6.75 psi) for example. Enter the volume value for the upper calibration point via the "Full calib." parameter, here "1000 liters" (264 US gal) for example. The pressure currently measured is displayed as the height, here "4.5 m" (15 ft) for example. Menu path: Setup → Extended setup → Level → Full calib.
8	If calibration is performed with a medium other than the process medium, enter the density of the calibration medium in the "Adjust density" parameter, here "1 g/cm ³ " (1 SGU) for example. Menu path: Setup → Extended setup → Level → Adjust density
11	Set the volume value for the lower current value (4 mA) via the "Set LRV" parameter. Menu path: Setup → Extended setup → Current output → Set LRV
12	Set the volume value for the upper current value (20 mA) via the "Set URV" parameter. Menu path: Setup → Extended setup → Current output → Set URV
13	If calibration was performed with a medium other than the process medium, specify the density of the process medium in the "Process density" parameter. Menu path: Setup → Extended setup → Level → Process density
14	Result: The measuring range is set for 0 to 1000 l (264 US gal).



P01-xxxxxxx-05-xx-xx-xx-029



P01-xxxxxxx-05-xx-xx-xx-001



P01-xxxxxxx-05-xx-xx-xx-031

Fig. 29: Calibration with reference pressure – wet calibration

- 1 See Table, Step 10.
- 2 See Table, Step 8.
- 3 See Table, Step 9.
- 4 See Table, Step 11
- 5 See Table, Step 12.



Note!

- 1. The measured variables %, level, volume and mass are available for this level mode → 116 "Output unit (025)".

7.5.6 "In height" level selection Calibration without reference pressure (dry calibration)

Example:

In this example, the volume in a tank should be measured in liters. The maximum volume of 1000 liters (264 US gal) corresponds to a level of 4.5 m (15 ft). The minimum volume of 0 liters corresponds to a level of 0.5 m (1.6 ft) since the device is mounted below the start of the level measuring range.

Prerequisite:


- The measured variable is in direct proportion to the pressure.
- This is a theoretical calibration i.e. the height and volume values for the lower and upper calibration point must be known.



Note!

- The values for "Empty calib./Full calib.", "Empty height/Full height" and "Set LRV/Set URV" must be at least 1% apart. The value will be rejected, and a warning message displayed, if the values are too close together. Further limit values are not checked, i.e. the values entered must be appropriate for the sensor and the measuring task for the measuring device to be able to measure correctly.
- Due to the orientation of the device, there may be pressure shifts in the measured value, i.e. when the container is empty or partly filled, the measured value is not zero. For information on how to perform position adjustment, see → 58, "Position zero adjustment".









Description	
1	Select the "Level" measuring mode via the "Measuring mode" parameter. Menu path: Setup → Measuring mode
2	Select a pressure unit via the "Press eng. unit" parameter, here "mbar" for example. Menu path: Setup → Press. eng. unit
3	Select the "In height" level mode via the "Level selection" parameter. Menu path: Setup → Extended setup → Level → Level selection
4	Select a level unit via the "Output unit" parameter, here "l" (liters) for example. Menu path: Setup → Extended setup → Level → Output unit
5	Select a level unit via the "Height unit" parameter, here "m" for example. Menu path: Setup → Extended setup → Level → Height unit
6	Select the "Dry" option via the "Calibration mode" parameter. Menu path: Setup → Extended setup → Level → Calibration mode



P01-Mxxxxxxx-19-xx-xx-xx-007

Fig. 30: Calibration without reference pressure – dry calibration

1 See Table, Step 11.
2 See Table, Steps 7 and 8.
3 See Table, Steps 9 and 10.

	Description	
7	Enter the volume value for the lower calibration point via the "Empty calib." parameter, here 0 liters for example. Menu path: Setup → Extended setup → Level → Empty calib.	
8	Enter the height value for the lower calibration point via the "Empty height" parameter, here 0.5 m (1.6 ft) for example. Menu path: Setup → Extended setup → Level → Empty height	
9	Enter the volume value for the upper calibration point via the "Full calib." parameter, here 1000 liters (264 US gal) for example. Menu path: Setup → Extended setup → Level → Full calib.	
10	Enter the height value for the upper calibration point via the "Full height" parameter, here 4.5 m (15 ft) for example. Menu path: Setup → Extended setup → Level → Full height	
11	Enter the density of the medium via the "Adjust density" parameter, here "1 g/cm³" (1 SGU) for example. Menu path: Setup → Extended setup → Level → Adjust density	
12	Set the volume value for the lower current value (4 mA) via the "Set LRV" parameter. Menu path: Setup → Extended setup → Current output → Set LRV	
13	Set the volume value for the upper current value (20 mA) via the "Set URV" parameter. Menu path: Setup → Extended setup → Current output → Set URV	
14	If the process uses a medium other than that on which the calibration was based, the new density has to be specified in the "Process density" parameter. Menu path: Setup → Extended setup → Level → Process density	
15	Result: The measuring range is set for 0 to 1000 l (264 US gal).	<p>Fig. 31: Calibration with reference pressure – wet calibration</p> <ol style="list-style-type: none"> 1 See Table, Step 11. 2 See Table, Step 7. 3 See Table, Step 8. 4 See Table, Step 9. 5 See Table, Step 10. 6 See Table, Step 12. 7 See Table, Step 13.



Note!

The measured variables %, level, volume and mass are available for this level mode → 116 "Output unit (025)".

7.5.7 Calibration with partially-filled tank (wet calibration)

Example:


In this example a wet calibration is shown when it is not possible to empty the vessel and then fill it up to 100%. Here a 20% filling is used as "Empty" and a "25%" filling is used as "Full" calibration point. The calibration is then extended to 0% ... 100% and LRV / URV are adjusted accordingly.

Prerequisite:

The default value in the level mode for calibration mode is "Wet".

However, it can be changed via: Setup → Extended Setup → Level → Calibration mode

Description	
1	Select the "Level" measuring mode via the "Measuring mode (005)" parameter. Menu path: Setup → Measuring mode (005)
2	Set value for "Empty calib." with acting pressure for Level e.g. 20%. Menu path: Setup → Extended Setup → Level → Empty calibration
3	Set value for "Full calib." with acting pressure for Level e.g. 25%. Menu path: Setup → Extended Setup → Level → Full calibration
4	The values for full and empty pressure are measured automatically at adjustment. As the transmitter automatically sets the pressure values that suit to empty and full calibration to min and max pressure that cause the output current, it is necessary to set the right upper range value (URV) and lower range value (LRV).



P01-Mxxxxxxx-19-xx-xx-xx-007

Fig. 32: Calibration with partially-filled tank

1 See Table, Step 2
2 See Table, Step 3



Note!

It is also possible to use different liquids (e.g. water) for the adjustment. In this case you have to enter the different densities at following menu path:

- Setup → Ext. Setup → Level → Adjust density (034) (e.g. 1.0 kg/l for water)
- Setup → Ext. Setup → Level → Process density (035) (e.g. 0.8 kg/l for oil)

7.6 Linearization

7.6.1 Manual entry of the linearization table

Example:

In this example, the volume in a tank with a conical outlet should be measured in m³.

Prerequisite:

- This is a theoretical calibration, i.e. the points for the linearization table are known.
- The "Level" operating mode has been selected.
- A level calibration has been performed.



Warning!


If the measuring mode is changed, the span setting (URV) must be verified in the "Setup" operating menu and, if necessary, reconfigured.




Note!

For a description of the parameters mentioned, → Chap. 11.2 "Description of parameters".

Description	
1	<p>Select the "Manual entry" option via the "Lin. mode" parameter.</p> <p>Menu path: Setup → Extended setup → Linearization → Lin. mode</p>
2	<p>Select the volume/mass unit via the "Unit after lin." parameter, e.g. m³.</p> <p>Menu path: Setup → Extended setup → Linearization → Unit after lin.</p>
3	<p>Enter the number of the point in the table via the "Line-numb." parameter.</p> <p>Menu path: Setup → Extended setup → Linearization → Line-numb</p>
	<p>The level (e.g. 0 m) is entered via the "X-value" parameter. Confirm your entry.</p> <p>Menu path: Setup → Extended setup → Linearization → X-value</p>
	<p>Using the "Y-value" parameter, enter the associated volume value, here 0 m³ for example, and confirm the value.</p> <p>Menu path: Setup → Extended setup → Linearization → Y-value</p>



P01-Mxxxxxxx-19-xx-xx-xx-006



P01-Mxxxxxxx-05-xx-xx-xx-015


	Description	
4	To enter another point in the table, select the "Next point" option via the "Edit table" parameter. Enter the next point as explained in Step 3. Menu path: Setup → Extended setup → Linearization → Edit table	 <p style="text-align: right; font-size: small;">P01-Mxxxxxxx-05-xx-xx-xx-016</p>
5	Once all the points have been entered in the table, select the "Activate table" option via the "Lin. mode" parameter. Menu path: Setup → Extended setup → Linearization → Lin. mode	
6	Result: The measured value after linearization is displayed.	

Fig. 33: Manual entry of the linearization table

**Note!**

1. Error message F510 "Linearization" and alarm current as long as the table is being entered and until the table is activated.
2. The 0% value (= 4 mA) is defined by the smallest point in the table.
The 100% value (= 20 mA) is defined by the biggest point in the table.
3. You can change the allocation of the volume or mass values to the current values using the "Set LRV" and "Set URV" parameters.

7.6.2 Manual entry of the linearization table via the operating tool

With an operating tool based on FDT technology (e.g. FieldCare), it is possible to enter linearization via a module that has been specially designed for this. In doing so, you gain an overview of the selected linearization even while making the entry. Additionally, it is possible to call up pre-programmed tank shapes.

**Note!**

The linearization table can also be entered manually point for point in the menu of the operating tool (see → Chap. 7.6.1 "Manual entry of the linearization table").

7.6.3 Semi-automatic entry of the linearization table

Example:

In this example, the volume in a tank with a conical outlet should be measured in m³.

Prerequisite:

- The tank can be filled or emptied. The linearization characteristic must rise continuously.
- The "Level" operating mode has been selected.



Warning!

If the measuring mode is changed, the span setting (URV) must be verified in the "Setup" operating menu and, if necessary, reconfigured.




Note!

For a description of the parameters mentioned → Chap. 11.2 "Description of parameters".


Description	
1	<p>Select the "Semi-auto. entry" option via the "Lin. mode" parameter.</p> <p>Menu path: Setup → Extended setup → Linearization → Lin. mode</p>
2	<p>Select the volume unit/mass unit via the "Unit after lin." parameter, e.g. m³.</p> <p>Menu path: Setup → Extended setup → Linearization → Unit after lin.</p>
3	<p>Fill the tank to the height of the 1st point.</p>

P01-Mxxxxxxx-19-xx-xx-xx-006

Description	
4	<p>Enter the number of the point in the table via the "Line-numb." parameter.</p> <p>Menu path: Setup → Extended setup → Linearization → Line-numb</p> <p>The actual level is displayed via the "X-value" parameter.</p> <p>Menu path: Setup → Extended setup → Linearization → X-value</p> <p>Using the "Y-value" parameter, enter the associated volume value, here 0 m³ for example, and confirm the value.</p> <p>Menu path: Setup → Extended setup → Linearization → Y-value</p>
5	<p>To enter another point in the table, select the "Next point" option via the "Edit table" parameter.</p> <p>Enter the next point as explained in Step 4.</p> <p>Menu path: Setup → Extended setup → Linearization → Edit table</p>
6	<p>Once all the points have been entered in the table, select the "Activate table" option via the "Lin. mode" parameter.</p> <p>Menu path: Setup → Extended setup → Linearization → Lin. mode</p>
7	<p>Result:</p> <p>The measured value after linearization is displayed.</p>



P01-MXXXXXXXX-05-xx-xx-xx-015



P01-MXXXXXXXX-05-xx-xx-xx-016

Fig. 34: Semi-automatic entry of the linearization table



Note!

1. Error message F510 "Linearization" and alarm current as long as the table is being entered and until the table is activated.
2. The 0% value (= 4 mA) is defined by the smallest point in the table.
The 100% value (= 20 mA) is defined by the biggest point in the table.
3. You can change the allocation of the volume or mass values to the current values using the "Set LRV" and "Set URV" parameters.

7.7 Pressure measurement

7.7.1 Calibration without reference pressure (dry calibration)

Example:

In this example, a device with a 400 mbar (6 psi) sensor is configured for the 0 to +300 mbar (4.5 psi) measuring range, i.e. 0 mbar is assigned to the 4 mA value and 300 mbar (4.5 psi) to the 20 mA value.

Prerequisite:


This is a theoretical calibration, i.e. the pressure values for the lower and upper range are known.



Note!

Due to the orientation of the device, there may be pressure shifts in the measured value, i.e. the measured value is not zero in a pressureless condition. For information on how to perform position adjustment, see → 58.

Description	
1	Select the "Pressure" measuring mode via the "Measuring mode" parameter. Menu path: Setup → Measuring mode
2	Select a pressure unit via the "Press eng. unit" parameter, here "mbar" for example. Menu path: Setup → Press. eng. unit
3	Select the "Set LRV" parameter. Menu path: Setup → Set LRV Enter the value for the "Set LRV" parameter (here 0 mbar) and confirm. This pressure value is assigned to the lower current value (4 mA).
4	Select the "Set URV" parameter. Menu path: Setup → Set URV Enter the value for the "Set URV" parameter (here 300 mbar (4.5 psi)) and confirm. This pressure value is assigned to the upper current value (20 mA).
5	Result: The measuring range is configured for 0 to +300 mbar (4,5 psi).



P01-xxxxxxx-05-xx-xx-xx-010

Fig. 35: Calibration without reference pressure

- 1 See Table, Step 3.
- 2 See Table, Step 4.

7.7.2 Calibration with reference pressure (wet calibration)

Example:

In this example, a device with a 400 mbar (6 psi) sensor is configured for the 0 to +300 mbar (4.5 psi) measuring range, i.e. 0 mbar is assigned to the 4 mA value and 300 mbar (4.5 psi) to the 20 mA value.

Prerequisite:


The pressure values 0 mbar and 300 mbar (4.5 psi) can be specified. The device is already mounted, for example.



Note!

For a description of the parameters mentioned, see Section 11.2 "Description of parameters".

	Description
1	Perform position adjustment → 58.
2	Select the "Pressure" measuring mode via the "Measuring mode" parameter. Menu path: Setup → Measuring mode
3	Select a pressure unit via the "Press eng. unit" parameter, here "mbar" for example. Menu path: Setup → Press. eng. unit
4	The pressure for the lower-range value (4 mA value) is present at the device, here 0 mbar for example. Select the "Get LRV" parameter. Menu path: Setup → Extended setup → Current output → Get LRV. Confirm the value present by selecting "Confirm". The pressure value present is assigned to the lower current value (4 mA).
5	The pressure for the upper-range value (20 mA value) is present at the device, here 300 mbar (4.5 psi) for example. Select the "Get URV" parameter. Menu path: Setup → Extended setup → Current output → Get URV. Confirm the value present by selecting "Confirm". The pressure value present is assigned to the upper current value (20 mA).
6	Result: The measuring range is configured for 0 to +300 mbar (4.5 psi).



P01-xxxxxxx-05-xx-xx-xx-010

Fig. 36: Calibration with reference pressure

- 1 See Table, Step 4.
2 See Table, Step 5.

7.8 Electrical differential pressure measurement with gauge pressure sensors (Cerabar M or Deltapilot M)

Example:

In the example given, two Cerabar M or Deltapilot M devices (each with a gauge pressure sensor) are interconnected. The pressure difference can thus be measured using two independent Cerabar M or Deltapilot M devices.



Note!

For a description of the parameters mentioned → Chap. 11.2 "Description of parameters".






Fig. 37: 1 Shut-off valves

2 e.g. filter

Description	
Adjustment of the Cerabar M/Deltapilot M on the high pressure side	
1	Select the "Pressure" measuring mode via the "Measuring mode" parameter. ⚠ Warning! If the measuring mode is changed, the span setting (URV) must be verified in the "Setup" operating menu and, if necessary, reconfigured. Menu path: Setup → Measuring mode
2	Select a pressure unit via the "Press eng. unit" parameter, here "mbar" for example. Menu path: Setup → Press. eng. unit
3	The Cerabar M/Deltapilot M is unpressurized, perform position adjustment, see → 58.
4	Switch on burst mode via the "Burst mode" parameter Menu path: Expert → Communication → HART Config.
5	Set the output current to "Fixed" 4.0 mA via the "Current mode" parameter. Menu path: Expert → Communication → HART Config
6	Configure an address ≠ 0 via the "Bus address" parameter, e.g. bus address = 1 (HART 5.0 master: Range 0 to 15, where address = 0 calls up the "Signaling" setting; HART 6.0 master: range 0 to 63) Menu path: Expert → Communication → HART Config.

	Description Adjustment of the Cerabar M/Deltapilot M on the low pressure side (the differential is generated in this device)
1	Select the "Pressure" measuring mode via the "Measuring mode" parameter.  Warning! If the measuring mode is changed, the span setting (URV) must be verified in the "Setup" operating menu and, if necessary, reconfigured. Menu path: Setup → Measuring mode
2	Select a pressure unit via the "Press eng. unit" parameter, here "mbar" for example. Menu path: Setup → Press. eng. unit
3	The Cerabar M/Deltapilot M is unpressurized, perform position adjustment, see →  58.
4	Set the output current to "Fixed" 4.0mA via the "Current mode" parameter. Menu path: Expert → Communication → HART Config.
5	Configure an address $\neq 0$ via the "Bus address" parameter, e.g. bus address = 2 (HART 5.0 master: Range 0 to 15, where address = 0 calls up the "Signaling" setting; HART 6.0 master: range 0 to 63) Menu path: Expert → Communication → HART Config.
6	Activate the reading of a value sent externally in burst mode via the "Electr. Delta P" parameter. Menu path: Expert → Application
7	Result: The measured value output by the Cerabar M/Deltapilot M on the low pressure side equals the differential: high pressure - low pressure, and can be read out by means of a HART request of the address of the Cerabar M/Deltapilot M on the low pressure side.

**Note!**

It is not permitted to reverse the assignment of the measuring points to the direction of communication. The measured value of the transmitting device (via burst) must always be greater than the measured value of the receiving device (via the "Electr. Delta P" function).

Adjustments that result in an offset of the pressure values (e.g. position adjustment, trim) must always be performed in accordance with the individual sensor and its orientation, irrespective of the "Electr. Delta P" application. Other settings result in non-permitted use of the "Electr. Delta P" function and can lead to incorrect measured values.

7.9 Differential pressure measurement (Deltabar M)

7.9.1 Preparatory steps



Note!

- Before calibrating the device, the impulse piping must be cleaned and filled with fluid. → See the following table.



	Valves	Meaning	Preferred installation	
1	Close 3.			
2	Fill measuring system with fluid.			
	Open A, B, 2, 4.	Fluid flows in.		
3	Clean impulse piping if necessary: ¹⁾ – by blowing out with compressed air in the case of gases – by rinsing out in the case of liquids.			
	Close 2 and 4.	Block off device.		
	Open 1 and 5. ¹⁾	Blow out/rinse out impulse piping.		
	Close 1 and 5. ¹⁾	Close valves after cleaning.		
4	Vent device.			
	Open 2 and 4.	Introduce fluid.		
	Close 4.	Close low-pressure side.		
	Open 3.	Balance positive and low-pressure side.		
	Open 6 and 7 briefly, then close them again.	Fill device completely with fluid and remove air.		
5	Set measuring point in operation.			
	Close 3.	Shut off high-pressure side from low-pressure side.		
	Open 4.	Connect low-pressure side.		
	Now – 1 ¹⁾ , 3, 5 ¹⁾ , 6 and 7 are closed. – 2 and 4 are open. – A and B open (if present).			
6	Carry out calibration if necessary. → See also page 78, section 6.6.2.			

Above: preferred installation for gases
Below: preferred installation for liquids

- I Deltabar M
- II Three-valve manifold
- III Separator
- 1, 5 Drain valves
- 2, 4 Inlet valves
- 3 Equalising valve
- 6, 7 Vent valves on Deltabar M
- A, B Shut-off valve

1) for arrangement with 5 valves

7.9.2 Setup menu for Pressure measuring mode

Parameter name	Description	see page
Measuring mode (005) Selection	Select the "Pressure" measuring mode.	112
Switch P1/P2 (163) Display	Indicates whether the "SW/P2High" DIP switch (DIP switch 5) is switched on.	114
High pressure side (006) (183) Selection/Display	Determines, which pressure input corresponds to the high-pressure side.  Note! This setting is only valid if the "SW/P2High" DIP switch is in the OFF position (see the "Pressure side switch" (163) parameter). Otherwise P2 corresponds to the high-pressure side in any case.	114
Press. eng. unit (125) Selection	Select the pressure unit. If a new pressure unit is selected, all pressure-specific parameters are converted and displayed with the new unit.	113
Corrected press. (172) Display	Displays the measured pressure after sensor trim and position adjustment.	115
Pos. zero adjust (007) Selection	Position adjustment – the pressure difference between zero (set point) and the measured pressure need not be known. Example: – Measured value = 2.2 mbar (0.033 psi) – You correct the measured value via the "Pos. zero adjust" parameter with the "Confirm" option. This means that you assign the value 0.0 to the pressure present. – Measured value (after pos. zero adjust) = 0.0 mbar – The current value is also corrected.	113
Set LRV (056) Entry	Set the pressure value for the lower current value (4 mA).	123
Set URV (057) Entry	Set the pressure value for the upper current value (20 mA).	123
Damping switch (164) Display	Displays the status of DIP switch 2 ("damping τ "), which is used to switch the damping of the output signal on and off.	113
Damping value (017) Entry/Display	Enter damping time (time constant τ). The damping affects the speed at which the measured value reacts to changes in pressure.  Note! The damping is only active if DIP switch 2 ("damping τ ") is in the ON position.	113
Pressure after damping (111) Display	Displays the measured pressure after sensor trim, position adjustment and damping.	115

7.10 Flow measurement (Deltabar M)

7.10.1 Information on flow measurement

In the "Flow" measuring mode, the device determines a volume or mass flow value from the differential pressure measured. The differential pressure is generated by means of primary elements such as pitot tubes or orifice plates and depends on the volume or mass flow. Four flow types are available: volume flow, norm volume flow (European norm conditions), standard volume flow (American standard conditions), mass flow and flow in %.

In addition, the Deltabar M software is equipped with two totalizers as standard. The totalizers add up the volume or the mass flow. The counting function and the unit can be set separately for both totalizers. The first totalizer (totalizer 1) can be reset to zero at any time while the second (totalizer 2) totalises the flow from commissioning onwards and cannot be reset.



Note!

The totalizers are not available for the "Flow in %" flow type.

7.10.2 Preparatory steps





Note!

- Before calibrating the Deltabar M, the impulse piping must be cleaned and filled with fluid. → See the following table.

	Valves	Meaning	Preferred installation	
1	Close 3.			
2	Fill measuring system with fluid. Open A, B, 2, 4.	Fluid flows in.		
3	Clean impulse piping if necessary ¹⁾ : – by blowing out with compressed air in the case of gases – by rinsing out in the case of liquids. Close 2 and 4.	Block off device.		
	Open 1 and 5. ¹	Blow out/rinse out impulse piping.		
	Close 1 and 5. ¹	Close valves after cleaning.		
4	Vent device. Open 2 and 4.	Introduce fluid.		
	Close 4.	Close low-pressure side.		
	Open 3.	Balance positive and low-pressure side.		
	Open 6 and 7 briefly, then close them again.	Fill device completely with fluid and remove air.		
5	Carry out position zero adjustment (→ 58) if the following conditions are met. If the conditions are not met, then do not carry out the pos. zero adjustment until after step 6. Conditions: – The process cannot be blocked off. – The tapping points (A and B) are at the same geodetic height.			
6	Set measuring point in operation. Close 3. Open 4. Now – 1 ¹ , 3, 5 ¹ , 6 and 7 are closed. – 2 and 4 are open. – A and B open (if present).	Shut off high-pressure side from low-pressure side. Connect low-pressure side.	<p><i>Above: preferred installation for gases</i> <i>Below: preferred installation for liquids</i></p> <p><i>I Deltabar M</i> <i>II Three-valve manifold</i> <i>III Separator</i> <i>1, 5 Drain valves</i> <i>2, 4 Inlet valves</i> <i>3 Equalising valve</i> <i>6, 7 Vent valves on Deltabar M</i> <i>A, B Shut-off valves</i></p>	
7	Carry out position zero adjustment (→ 58) if the flow can be blocked off. In this case, step 5 is not applicable.			
8	Carry out calibration. → See page 81, → Chap. 7.10.3.			

1) for arrangement with 5 valves

7.10.3 Setup menu for the "Flow" measuring mode

Parameter name	Description	see page
Lin./SQRT switch (133) Display	Displays the status of DIP switch 4 on the electronic insert, which is used to define the output characteristics of the current output.	122
Measuring mode (005) Selection	Select the "Flow" measuring mode.	112
Pressure side switch (163) Display	Indicates whether the "SW/P2High" DIP switch (DIP switch 5) is switched on.	114
High pressure side (006) (183) Selection	Determines, which pressure input corresponds to the high-pressure side.  Note! This setting is only valid if the "SW/P2High" DIP switch is in the OFF position (see the "Pressure side switch" (163) parameter). Otherwise P2 corresponds to the high-pressure side in any case.	114
Press. eng. unit (125) Selection	Select the pressure unit. If a new pressure unit is selected, all pressure-specific parameters are converted and displayed with the new unit.	113
Corrected press. (172) Display	Displays the measured pressure after sensor trim and position adjustment.	115
Pos. zero adjust (007) Selection	Position adjustment – the pressure difference between zero (set point) and the measured pressure need not be known. Example: – Measured value = 2.2 mbar (0.033 psi) – You correct the measured value via the "Pos. zero adjust" parameter with the "Confirm" option. This means that you assign the value 0.0 to the pressure present. – Measured value (after pos. zero adjust) = 0.0 mbar – The current value is also corrected.	113
Max. flow (009) Entry	Enter maximum flow of primary element. See also layout sheet of primary element. The maximum flow is assigned to the maximum pressure which you enter via the "Max. pressure flow" (010) parameter.	120
Max. pressure flow (010) Entry	Enter maximum pressure of primary element. → See layout sheet of primary element. This pressure is assigned to the flow defined in the "Max. flow" (009) parameter.	121
Damping switch (164) Display	Displays the status of DIP switch 2 "damping τ ", which is used to switch the damping of the output signal on and off.	113
Damping value (017) Entry/Display	Enter damping time (time constant τ). The damping affects the speed at which the measured value reacts to changes in pressure.  Note! The damping is only active if DIP switch 2 "damping τ " is in the ON position.	113
Flow (018) Display	Displays the present flow value.	121
Pressure after damping (111) Display	Displays the measured pressure after sensor trim, position adjustment and damping.	115

7.11 Level measurement (Deltabar M)

7.11.1 Preparatory steps

Open container



Note!

- Before calibrating the device, the impulse piping must be cleaned and filled with fluid. → See the following table.

	Valves	Meaning	Installation
1	Fill container to a level above the lower tap.		<p style="text-align: right; font-size: small;">P01-PMD55xxx-11-xx-xx-xx-008</p>
2	Fill measuring system with fluid.		
	Open A.	Open shut-off valve.	
3	Vent device.		
	Open 6 briefly, then close it again.	Fill device completely with fluid and remove air.	
4	Set measuring point in operation.		
	Now		
	– B and 6 are closed.		
	– A is open.		
5	Carry out calibration according to one of the following methods:		
	<ul style="list-style-type: none"> "in pressure" - with reference pressure (→ 86) "in pressure" - without reference pressure (→ 60) "in height" - with reference pressure (→ 92) "in height" - without reference pressure (→ 92) 		<p><i>Open container</i></p> <p><i>I Deltabar M</i></p> <p><i>II Separator</i></p> <p><i>6 Vent valves on Deltabar M</i></p> <p><i>A Shut-off valve</i></p> <p><i>B Drain valve</i></p>

Closed container



Note!

- Before calibrating the device, the impulse piping must be cleaned and filled with fluid. → See the following table.

	Valves	Meaning	Installation
1	Fill container to a level above the lower tap.		
2	Fill measuring system with fluid.		
	Close 3.	Shut off high-pressure side from low-pressure side.	
	Open A and B.	Open shut-off valves.	
3	Vent high-pressure side (empty low-pressure side if necessary).		
	Open 2 and 4.	Introduce fluid on high-pressure side.	
	Open 6 and 7 briefly, then close them again.	Fill high-pressure side completely with fluid and remove air.	
4	Set measuring point in operation.		<p><i>Closed container</i></p> <p><i>I Deltabar M</i> <i>II Three-valve manifold</i> <i>III Separator</i> <i>1, 2 Drain valves</i> <i>2, 4 Inlet valves</i> <i>3 Equalizing valve</i> <i>6, 7 Vent valve on Deltabar M</i> <i>A, B Shut-off valve</i></p>
	Now - 3, 6 and 7 are closed. - 2, 4, A and B are open.		
5	Carry out calibration according to one of the following methods:		
	<ul style="list-style-type: none"> ■ "in pressure" - with reference pressure (→ 86) ■ "in pressure" - without reference pressure (→ 62) ■ "in height" - with reference pressure (→ 92) ■ "in height" - without reference pressure (→ 92) 		

Closed container with superimposed steam



Note!

- Before calibrating the device, the impulse piping must be cleaned and filled with fluid. → See the following table.

	Valves	Meaning	Installation
1	Fill container to a level above the lower tap.		<p style="text-align: right; font-size: small;">P01-PMD55xxx-11-xx-xx-xx-010</p> <p style="text-align: center;"><i>Closed container with superimposed steam</i></p> <p> <i>I</i> Deltabar M <i>II</i> Three-valve manifold <i>III</i> Separator <i>1, 5</i> Drain valves <i>2, 4</i> Inlet valves <i>3</i> Equalising valve <i>6, 7</i> Vent valves on Deltabar M <i>A, B</i> Shut-off valves </p>
2	Fill measuring system with fluid.		
	Open A and B.	Open shut-off valves.	
	Fill the negative impulse piping to the level of the condensate trap.		
3	Vent device.		
	Open 2 and 4.	Introduce fluid.	
	Close 4.	Close low-pressure side.	
	Open 3.	Balance positive and low-pressure side.	
	Open 6 and 7 briefly, then close them again.	Fill device completely with fluid and remove air.	
4	Set measuring point in operation.		
	Close 3.	Shut off high-pressure side from low-pressure side.	
	Open 4.	Connect low-pressure side.	
	Now – 3, 6 and 7 are closed. – 2, 4, A and B are open.		
5	Carry out calibration according to one of the following methods:		
	<ul style="list-style-type: none"> ■ "in pressure" - with reference pressure (→ 86) ■ "in pressure" - without reference pressure (→ 62) ■ "in height" - with reference pressure (→ 92) ■ "in height" - without reference pressure (→ 92) 		

7.11.2 Information on level measurement



Note!

You have a choice of two methods for calculating the level: "In pressure" and "In height". The table in the "Overview of level measurement" section that follows provides you with an overview of these two measuring tasks.

- The limit values are not checked, i.e. the values entered must be appropriate for the sensor and the measuring task for the device to be able to measure correctly.
- Customer-specific units are not possible.
- The values entered for "Empty calib./Full calib.", "Empty pressure/Full pressure", "Empty height/ Full height" and "Set LRV/Set URV" must be at least 1% apart. The value will be rejected, and a message output, if the values are too close together.

7.11.3 Overview of level measurement

Measuring task	Level selection	Measured variable options	Description	Measured value display
Calibration takes place by entering two pressure/level value pairs.	"In pressure"	Via the "Output unit" parameter: %, level, volume or mass units.	<ul style="list-style-type: none"> ■ Calibration with reference pressure (wet calibration), → 86 ■ Calibration without reference pressure (dry calibration) → 62 	The measured value display and the "Level before lin" parameter display the measured value.
Calibration takes place by entering the density and two height/level value pairs.	"In height"		<ul style="list-style-type: none"> ■ Calibration with reference pressure (wet calibration), → 92 ■ Calibration without reference pressure (dry calibration) → 90 	

7.11.4 Level selection "in pressure" Calibration with reference pressure (wet calibration)

Example:

In this example, the level in a tank should be measured in "m". The maximum level is 3 m (9.8 ft). The pressure range is set to 0 to 300 mbar (4.5 psi).

Prerequisite:

- The measured variable is in direct proportion to the pressure.
- The tank can be filled and emptied.




Note!

The values entered for "Empty calib./Full calib." and "Set LRV/Set URV" must be at least 1% apart. The value will be rejected, and a message output, if the values are too close together. Other limit values are not checked, i.e. the values entered must be appropriate for the sensor and the measuring task for the device to be able to measure correctly.

	Description
1	Perform "position zero adjustment" → 58.
2	Select the "Level" measuring mode via the "Measuring mode (005)" parameter (→ 57). Menu path: Setup → Measuring mode
3	Select a pressure unit via the "Press eng. unit" parameter (→ 81), here "mbar" for example. Menu path: Setup → Press. eng. unit
4	Select the "In pressure" level mode via the "Level selection" parameter (→ 116). Menu path: Setup → Extended setup → Level → Level selection
5	Select a level unit via the "Output unit" parameter (→ 116), here "m" for example. Menu path: Setup → Extended setup → Level → Output unit
6	Select the "Wet" option via the "Calibration mode" parameter (→ 116). Menu path: Setup → Extended setup → Level → Calibration mode

Description	
7	<p>a. The pressure for the lower calibration point is present at the device, here "0 mbar" for example.</p> <p>b. Select the "Empty calib." parameter (→ 117).</p> <p>c. Enter the level value, here "0 m" for example. Confirming the value means you assign the pressure value present to the lower level value.</p> <p>Menu path: Setup → Extended setup → Level → Empty calib.</p>
8	<p>a. The pressure for the upper calibration point is present at the device, here "300 mbar" (4.5 psi) for example.</p> <p>b. Select the "Full calib." parameter (→ 117).</p> <p>c. Enter the level value, here "3 m" for example. Confirming the value means you assign the pressure value present to the upper level value.</p> <p>Menu path: Setup → Extended setup → Level → Full calib.</p>
9	<p>Result: The measuring range is set for 0 to 3 m (9.8 ft). 0 m corresponds to an output current of 4 mA. 3 m (9.8 ft) corresponds to an output current of 20 mA.</p>



P01-xxxxxxx-05-xx-xx-xx-011

Calibration with reference pressure (wet calibration)

- 1 See Table, Step 7
- 2 See Table, Step 8

7.11.5 Level selection "in pressure" Calibration without reference pressure (dry calibration)

Example:

In this example, the volume in a tank should be measured in liters. The maximum volume of 1000 liters (264 US gal) corresponds to a pressure of 400 mbar (6 psi). The minimum volume of 0 liters corresponds to a pressure of 0 mbar.

Prerequisite:

- The measured variable is in direct proportion to the pressure.
- This is a theoretical calibration i.e. the pressure and volume values for the lower and upper calibration point must be known.




Note!

The values entered for "Empty calib./Full calib." and "Set LRV/Set URV" must be at least 1% apart. The value will be rejected, and a message output, if the values are too close together. Other limit values are not checked, i.e. the values entered must be appropriate for the sensor and the measuring task for the device to be able to measure correctly.

	Description
1	Perform "position zero adjustment" → 58.
2	Select the "Level" measuring mode via the "Measuring mode (005)" parameter (→ 57). Menu path: Setup → Measuring mode
3	Select a pressure unit via the "Press eng. unit" parameter (→ 57), here "mbar" for example. Menu path: Setup → Press. eng. unit
4	Select the "In pressure" level mode via the "Level selection" parameter (→ 116). Menu path: Setup → Extended setup → Level → Level selection
5	Select a level unit via the "Output unit" parameter (→ 116), here "l" for example. Menu path: Setup → Extended setup → Level → Output unit
6	Select the "Dry" option via the "Calibration mode" parameter (→ 116). Menu path: Setup → Extended setup → Level → Calibration mode

Description	
7	<p>Enter the volume value for the lower calibration point via the "Empty calib." parameter (→ 117), here "0 liter" for example.</p> <p>Menu path: Setup → Extended setup → Level → Empty calib.</p>
8	<p>Enter the pressure value for the lower calibration point via the "Empty pressure" parameter (→ 117), here "0 mbar" for example.</p> <p>Menu path: Setup → Extended setup → Level → Empty pressure</p>
9	<p>Enter the volume value for the upper calibration point via the "Full calib." parameter (→ 117), here "1000 liter" (264 US gal) for example.</p> <p>Menu path: Setup → Extended setup → Level → Full calib.</p>
10	<p>Enter the pressure value for the upper calibration point via the "Full pressure" parameter (→ 117), here "400 mbar" (6 psi) for example.</p> <p>Menu path: Setup → Extended setup → Level → Full pressure</p>
11	<p>Result: The measuring range is set for 0 to 1000 l (264 US gal). 0 l corresponds to an output current of 4 mA. 1000 l (264 US gal) corresponds to an output current of 20 mA.</p>



P01-FMX21xxx-05-xx-xx-xx-026

Calibration without reference pressure (dry calibration)

- 1 See Table, Step 7.
- 2 See Table, Step 8.
- 3 See Table, Step 9.
- 4 See Table, Step 10.

7.11.6 Level selection "in height" Calibration without reference pressure (dry calibration)

Example:

In this example, the volume in a tank should be measured in liters. The maximum volume of 1000 liters (264 US gal) corresponds to a level of 4 m (13 ft). The minimum volume of 0 liters corresponds to a level of 0 m. The density of the medium is 1 g/cm³ (1 SGU).

Prerequisite:



- The measured variable is in direct proportion to the pressure.
- This is a theoretical calibration i.e. the pressure and volume values for the lower and upper calibration point must be known.



Note!

The values entered for "Empty calib./Full calib." and "Set LRV/Set URV" must be at least 1% apart. The value will be rejected, and a message output, if the values are too close together. Other limit values are not checked, i.e. the values entered must be appropriate for the sensor and the measuring task for the device to be able to measure correctly.

	Description
1	Perform "position zero adjustment" → 58.
2	Select the "Level" measuring mode via the "Measuring mode (005)" parameter (→ 57). Menu path: Setup → Measuring mode
3	Select a pressure unit via the "Press eng. unit" parameter (→ 57), here "mbar" for example. Menu path: Setup → Press. eng. unit
4	Select the "In height" level mode via the "Level selection" parameter (→ 116). Menu path: Setup → Extended setup → Level → Level selection
5	Select a level unit via the "Output unit" parameter (→ 116), here "l" for example. Menu path: Setup → Extended setup → Level → Output unit
6	Select a level unit via the "Height unit" parameter (→ 116), here "m" for example. Menu path: Setup → Extended setup → Level → Height unit
7	Select the "Wet" option via the "Calibration mode" parameter (→ 116). Menu path: Setup → Extended setup → Level → Calibration mode

	Description	
8	Enter the height value for the lower calibration point via the "Empty height" parameter (→ 117), here "0 m" for example. Menu path: Setup → Extended setup → Level → Empty height	 <p style="text-align: right;"><small>P01-FM021xxx-05-xx-xx-xx-029</small></p>
9	Enter the volume value for the upper calibration point via the "Full calib." parameter (→ 117), here "1000 liter" (264 US gal) for example. Menu path: Setup → Extended setup → Level → Full calib.	 <p style="text-align: right;"><small>P01-FM021xxx-05-xx-xx-xx-032</small></p>
10	Enter the volume value for the lower calibration point via the "Empty calib." parameter (→ 117), here "0 liter" for example. Menu path: Setup → Extended setup → Level → Empty calib.	<p><i>Calibration without reference pressure (dry calibration)</i></p> <ol style="list-style-type: none"> 1 See table, Step 12. 2 See table, Step 8. 3 See table, Step 9. 4 See table, Step 10. 5 See table, Step 11.
11	Enter the height value for the upper calibration point via the "Full height" parameter (→ 117), here "4 m" (13 ft) for example. Menu path: Setup → Extended setup → Level → Full height	
12	Enter the density of the medium, using the "Adjust density" parameter (→ 117), here 1 g/cm ³ (1 SGU) for example. Menu path: Setup → Extended setup → Level → Adjust density	
13	Result: The measuring range is set for 0 to 1000 l (264 US gal). 0 l corresponds to an output current of 4 mA. 1000 l (264 US gal) corresponds to an output current of 20 mA.	

7.11.7 Level selection "in height" Calibration with reference pressure (wet calibration)

Example:

In this example, the volume in a tank should be measured in liters. The maximum volume of 1000 liters (264 US gal) corresponds to a level of 4 m (13 ft). The minimum volume of 0 liters corresponds to a level of 0 m. The density of the medium is 1 g/cm³ (1 SGU).

Prerequisite:

- The measured variable is in direct proportion to the pressure.
- The tank can be filled and emptied.



Note!

The values entered for "Empty calib./Full calib." and "Set LRV/Set URV" must be at least 1% apart. The value will be rejected, and a message output, if the values are too close together. Other limit values are not checked, i.e. the values entered must be appropriate for the sensor and the measuring task for the device to be able to measure correctly.

	Description
1	Perform "position zero adjustment" → 58.
2	Select the "Level" measuring mode via the "Measuring mode (005)" parameter (→ 57). Menu path: Setup → Measuring mode
3	Select a pressure unit via the "Press eng. unit" parameter (→ 57), here "mbar" for example. Menu path: Setup → Press. eng. unit
4	Select the "In height" level mode via the "Level selection" parameter (→ 116). Menu path: Setup → Extended setup → Level → Level selection
5	Select a level unit via the "Output unit" parameter (→ 116), here "l" for example. Menu path: Setup → Extended setup → Level → Output unit
6	Select a level unit via the "Height unit" parameter (→ 116), here "m" for example. Menu path: Setup → Extended setup → Level → Height unit
7	Select the "Wet" option via the "Calibration mode" parameter (→ 116). Menu path: Setup → Extended setup → Level → Calibration mode

Description	
8	<p>a. The pressure for the lower calibration point is present at the device, here "0 mbar" for example.</p> <p>b. Select the "Empty calib." parameter (→ 117).</p> <p>c. Enter the volume value, here "0 l" for example.</p> <p>Menu path: Setup → Extended setup → Level → Empty calib.</p>
9	<p>a. The pressure for the upper calibration point is present at the device, here "400 mbar" (6 psi) for example.</p> <p>b. Select the "Full calib." parameter (→ 117).</p> <p>c. Enter the volume value, here "1000 l" (264 US gal) for example.</p> <p>Menu path: Setup → Extended setup → Level → Full calib.</p>
10	<p>Enter the density of the medium, using the "Adjust density" parameter (→ 117), here 1 g/cm³ (1 SGU) for example.</p> <p>Menu path: Setup → Extended setup → Level → Adjust density</p>
11	<p>If the process uses a medium other than the medium on which the calibration was based, the new density must be specified in the "Process density" parameter (→ 118).</p> <p>Menu path: Setup → Extended Setup → Level → Density process</p>
12	<p>Result: The measuring range is set for 0 to 1000 l (264 US gal). 0 l corresponds to an output current of 4 mA. 1000 l (264 US gal) corresponds to an output current of 20 mA.</p>

P01-FM021xxx-05-xx-xx-xx-029

P01-FM021xxx-05-xx-xx-xx-030

Calibration with reference pressure (wet calibration)

- 1 See table, Step 10.
- 2 See table, Step 8.
- 3 See table, Step 9.

7.12 Backup or duplicate device data


The device has no memory module. With an operating tool based on FDT technology (e.g. FieldCare), you have the following options:

- Saving/rescuing configuration data
- Duplicating instrument configurations
- Transferring all relevant parameters when replacing electronic inserts.

8 Maintenance

Deltabar M requires no maintenance.

For Cerabar M and Deltapilot M keep the pressure compensation and GORE-TEX® filter (1) free from contamination.



P01-xMx5xxxx-17-xx-xx-xx-000.

8.1 Cleaning instructions

Endress+Hauser offer flushing rings as accessories to clean process isolating diaphragms without taking the transmitters out of the process.

For further information please contact your local Endress+Hauser Sales Center.

8.1.1 Cerabar M PMP55

We recommend you perform CIP (cleaning in place (hot water)) before SIP (sterilization in place (steam)) for pipe diaphragm seals. A frequent use of sterilization in place (SIP) will increase the stress on the process isolating diaphragm. Under unfavorable circumstances in the long term view we cannot exclude that a frequent temperature change could lead to a material fatigue of the process isolating diaphragm and possibly to a leakage.

8.2 Exterior cleaning

Please note the following points when cleaning the device:

- The cleaning agents used should not corrode the surface and the seals.
- Mechanical damage to the process isolating diaphragm, e.g. due to pointed objects, must be avoided.
- Observe the degree of protection of the device. See the nameplate if necessary (→ 6 ff).

9 Troubleshooting

9.1 Messages

The following table lists the messages that can occur. The Diagnostic code parameter shows the message with the highest priority. The device has four different status information codes according to NAMUR NE107:

- F = failure
- M (warning) = maintenance required
- C (warning) = function check
- S (warning) = out of specification (deviations from the permitted ambient or process conditions determined by the device with the self-monitoring function, or errors in the device itself indicate that the measuring uncertainty is greater than what would be expected under normal operating conditions).




Diagnostic code	Error message	Cause	Measure
0	No error	–	–
C412	Backup in prog.	Downloading.	1. Wait for download to complete
C482	Current simul.	Current output simulation is switched on, i.e. the device is not measuring at present.	1. End the simulation
C484	Error simul.	Fault state simulation is switched on, i.e. the device is not measuring at present.	1. End the simulation
C485	Measure simul.	Simulation is switched on, i.e. the device is not measuring at present.	1. End the simulation
C824	Process pressure	<ul style="list-style-type: none"> – Overpressure or low pressure present. This message normally only appears briefly. – Electromagnetic effects are greater than specifications in the technical data. 	<ol style="list-style-type: none"> 1. Check the pressure value 2. Restart the device 3. Perform a reset
F002	Sens. unknown	Sensor does not suit the device (electronic sensor nameplate).	1. Contact Endress+Hauser Service
F062	Sensor conn.	<ul style="list-style-type: none"> – Cable connection between sensor and main electronics disconnected. – Sensor defective. – Electromagnetic effects are greater than specifications in the technical data. This message normally only appears briefly. 	<ol style="list-style-type: none"> 1. Check sensor cable 2. Replace electr. 3. Contact Endress+Hauser Service 4. Replace sensor (snap-on Version)
F081	Initialization	<ul style="list-style-type: none"> – Cable connection between sensor and main electronics disconnected. – Sensor defective. – Electromagnetic effects are greater than specifications in the technical data. This message normally only appears briefly. 	<ol style="list-style-type: none"> 1. Perform a reset 2. Check sensor cable 3. Contact Endress+Hauser Service
F083	Permanent mem.	<ul style="list-style-type: none"> – Sensor defective. – Electromagnetic effects are greater than specifications in the technical data. This message normally only appears briefly. 	<ol style="list-style-type: none"> 1. Restart the device 2. Contact Endress+Hauser Service
F140	Working range P	<ul style="list-style-type: none"> – Overpressure or low pressure present. – Electromagnetic effects are greater than specified in the technical data. – Sensor defective. 	<ol style="list-style-type: none"> 1. Check the process pressure 2. Check the sensor range
F261	Electronics	<ul style="list-style-type: none"> – Main electronics defective. – Fault in the main electronics. 	<ol style="list-style-type: none"> 1. Restart the device 2. Replace electr.
F282	Data memory	<ul style="list-style-type: none"> – Fault in the main electronics. – Main electronics defective. 	<ol style="list-style-type: none"> 1. Restart the device 2. Replace electr.

Diagnostic code	Error message	Cause	Measure
F283	Permanent mem.	<ul style="list-style-type: none"> - Main electronics defective. - Electromagnetic effects are greater than specifications in the technical data. - The supply voltage is disconnected when writing. - An error occurred when writing. 	<ol style="list-style-type: none"> 1. Perform a reset 2. Replace electr.
F411	Up-/download	<ul style="list-style-type: none"> - The file is defective. - During the download, the data are not correctly transmitted to the processor, e.g. because of open cable connections, voltage peaks (ripple) on the supply voltage or electromagnetic effects. 	<ol style="list-style-type: none"> 1. Download again 2. Use another file 3. Perform a reset
F510	Linearization	<ul style="list-style-type: none"> - The linearization table is being edited. 	<ol style="list-style-type: none"> 1. Conclude entries 2. Select "linear"
F511	Linearization	<ul style="list-style-type: none"> - The linearization table consists of less than 2 points. 	<ol style="list-style-type: none"> 1. Table too small 2. Corr. table 3. Accept the table
F512	Linearization	<ul style="list-style-type: none"> - The linearization table is not monotonic increasing or decreasing. 	<ol style="list-style-type: none"> 1. Tab. not monotonic 2. Corr. table 3. Accept the table
F841	Sensor range	<ul style="list-style-type: none"> - Overpressure or low pressure present. - Sensor defective. 	<ol style="list-style-type: none"> 1. Check the pressure value 2. Contact Endress+Hauser Service
F882	Input signal	<ul style="list-style-type: none"> - External measured value is not received or displays a failure status. 	<ol style="list-style-type: none"> 1. Check the bus 2. Check source device 3. Check setting
M002	Sens. unknown	<ul style="list-style-type: none"> - Sensor does not suit the device (electronic sensor nameplate). Device continues measuring. 	<ol style="list-style-type: none"> 1. Contact Endress+Hauser Service
M283	Permanent mem.	<ul style="list-style-type: none"> - Cause as indicated for F283. - Correct measurement can continue as long as you do not need the peakhold indicator function. 	<ol style="list-style-type: none"> 1. Perform a reset 2. Replace electr.
M431	Adjustment	<ul style="list-style-type: none"> - The pressure applied is outside the set measuring range (but within the sensor range). - The calibration carried out would result in the sensor nominal operating range being undershot or overshoot. 	<ol style="list-style-type: none"> 1. Check the measuring range 2. Check position adjustment 3. Check the setting
M434	Scaling	<ul style="list-style-type: none"> - Values for calibration (e.g. lower range value and upper range value) are too close together. - Lower range value and/or upper range value undershoot or overshoot the sensor range limits. - The sensor was replaced and the customer-specific configuration does not suit the sensor. - Unsuitable download carried out. 	<ol style="list-style-type: none"> 1. Check the measuring range 2. Check the setting 3. Contact Endress+Hauser Service
M438	Data record	<ul style="list-style-type: none"> - The supply voltage is disconnected when writing. - An error occurred when writing. 	<ol style="list-style-type: none"> 1. Check setting 2. Restart the device 3. Replace electr.
M515	Configuration Flow	<ul style="list-style-type: none"> - Max. flow out of nominal range of sensor 	<ol style="list-style-type: none"> 1. Recalibrate the device 2. Restart the device
M882	Input signal	<ul style="list-style-type: none"> - External measured value displays a warning status. 	<ol style="list-style-type: none"> 1. Check the bus 2. Check source device 3. Check setting


Diagnostic code	Error message	Cause	Measure
S110	Working range T	<ul style="list-style-type: none"> - Electromagnetic effects are greater than specifications in the technical data. - Sensor defective. - Overtemperature or low temperature present. 	<ol style="list-style-type: none"> 1. Check proc. temp. 2. Check temperature range
S140	Working range P	<ul style="list-style-type: none"> - Electromagnetic effects are greater than specifications in the technical data. - Sensor defective. - Overpressure or low pressure present. 	<ol style="list-style-type: none"> 1. Check proc. pressure 2. Check sensor range
S822	Process temp.	<ul style="list-style-type: none"> - The temperature measured in the sensor is greater than the upper nominal temperature of the sensor. - The temperature measured in the sensor is lower than the lower nominal temperature of the sensor. - Loose connection at the sensor cable. 	<ol style="list-style-type: none"> 1. Check the temperature 2. Check the setting
S841	Sensor range	<ul style="list-style-type: none"> - Overpressure or low pressure present. - Sensor defective. 	<ol style="list-style-type: none"> 1. Check the pressure value 2. Contact Endress+Hauser Service
S971	Adjustment	<ul style="list-style-type: none"> - The current is outside the permitted range 3.8 to 20.5 mA. - The pressure applied is outside the set measuring range (but within the sensor range). 	<ol style="list-style-type: none"> 1. Check the pressure value 2. Check the measuring range 3. Check the setting

9.2 Response of output to errors

The response of the current output to errors is defined in the following parameters:

- "Alarm behavior" (050) →  122
- "Output fail mode (190) →  122
- "High alarm current" (052) →  122

9.3 Repair

The Endress+Hauser repair concept provides for measuring devices to have a modular design and that the customer can also carry out repairs (see →  98, → Chap. 9.5 "Spare Parts").



Note!

- For certified devices, please see the "Repair of Ex-certified devices" section.
- For more information on service and spare parts, contact Endress+Hauser Service. → See www.endress.com/worldwide.

9.4 Repair of Ex-certified devices



Warning!

When repairing Ex-certified devices, please note the following:

- Only specialist personnel or Endress+Hauser may repair certified devices.
- Relevant standards, national hazardous area regulations and safety instructions and certificates must be observed.
- Only genuine Endress+Hauser spare parts may be used.
- When ordering spare parts, please check the device designation on the nameplate. Identical parts may only be used as replacements.
- Electronic inserts or sensors already in use in a standard device may not be used as spare parts for a certified device.
- Carry out repairs according to the instructions. Following a repair, the device must fulfill the requirements of the specified individual tests.
- A certified device may only be converted to another certified device version by Endress+Hauser.
- All repairs and modifications must be documented.

9.5 Spare Parts

- Some replaceable measuring device components are identified by means of a spare part nameplate. This contains information about the spare part.
- All the spare parts for the measuring device along with the order code are listed in the W@M Device Viewer (www.endress.com/deviceviewer) and can be ordered. If available, users can also download the associated Installation Instructions.



Note!

Measuring device serial number:

- Located on the device and spare part nameplate.
- Can be read out via the "Serial number" parameter in the "Instrument info" submenu.

9.6 Return

The measuring device must be returned if repairs or a factory calibration are required, or if the wrong measuring device has been ordered or delivered. According to legal regulations, Endress+Hauser, as a ISO-certified company, is required to follow certain procedures when handling returned products that are in contact with process fluids.

To ensure swift, safe and professional device returns, please read the return procedures and conditions on the Endress+Hauser website at www.services.endress.com/return-material.

9.7 Disposal

When disposing, separate and recycle the device components based on the materials.

9.8 Software history

Device	Date	Softwareversion	Software modifications	Operating Instruction
Cerabar	09.2009	01.00.zz	Original software. Compatible with: – FieldCare from version 2.02.00 – Field Communicator DXR375 with Device Rev.: 1, DD Rev.: 1	BA382P/00/EN/08.09 71089556
				BA382P/00/EN/10.09 71104504
				BA00382P/00/EN/13.10 71123275
				BA00382P/00/EN/14.11 71134588
				BA00382P/00/EN/15.11 71134880
				BA00382P/00/EN/16.12 71157182
				BA00382P/00/EN/17.12 71191304
				BA00382P/00/EN/18.14 71241501
				BA00382P/00/EN/19.14 71270330

Device	Date	Softwareversion	Software modifications	Operating Instruction
Deltabar	08.2009	01.00.zz	Original software. Compatible with: – FieldCare from version 2.02.00 – Field Communicator DXR375 with Device Rev.: 1, DD Rev.: 1	BA382P/00/EN/08.09 71089556
				BA382P/00/EN/10.09 71104504
				BA00382P/00/EN/13.10 71123275
				BA00382P/00/EN/14.11 71134588
				BA00382P/00/EN/15.11 71134880
				BA00382P/00/EN/16.12 71157182
				BA00382P/00/EN/17.12 71191304
				BA00382P/00/EN/18.14 71241501
				BA00382P/00/EN/19.14 71270330

Device	Date	Softwareversion	Software modifications	Operating Instruction
Deltapilot	10.2009	01.00.zz	Original software. Compatible with: – FieldCare from version 2.02.00 – Field Communicator DXR375 with Device Rev.: 1, DD Rev.: 1	BA382P/00/EN/10.09 71104504
				BA00382P/00/EN/13.10 71123275
				BA00382P/00/EN/14.11 71134588
				BA00382P/00/EN/15.11 71134880
				BA00382P/00/EN/16.12 71157182
				BA00382P/00/EN/17.12 71191304
				BA00382P/00/EN/18.14 71241501
				BA00382P/00/EN/19.14 71270330

10 Technical data

For the technical data, please refer to the Technical Information for Cerabar M TI436P / Deltabar M TI434P / Deltapilot M TI437P.

11 Appendix

11.1 Overview of operating menu



Note!

All the parameters are listed in the following table. The page number refers to where a description of the parameter can be found.

Level 1	Level 2	Level 3	Level 4	Direct access	Page		
Parameters in italics are read-only parameters and cannot be edited. Specific settings, such as the measuring mode, dry or wet calibration, or hardware locking, determine whether these parameters are displayed.							
	Language			000	111		
Display/operat.	Display mode			001	111		
	Add. disp. value			002	111		
	Format 1st value			004	112		
Setup	Lin./SQRT switch (Deltabar)			133	112		
	Measuring mode <i>Measuring mode (read only)</i>			005 <i>182</i>	112		
	Switch P1/P2 (Deltabar)			163	114		
	High pressure side (Deltabar) <i>High pressure side (read only)</i>			006 <i>183</i>	114		
	Press. eng. unit			125	113		
	Corrected press.			172	115		
	Pos. zero adjust (Deltabar M and gauge pressure sensors) Calib. offset (absolute pressure sensor)			007 192	113 113		
	Max. flow ("Flow" measuring mode) (Deltabar)			009	120		
	Max. pressure flow ("Flow" measuring mode) (Deltabar)			010	121		
	Empty calib. (Level measuring mode and "Calibration mode" = wet)			011	117		
	Full calib. (Level measuring mode and "Calibration mode" = wet)			012	117		
	Set LRV (Pressure measuring mode and flow linear)			013	123		
	Set URV (Pressure measuring mode and flow linear)			014	123		
	Damping switch (read only)			164	113		
	Damping <i>Damping (read only)</i>			017 <i>184</i>	113		
	Flow ("Flow" measuring mode) (Deltabar)			018	121		
	Level before lin (Level measuring mode)			019	118		
	Pressure af. damp			111	115		
	Extended setup	Code definition			023	110	
		Device tag			022	111	
		Operator code			021	110	
		Level (Level measuring mode)	Level selection			024	116
			Output unit			025	116
Height unit					026	116	
Calibration mode					027	116	
Empty calib. <i>Empty calib.</i>			028 011	117			
...					

Level 1	Level 2	Level 3	Level 4	Direct access	Page		
... Setup	... Extended setup	... Level (Level measuring mode)	Empty pressure <i>Empty pressure (read only)</i>	029 185	117		
			Empty height <i>Empty height (read only)</i>	030 186	117		
			Full calib. <i>Full calib.</i>	031 012	117		
			Full pressure <i>Full pressure (read only)</i>	032 187	117		
			Full height <i>Full height (read only)</i>	033 188	117		
			Adjust density	034	117		
			Process density	035	118		
			Level before lin	019	118		
		Linearization	Lin. mode	037	118		
			Unit after lin.	038	118		
			Line-numb.:	039	118		
			X-value:	040	118		
			Y-value:	041	119		
			Edit table	042	119		
			Tank description	173	119		
			Tank content	043	119		
		Flow ("Flow" measuring mode) (Deltabar)	Flow type	044	119		
			Mass flow unit	045	119		
			Norm. flow unit	046	120		
			Std. flow unit	047	120		
			Flow unit	048	120		
			Max. flow	009	120		
			Max. pressure flow	010	121		
			Set low-flow cut-off	049	121		
			Flow	018	121		
			Current output	Alarm behavior P	050	122	
		Alarm cur. switch		165	122		
		Output fail mode		190	122		
		High alarm curr.		052	122		
		Set min. current		053	122		
		Output current		054	122		
		Linear/Sqroot (Deltabar) <i>Linear/Sqroot (read only)</i>		055 191	123		
		Get LRV (Pressure measuring mode)		015	123		
		Set LRV		013	123		
		Get URV (pressure)		016	123		
		Set URV		014	123		
		Totalizer 1 (Deltabar)	Eng. unit totalizer 1	058 059 060 061	128

Level 1	Level 2	Level 3	Level 4	Direct access	Page		
... Setup	... Extended setup	... Totalizer 1 (Deltabar)	Totalizer 1 mode	175	128		
			Totalizer 1 failsafe	176	128		
			Reset totalizer 1	062	128		
			Totalizer 1	063	128		
			Totalizer 1 overflow	064	128		
		Totalizer 2 (Deltabar)	Eng. unit totalizer 2	065 066 067 068	129		
			Totalizer 2 mode	177	129		
			Totalizer 2 failsafe	178	129		
			Totalizer 2	069	129		
			Totalizer 2 overflow	070	129		
			Diagnostic code			071	129
			Last diag. code			072	129
			Min. meas. press.			073	129
Max. meas. press.			074	129			
Diagnostic list	Diagnostic 1	075	130				
	Diagnostic 2	076	130				
	Diagnostic 3	077	130				
	Diagnostic 4	078	130				
	Diagnostic 5	079	130				
	Diagnostic 6	080	130				
	Diagnostic 7	081	130				
	Diagnostic 8	082	130				
	Diagnostic 9	083	130				
	Diagnostic 10	084	130				
Event logbook	Last diag. 1	085	130				
	Last diag. 2	086	130				
	Last diag. 3	087	130				
	Last diag. 4	088	130				
	Last diag. 5	089	130				
	Last diag. 6	090	130				
	Last diag. 7	091	130				
	Last diag. 8	092	130				
	Last diag. 9	093	130				
	Last diag. 10	094	130				
Instrument info	Firmware version	095	111				
	Serial number	096	111				
	Ext. order code	097	111				
	Order identifier	098	111				
	Cust. tag number	254	111				
	Device tag	022	111				
	ENP version	099	111				
...	...						

Level 1	Level 2	Level 3	Level 4	Direct access	Page	
... Diagnosis	... Instrument Info	Config. counter		100	130	
		LRL sensor		101	121	
		URL sensor		102	121	
		Manufacturer ID		103	125	
		Device type code		105	125	
		Device revision		108	125	
	Measured values	Flow (Deltabar)		018	121	
		Level before lin		019	118	
		Tank content		043	118	
		Meas. pressure		020	115	
		Sensor pressure		109	115	
		Corrected press.		172	115	
		Sensor temp. (Cerabar/Deltapilot)		110	114	
		Pressure af. damp		111	115	
	Simulation	Simulation mode		112	131	
		Sim. pressure		113	131	
		Sim. flow (Deltabar)		114	131	
		Sim. level		115	131	
		Sim. tank cont.		116	132	
		Sim. current		117	132	
		Sim. error no.		118	132	
	Reset	Enter reset code		124	112	
	Expert	Direct access			119	110
System		Code definition		023	110	
		Lock switch		120	110	
		Operator code		021	110	
		Instrument info	Cust. tag number		254	110
			Device tag		022	111
			Serial number		096	111
			Firmware version		095	111
			Ext. order code		097	111
			Order identifier		098	111
			ENP version		099	111
			Electr. serial no.		121	111
		Sensor serial no.		122	111	
		Display	Language		000	111
			Display mode		001	111
Add. disp. value			002	111		
Format 1st value			004	112		
Management		Enter reset code		124	112	
Measurement		Lin./SQRT switch (Deltabar)		133	112	
		Measuring mode <i>Measuring mode (read only)</i>		005 182	112	
...	...					

Level 1	Level 2	Level 3	Level 4	Direct access	Page
... Expert	... Measurement	Basic setup	Pos. zero adjust (Deltabar and gauge pressure sensors)	007	113
			Calib. offset (absolute pressure sensor)	008	
			Damping switch (read only)	164	113
			Damping <i>Damping (read only)</i>	017 184	113
			Press. eng. unit	125	113
			Temp. eng. unit (Cerabar/Deltapilot)	126	114
			Sensor temp. (Cerabar/Deltapilot)	110	114
		Pressure	Switch P1/P2 (Deltabar)	163	114
			High pressure side (Deltabar) <i>High pressure side (read only)</i>	006 183	114
			Set LRV	013	114
			Set URV	014	114
			Meas. pressure	020	115
			Sensor pressure	109	115
			Corrected press.	172	115
			Pressure af. damp	111	115
		Level	Level selection	024	116
			Output unit	025	116
			Height unit	026	116
			Calibration mode	027	116
			Empty calib. <i>Empty calib.</i>	028 011	117
			Empty pressure <i>Empty pressure (read only)</i>	029 185	117
			Empty height <i>Empty height (read only)</i>	030 186	117
			Full calib. <i>Full calib.</i>	031 012	117
			Full pressure <i>Full pressure (read only)</i>	032 187	117
			Full height <i>Full height (read only)</i>	033 188	117
			Density unit	127	117
			Adjust density <i>Adjust density (read only)</i>	034 189	117
			Process density <i>Process density (read only)</i>	035 181	118
			Level before lin	019	118
			Linearization	Lin. mode	037
		Unit after lin.		038	118
		Line-numb.:		039	118
		X-value:		040	118
		Y-value:		041	119
Edit table	042	119			
Tank description	173	119			
...			

Level 1	Level 2	Level 3	Level 4	Direct access	Page		
... Expert	... Measurement	... Linearization	Tank content	043	119		
		Flow (Deltabar)	Flow type	044	119		
			Mass flow unit	045	119		
			Norm. flow unit	046	120		
			Std. flow unit	047	120		
			Flow unit	048	120		
			Max. flow	009	120		
			Max. pressure flow	010	121		
			Set low-flow cut-off	049	121		
			Flow	018	121		
			Sensor limits	LRL sensor	101	121	
		URL sensor		102	121		
		Sensor trim		Lo trim measured	129	121	
				Hi trim measured	130	121	
			Lo trim sensor	131	121		
			Hi trim sensor	132	121		
		Output	Current output	Output current (read only)	054	122	
				Alarm behavior P	050	122	
				Alarm cur. switch (read only)	165	122	
				Output fail mode <i>Output fail mode (read only)</i>	190 051	122	
	High alarm curr.			052	122		
	Set min. current			053	122		
	Lin./SQRT switch (Deltabar)			133	122		
	Linear/Sqroot (Deltabar)			055	123		
	Get LRV (Pressure measuring mode)			015	123		
	Set LRV			056 013 166 168	123		
	Get URV (Pressure measuring mode)			016	123		
	Set URV			057 014 067 169	123		
	Start current			134	123		
	Curr. trim 4mA			135	123		
	Curr. trim 20mA			136	124		
	Offset trim 4mA			137	124		
	Offset trim 20 mA			138	124		
	Communication			HART config	Burst mode	142	125
					Burst option	143	125
					Current mode	144	125
		Bus address	145		125		
		Preamble number	146		125		
					

Level 1	Level 2	Level 3	Level 4	Direct access	Page		
... Expert	... Communication	HART info	Device type code	105	125		
			Device revision	108	125		
			Manufacturer ID	103	125		
			Hart version	180	125		
			Descriptor	139	125		
			HART message	140	125		
			HART date	141	126		
		HART output	Primary value is	147	126		
			Primary value	148	126		
			Secondary val. is	149	126		
			Secondary value	150	126		
			Third value is	151	126		
			Third value	152	126		
			4th value is	153	126		
		4th value	154	126			
		HART input	HART input value	155	126		
			HART input stat.	179	126		
			HART input unit	156	127		
			HART input form.	157	127		
	Application	Electr. delta P (Cerabar/Deltapilot)		158	127		
			Fixed ext. value (Cerabar/Deltapilot)	174	127		
		Totalizer 1 (Deltabar)	Eng. unit totalizer 1		058 059 060 061	128	
				Totalizer 1 mode	175		128
				Totalizer 1 failsafe	176		128
			Reset totalizer 1	062	128		
			Totalizer 1	063	128		
			Totalizer 1 overflow	064	128		
		Totalizer 2 (Deltabar)	Eng. unit totalizer 2		065 066 067 068	129	
				Totalizer 2 mode	177		129
				Totalizer 2 failsafe	178		129
			Totalizer 2	069	129		
			Totalizer 2 overflow	070	129		
		Diagnosis	Diagnostic code		071	129	
Last diag. code			072	129			
Reset logbook			159	129			
Min. meas. press.			073	129			
Max. meas. press.			074	129			
Reset peakhold			161	130			
Operating hours			162	130			
...	...						

Level 1	Level 2	Level 3	Level 4	Direct access	Page
... Expert	... Diagnosis	Config. counter		100	130
		Diagnostic list	Diagnostic 1	075	130
			Diagnostic 2	076	130
			Diagnostic 3	077	130
			Diagnostic 4	078	130
			Diagnostic 5	079	130
			Diagnostic 6	080	130
			Diagnostic 7	081	130
			Diagnostic 8	082	130
			Diagnostic 9	083	130
			Diagnostic 10	084	130
		Event logbook	Last diag. 1	085	130
			Last diag. 2	086	130
			Last diag. 3	087	130
			Last diag. 4	088	130
			Last diag. 5	089	130
			Last diag. 6	090	130
			Last diag. 7	091	130
			Last diag. 8	092	130
			Last diag. 9	093	130
			Last diag. 10	094	130
		Simulation	Simulation mode	112	131
			Sim. pressure	113	131
			Sim. flow (Deltabar)	114	131
			Sim. level	115	131
			Sim. tank cont.	116	132
			Sim. current	117	132
			Sim. error no.	118	132

11.2 Description of parameters



Note!


This section describes the parameters in the order they are arranged in the "Expert" operating menu. Parameters (or parameter numbers) in *italics* are read-only parameters and cannot be edited. Specific settings, such as the measuring mode, dry or wet calibration, or hardware locking, determine whether these parameters are displayed.

Expert

Parameter name	Description
Direct access (119) Entry	Enter the direct access code to go directly to a parameter. Options: ■ A number between 0 and 999 (only valid entries are recognized) Factory setting: 0 Note: For direct access, it is not necessary to enter leading zeros.

11.2.1 System

Expert → System

Parameter name	Description
Code definition (023) Entry	Use this function to enter a release code with which the device can be unlocked. Options: ■ A number between 0 and 9999 Factory setting: 0
Lock switch (120) Display	Displays the status of DIP switch 1 on the electronic insert. You can lock or unlock parameters relevant to the measured value with DIP switch 1. If operation is locked by means of the " Operator code " (021) parameter, you can only unlock operation again by means of this parameter. Display: ■ On (locking switched on) ■ Off (locking switched off) Factory setting: Off (locking switched off)
Operator code (021) Entry	Use this function to enter a code to lock or unlock operation. Options: ■ To lock operation: enter a number between 1 and 9999 provided the release code = 0; then a number ≠ release code. ■ To unlock operation: enter the number 0.  Note! The release code is "0" in the order configuration. Another release code can be defined in the "Code definition" parameter. If the user has forgotten the release code, it can be made visible again by entering the number sequence "5864". Factory setting: 0

Expert → System → Instrument info

Parameter name	Description
Cust. tag number (254) Entry	Enter device tag e.g. TAG number (max. 8 alphanumeric characters). Factory setting: no entry or as per order specifications
Device tag (022) Entry	Enter device tag e.g. TAG number (max. 32 alphanumeric characters). Factory setting: no entry or as per order specifications
Serial number (096) Display	Displays the serial number of the device (11 alphanumeric characters).
Firmware version (095) Display	Displays the firmware version.
Ext. order code (097) Display	Enter the extended order code. Factory setting: As per order specifications
Order identifier (098) Entry	Enter the order identifier. Factory setting: As per order specifications
ENP version (099) Display	Displays the ENP version (ENP = electronic nameplate)
Electr. serial no. (121) Display	Displays the serial number of the main electronics (11 alphanumeric characters).
Sensor serial no. (122) Display	Displays the serial number of the sensor (11 alphanumeric characters).

Expert → System → Display


Parameter name	Description
Language (000) Selection	Select the menu language for the local display. Options: <ul style="list-style-type: none"> ■ English ■ Optionally one further language (as selected when ordering the device) ■ One further language (language of the producing factory) Factory setting: English
Display mode (001) Selection	Specify the contents for the first line of the local display in the measuring mode. Options: <ul style="list-style-type: none"> ■ Primary value (PV) ■ External value ■ All alternating Factory setting: Primary value (PV)
Add. disp. value (002) Selection	Specify the contents for the second line of the local display in the measuring mode. Options: <ul style="list-style-type: none"> ■ No value ■ Pressure ■ Main value (%) ■ Current ■ Temperature ■ Totalizer 1 ■ Totalizer 2 The options depend on the measuring mode chosen. Factory setting: No value

Parameter name	Description
Format 1st value (004) Selection	Specify the number of places after the decimal point for the value displayed in the main line. Options: <ul style="list-style-type: none"> ■ Auto ■ x ■ x.x ■ x.xx ■ x.xxx ■ x.xxxx ■ x.xxxxx Factory setting: Auto

Expert → System → Management


Parameter name	Description
Enter reset code (124) Entry	Reset parameters completely or partially to the factory values or order configuration, → Page 50, "Resetting to factory settings (reset)". Factory setting: 0

11.2.2 Measurement**Expert → Measurement**



Parameter name	Description
Lin./SQRT switch (133) Display	Displays the status of DIP switch 4 on the electronic insert, which is used to define the output characteristics of the current output. Display: <ul style="list-style-type: none"> ■ SW setting The output characteristics is defined by the "Linear/Sqroot" (055) parameter. ■ Square root The square root signal is used, independent of the setting in the "Linear/Sqroot" (055) parameter. Factory setting SW setting
Measuring mode (005) Selection	Select the measuring mode. The operating menu is structured differently depending on the measuring mode selected.  Warning! If the measuring mode is changed, the span setting (URV) must be verified in the "Setup" operating menu and, if necessary, reconfigured. Options: <ul style="list-style-type: none"> ■ Pressure ■ Level ■ Flow (Deltabar M only) Factory setting Pressure or as per order specifications



Expert → Measurement → Basic setup

Parameter name	Description
Pos. zero adjust (007) (Deltabar M and gauge pressure sensor) Selection	Position adjustment – the pressure difference between zero (set point) and the measured pressure need not be known. Example: – Measured value = 2.2 mbar (0.033 psi) – You correct the measured value via the "Pos. zero adjust" parameter with the "Confirm" option. This means that you are assigning the value 0.0 to the pressure present. – Measured value (after pos. zero adjust) = 0.0 mbar – The current value is also corrected. Factory setting: Abort
Calib. offset (192) / (008) (absolute pressure sensor) Selection	Position adjustment – the pressure difference between the set point and the measured pressure must be known. Example: – Measured value = 982.2 mbar (14.73 psi) – You correct the measured value with the value entered (e.g. 2.2 mbar (0.033 psi)) via the "Calib. offset" parameter. This means that you are assigning the value 980.0 (14.7 psi) to the pressure present. – Measured value (after pos. zero adjust) = 980.0 mbar (14.7 psi) – The current value is also corrected. Factory setting: 0.0
Damping switch (164) Display	Displays the switch position of DIP switch 4 which is used to switch the damping of the output signal on and off. Display: <ul style="list-style-type: none"> ■ Off The output signal is not damped. ■ On The output signal is damped. The attenuation constant is specified in the "Damping value" parameter (017) (184) Factory setting On
Damping value (017) Entry	Enter the damping time (time constant τ). The damping affects the speed at which the measured value reacts to changes in pressure. Input range: 0.0 to 999.0 s Factory setting: 2.0 or as per order specifications
Press. eng. unit (125) Selection	Select the pressure unit. If a new pressure unit is selected, all pressure-specific parameters are converted and displayed with the new unit. Options: <ul style="list-style-type: none"> ■ mbar, bar ■ mmH₂O, mH₂O, inH₂O ■ ftH₂O ■ Pa, kPa, MPa ■ psi ■ mmHg, inHg ■ kgf/cm² Factory setting: mbar or bar depending on the sensor nominal measuring range, or as per order specifications


Parameter name	Description
Temp. eng. unit (126) (only for Cerabar M and Deltapilot M) Selection	Select the unit for the temperature measured values.  Note! The setting affects the unit for the "Sensor temp." parameter. Options: <ul style="list-style-type: none"> ■ °C ■ °F ■ K Factory setting: °C
Sensor temp. (110) (only for Cerabar M and Deltapilot M) Display	Displays the temperature currently measured in the sensor. This can deviate from the process temperature.



Expert → Measurement → Pressure


Parameter name	Description
Switch P1/P2 (163) Display	Indicates whether the "SW/P2High" DIP switch (DIP switch 5) is switched on.  Note! The "SW/P2High" DIP switch determines which pressure input corresponds to the high-pressure side. Display: <ul style="list-style-type: none"> ■ SW setting "SW/P2 High" is switched off: The "High pressure side" (006) parameter determines which pressure input corresponds to the high-pressure side. ■ P2 High "SW/P2 High" is switched on: Pressure input P2 corresponds to the high-pressure side, independent of the setting in the "High pressure side" (006) parameter. Factory setting: SW setting
High pressure side (006) (183) Selection	Determines, which pressure input corresponds to the high-pressure side.  Note! This setting is only valid if the "SW/P2High" DIP switch is in the OFF position (see the "Pressure side switch" (163) parameter). Otherwise P2 corresponds to the high-pressure side in any case. Selection: <ul style="list-style-type: none"> ■ P1 High Pressure input P1 is the high-pressure side. ■ P2 High Pressure input P2 is the high-pressure side. Factory setting P1 High
Set LRV (013) Display	Set the lower-range value – without reference pressure. Enter the pressure value for the lower current value (4 mA). Factory setting: 0.0 or as per order specifications
Set URV (014) Display	Set the upper-range value – without reference pressure. Enter the pressure value for the upper current value (20 mA). Factory setting: Upper range limit sensor or as per order specifications.

Parameter name	Description
<p>Meas. pressure (020) Display</p>	<p>Displays the measured pressure after sensor recalibration, position adjustment and damping. Cerabar M and Deltapilot M:</p>  <p style="text-align: right;"><small>P01-FMX21xxxx-05-xx-xx-en-009</small></p> <p>Deltabar M:</p>  <p style="text-align: right;"><small>P01-FMD55xxx-05-xx-xx-en-008</small></p>
<p>Sensor pressure (109) Display</p>	<p>Displays the measured pressure before the sensor trim and position adjustment.</p>
<p>Corrected press. (172) Display</p>	<p>Displays the measured pressure after sensor trim and position adjustment.</p>
<p>Pressure af. damp (111) Display</p>	<p>Displays the measured pressure after sensor trim, position adjustment and damping.</p>


Expert → Measurement → Level


Parameter name	Description
Level selection (024) Selection	Select the method for calculating the level Options: <ul style="list-style-type: none"> ■ In pressure If this option is selected, specify two pressure/level value pairs. The level value is displayed directly in the unit that you select via the "Output unit" parameter. ■ In height If this option is selected, specify two height/level value pairs. From the measured pressure, the device first calculates the height using the density. This information is then used to calculate the level in the "Output unit" selected using the two value pairs specified. Factory setting: In pressure
Output unit (025) Selection	Select the unit for the measured value display for the level before linearization.  Note! The unit selected is only used to describe the measured value. This means that the measured value is not converted when a new output unit is selected. Example: <ul style="list-style-type: none"> ■ Current measured value: 0.3 ft ■ New output unit: m ■ New measured value: 0.3 m Options <ul style="list-style-type: none"> ■ % ■ mm, cm, dm, m ■ ft, inch ■ m³, in³ ■ l, hl ■ ft³ ■ gal, lgal ■ kg, t ■ lb Factory setting: %
Height unit (026) Selection	Select the height unit. The measured pressure is converted to the selected height unit using the "Adjust density" parameter. Prerequisite "Level selection" = "In height" Options <ul style="list-style-type: none"> ■ mm ■ m ■ inch ■ ft Factory setting: m
Calibration mode (027) Selection	Select the calibration mode. Options: <ul style="list-style-type: none"> ■ Wet Wet calibration takes place by filling and emptying the container. With two different levels, the level, volume, mass or percentage value entered is assigned to the pressure measured at this point in time ("Empty calibration" and "Full calibration" parameters). ■ Dry Dry calibration is a theoretical calibration. For this calibration, you specify two pressure/level value pairs via the following parameters: "Empty calib.", "Empty pressure", "Full calib.", "Full pressure". Factory setting: Wet

Parameter name	Description
Empty calib. (028) Empty calib. (011) Entry	Enter the output value for the lower calibration point (container empty). The unit defined in "Output unit" must be used.  Note! <ul style="list-style-type: none"> ■ In the case of wet calibration, the level (container empty) must actually be available. The associated pressure is then automatically recorded by the device. ■ In the case of dry calibration, the level (container empty) does not have to be available. The associated pressure has to be entered in the "Empty pressure (029)" parameter for the "In pressure" level selection. The associated height has to be entered in the "Empty height (030)" parameter for the "In height" level selection. Factory setting: 0.0
Empty pressure (029) Entry/display	Enter the pressure value for the lower calibration point (container empty). → See also "Empty calib. (028)". Prerequisite <ul style="list-style-type: none"> ■ "Level selection" = In pressure "Calibration mode" = Wet (display only), Dry (entry) Factory setting: 0.0
Empty height (030) Entry/display	Enter the height value for the lower calibration point (container empty). Select the unit via the "Height unit (026)" parameter. Prerequisite: <ul style="list-style-type: none"> ■ "Level selection" = in height and "Calibration mode" = wet (display only) , Dry (entry) Factory setting: 0.0
Full calib. (031) Full calib. (012) Entry	Enter the output value for the upper calibration point (container full). The unit defined in "Output unit" must be used.  Note! <ul style="list-style-type: none"> ■ In the case of wet calibration, the level (container full) must actually be available. The associated pressure is then automatically recorded by the device. ■ In the case of dry calibration, the level (container full) does not have to be available. The associated pressure has to be entered in the "Full pressure (030)" parameter for the "In pressure" level mode. The associated height has to be entered in the "Empty height" parameter for the "In height" level selection. Factory setting: 100.0
Full pressure (032) Entry/display	Enter the pressure value for the upper calibration point (container full). → See also "Full calib.". Prerequisite <ul style="list-style-type: none"> ■ "Level selection" = in pressure and "Calibration mode" = wet (display only), Dry (entry) Factory setting: Upper-range limit (URL) of the sensor
Full height (033) Entry/display	Enter the height value for the upper calibration point (container full). You select the unit via the "Height unit" parameter. Prerequisite: <ul style="list-style-type: none"> ■ "Level selection" = in height and "Calibration mode" = wet (display only), Dry (entry) Factory setting: Upper-range limit (URL) is converted to a height unit
Density unit (127) Display	Displays the density unit. The measured pressure is converted to a height using the "Height unit", "Density unit" and "Adjust density" parameters. Factory setting: <ul style="list-style-type: none"> ■ g/cm³
Adjust density (034) Entry	Enter the density of the medium. The measured pressure is converted to a height using the "Height unit" and "Adjust density" parameters. Factory setting: 1.0

Parameter name	Description
Process density (035) Entry	<p>Enter a new density value for density correction.</p> <p>The calibration was carried out with water as the medium, for example. Now the container is to be used for another medium with another density. The calibration is corrected appropriately by entering the new density value in the "Process density" parameter.</p> <p> Note! If you change to dry calibration after a wet calibration using the "Calibration mode" parameter, the density for the "Adjust density" and "Process density" parameters must be entered correctly before changing the calibration mode. If the pressure falls with increasing levels, such as in the case of residual volume measurement, a negative value must be entered for this parameter.</p> <p>Factory setting: 1.0</p>
Level before lin. (019) Display	Displays the level value prior to linearization.


Expert → Measurement → Linearization




Parameter name	Description
Lin. mode (037) Selection	<p>Select the linearization mode.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ Linear The level is output without being converted beforehand. "Level before lin." is output. ■ Erase table The existing linearization table is deleted. ■ Manual entry (sets the table to the edit mode, an alarm is output): The value pairs of the table (X-value and Y-value) are entered manually. ■ Semiautomatic entry (sets the table to the edit mode, an alarm is output): The container is emptied or filled in stages in this entry mode. The device automatically records the level value (X-value). The associated volume, mass or %-value is entered manually (Y-value). ■ Activate table The table entered is activated and checked with this option. The device shows the level after linearization. <p>Factory setting: Linear</p>
Unit after lin. (038) Selection	<p>Select the volume unit (unit of the Y-value).</p> <p>Options:</p> <ul style="list-style-type: none"> ■ % ■ cm, dm, m, mm ■ hl ■ in³, ft³, m³ ■ l ■ in, ft ■ kg, t ■ lb ■ gal ■ lgal <p>Factory setting: %</p>
Line numb. (039) Entry	<p>Enter the number of the current point in the table.</p> <p>The subsequent entries for "X-value" and "Y-value" refer to this point.</p> <p>Input range:</p> <ul style="list-style-type: none"> ■ 1 to 32
X-value (193/040) Display/Entry	<p>Enter the level value for the specific point in the table and confirm.</p> <p> Note!</p> <ul style="list-style-type: none"> ■ If "Lin. mode" = "Manual", the level value has to be entered. ■ If "Lin. mode" = "Semiautomatic", the level value is displayed and has to be confirmed by entering the associated Y-value.

Parameter name	Description
Y-value (041) Entry	Enter the output value for the specific point in the table. The unit is determined by "Unit after lin."  Note! The linearization table must be monotonic (increasing or decreasing).
Edit table (042) Selection	Select the function for entering the table. Options: <ul style="list-style-type: none"> ■ Next point: enter the next point. ■ Current point: stay on the current point to correct a mistake for example. ■ Previous point: skip back to the previous point to correct a mistake for example. ■ Insert point: insert an additional point (see example below). ■ Delete point: delete the current point (see example below). Example: Add a point - in this case between the 4th and 5th point for example <ul style="list-style-type: none"> - Select point 5 via the "Line-numb." parameter. - Select the "Insert point" option via the "Edit table" parameter. - Point 5 is displayed for the "Line-numb" parameter. Enter new values for the "X-value" and "Y-value" parameters. Example: Delete a point - in this case the 5th point for example <ul style="list-style-type: none"> - Select point 5 via the "Line-numb." parameter. - Select the "Delete point" option via the "Edit table" parameter. - The 5th point is deleted. All of the subsequent points are moved up one number i.e. following deletion, the 6th point becomes Point 5. Factory setting: Current point
Tank description (173) Entry	Enter the tank description (max. 32 alphanumeric characters)
Tank content (043) Display	Displays the level value after linearization.

Expert → Measurement → Flow (Deltabar M)

Parameter name	Description
Flow type (044) Selection	Select the flow type. Options: <ul style="list-style-type: none"> ■ Volume process cond. (volume under operating conditions) ■ Volume norm. cond. (norm volume under norm conditions in Europe: 1013,25 mbar and 273,15 K (0 °C)) ■ Volume std. cond. (standard volume under standard conditions in the USA: 1013,25 mbar (14,7 psi) and 288,15 K (15 °C/59 °F)) ■ Mass (mass under operating conditions) ■ Flow in % Factory setting: Flow in %
Mass flow unit (045) Selection	Select mass flow unit. When a new flow unit is selected, all flow-specific parameters are converted and displayed with the new unit within a flow type. When the flow type is changed, conversion is not possible. Prerequisite: <ul style="list-style-type: none"> ■ "Flow type" (044) = Mass Options: <ul style="list-style-type: none"> ■ g/s, kg/s, kg/min, kg/h ■ t/s, t/min, t/h, t/d ■ oz/s, oz/min ■ lb/s, lb/min, lb/h ■ ton/s, ton/min, ton/h, ton/d Factory setting: kg/s

Parameter name	Description
Norm. flow unit (046) Selection	<p>Select norm flow unit. When a new flow unit is selected, all flow-specific parameters are converted and displayed with the new unit within a flow type. When the flow type is changed, conversion is not possible.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ "Flow type" (044) = Volume norm. cond. <p>Options:</p> <ul style="list-style-type: none"> ■ Nm³/s, Nm³/min, Nm³/h, Nm³/d <p>Factory setting: Nm³/s</p>
Std. flow unit (047) Selection	<p>Select standard flow unit. When a new flow unit is selected, all flow-specific parameters are converted and displayed with the new unit within a flow type. When the flow type is changed, conversion is not possible.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ "Flow type" (044) = Volume std. cond. <p>Options:</p> <ul style="list-style-type: none"> ■ Sm³/s, Sm³/min, Sm³/h, Sm³/d ■ SCFS, SCFM, SCFH, SCFD <p>Factory setting: Sm³/s</p>
Flow unit (048) Selection	<p>Select volume flow unit. When a new flow unit is selected, all flow-specific parameters are converted and displayed with the new unit within a flow type. When the flow type is changed, conversion is not possible.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ "Flow type" (044) = Volume process cond. <p>Options:</p> <ul style="list-style-type: none"> ■ dm³/s, dm³/min, dm³/h ■ m³/s, m³/min, m³/h, m³/d ■ l/s, l/min, l/h ■ hl/s, hl/min, hl/d ■ ft³/s, ft³/min, ft³/h, ft³/d ■ ACFS, ACFM, ACFH, ACFD ■ ozf/s, ozf/min ■ Gal/s, Gal/min, Gal/h, Gal/day, MGal/d ■ I. Gal/s, I. Gal/min, I. Gal/h ■ bbl/s, bbl/min, bbl/h, bbl/d <p>Factory setting: m³/s</p>
Max. flow (009) Entry	<p>Enter maximum flow of primary element. See also layout sheet of primary element. The maximum flow is assigned to the maximum pressure which you enter via the "Max. pressure flow" (010) parameter.</p> <p> Note! Use the "Linear/Sqroot" (055) parameter to specify the current signal for the "Flow" measuring mode. The following applies for the "square root" setting: If you enter a new value for "Max. flow" (009), the value for "Set URV" (057) is also changed. Use the "Set URV" (057) parameter to assign a flow to the upper current value. If you want to assign the upper current value a value other than that for "Max. flow" (009), you must enter the desired value for "Set URV" (057).</p> <p>Factory setting: 100.0</p>

Parameter name	Description
Max. pressure flow (010) Entry	Enter maximum pressure of primary element. → See layout sheet of primary element. This pressure is assigned to the flow defined in the " Max. flow " (009) parameter.  Note! Use the " Lienar/Sqroot " (055) parameter to specify the current signal for the "Flow" measuring mode. The following applies for the "linear" setting: If you enter a new value for " Max. pressure flow " (010), the value for " Set URV " (014) is also changed. Use the " Set URV " (014) parameter to assign a pressure value to the upper current value. If you want to assign the upper current value a value other than that for "Max. press. flow" (010), you must enter the desired value for " Set URV " (014). Factory setting: Upper range limit (URL) of the sensor
Set low-flow cut-off (049) Entry	Enter switch-on point of the flow-flow cut-off. The hysteresis between the switch-on point and the switch-off point is always 1 % of the maximum flow value. Input range: 0...50 % of the end flow value ("Max. flow" (009)). <div style="display: flex; justify-content: space-around; align-items: flex-end;"> <div style="text-align: center;">  <p>①</p> </div> <div style="text-align: center;">  <p>②</p> </div> </div> <p style="text-align: right; font-size: small;">P01-FMD7xxxx-05-xx-xx-xx-000</p> Factory setting: 5 % (of the maximum flow value)
Flow (018) Display	Displays the present flow value.

Expert → Measurement → Sensor limits

Parameter name	Description
LRL sensor (101) Display	Displays the lower-range limit of the sensor.
URL sensor (102) Display	Displays the upper-range limit of the sensor.

Expert → Measurement → Sensor trim

Parameter name	Description
Lo trim measured (129) Display	Displays the reference pressure present to be accepted for the lower calibration point.
Hi trim measured (130) Display	Displays the reference pressure present to be accepted for the upper calibration point.
Lo trim sensor (131) Display	Sensor recalibration by entering a target pressure while simultaneously and automatically accepting a reference pressure present for the lower calibration point.
Hi trim sensor (132) Display	Sensor recalibration by entering a target pressure while simultaneously and automatically accepting a reference pressure present for the upper calibration point.

11.2.3 Output

Expert → Output → Current output

Parameter name	Description
Output current (054) Display	Displays the current value of the current.
Alarm behav. P (050) Selection	Configure the current output for when the sensor limits are undershot or overshot. Options: <ul style="list-style-type: none"> ■ Warning The device continues measuring. An error message is displayed. ■ Alarm The output signal assumes a value that can be specified by the "Output fail mode" function. ■ NAMUR <ul style="list-style-type: none"> – Lower sensor limit undershot: Current output = 3.6 mA – Upper sensor limit overshot: Current output assumes value of 21 to 23 mA, depending on the setting of the "High alarm curr." (052) parameter. Factory setting: Warning
Alarm cur. switch (165)	Displays the switch status of DIP switch 3 "SW/alarm min." Display <ul style="list-style-type: none"> ■ AF The alarm current has the value defined in the "Output fail mode" (190). ■ Alarm min. The alarm current is 3.6 mA regardless of the software setting.
Output fail mode (190) Selection	Select the output fail mode. In the event of an alarm, the current assumes the current value specified with this parameter. Options: <ul style="list-style-type: none"> ■ Max. (110%): can be set from 21 to 23 mA Max: can be set from 21 to 23 mA → see also "High alarm curr. (052)" ■ Hold: last measured value is held ■ Min. (-10%): 3.6 mA Factory setting: Max. alarm 110% (22 mA)
High alarm curr. (052) Entry	Enter the current value for the high alarm current. → See also "Output fail mode". Input range: 21 to 23 mA Factory setting: 22 mA
Set min. current (053) Entry	Enter the lower current limiting value. Some switching units do not accept current values lower than 4.0 mA. Options: <ul style="list-style-type: none"> ■ 3.8 mA ■ 4.0 mA Factory setting: 3.8 mA
Lin./SQRT switch (133) Display	Displays the state of DIP switch 4 "SW/SQRT". Display <ul style="list-style-type: none"> ■ SW The output characteristics is defined in the "Linear/Sqroot" (055) parameter ■ Square root The output characteristics follows a square root function, independent of the software setting. This characteristics is needed for differential pressure flow measurement.

Parameter name	Description
Linear/Sqroot (055) Selection	Specify current signal for the "Flow" measuring mode. See also: "Set LRV" (056) and "Set URV" (057). Prerequisite: <ul style="list-style-type: none"> ■ "Measuring mode" (005) = Flow Options: <ul style="list-style-type: none"> ■ Linear The linear pressure signal is used for the current output. The flow must be calculated in the evaluation unit. ■ Flow (square root) The root flow signal is used for the current output. The "Flow (square root)" current signal is indicated on the on-site display with a root symbol. Factory setting: Square root
Get LRV (015) Entry (only in pressure measuring mode)	Set the lower-range value – reference pressure is present at the device. The pressure for the lower current value (4 mA) is present at the device. With the "Confirm" option, you assign the lower current value to the pressure value present. Options: <ul style="list-style-type: none"> ■ Abort ■ Confirm
Set LRV (056, 013, 166, 168) Entry	Set the pressure value for the lower current value (4 mA). Factory setting: 0.0 % in the level measuring mode; 0.0 or in accordance with ordering specifications in the pressure measuring mode 0.0 m ³ /h in the flow measuring mode
Get URV (016) Entry (only in pressure measuring mode)	Set the upper-range value – reference pressure is present at the device. The pressure for the upper current value (20 mA) is present at the device. With the "Confirm" option, you assign the upper current value to the pressure value present. Options: <ul style="list-style-type: none"> ■ Abort ■ Confirm
Set URV (057, 014, 167, 169) Entry	Set the pressure value for the upper current value (20 mA). Factory setting: 100.0 % in the level measuring mode; URL sensor or in accordance with ordering information in the pressure measuring mode; 3600 m ³ /h in the flow measuring mode
Startcurrent (134) Entry	Use this function to enter the start current. This setting is also effective in the HART multidrop mode. Options: <ul style="list-style-type: none"> ■ 12 mA ■ Max Alarm (22 mA, non-adjustable) Factory setting: 12 mA
Curr. trim 4mA (135) Entry	Enter the current value for the lower point (4 mA) of the current linear regression line. You can adapt the current output to the transmission conditions with this parameter and "Curr. trim 20mA". Perform the current trim for the lower point as follows: <ol style="list-style-type: none"> 1. Select the "Current" option in the "Simulation mode" parameter. 2. Set the 4mA value in the "Sim. current" parameter. 3. Enter the current value measured with the switching unit in the "Curr. trim 4mA" parameter. Input range: Measured current ± 0.2 mA Factory setting: 4 mA

Parameter name	Description
Curr. trim 20mA (136) Entry	Enter the current value for the upper point (20 mA) of the current linear regression line. You can adapt the current output to the transmission conditions with this parameter and "Curr. trim 4mA". Perform the current trim for the lower point as follows: <ol style="list-style-type: none"> 1. Select the "Current" option in the "Simulation mode" parameter. 2. Enter the "20 mA" value in the "Sim. current" parameter. 3. Enter the current value measured with the switching unit in the "Curr. trim 20mA" parameter. Input range: Measured current ± 0.2 mA Factory setting: 20 mA
Offset trim 4mA (137) Display	Displays the difference between 4 mA and the value entered for the "Curr. trim 4mA" parameter. Factory setting: 0
Offset trim 20mA (138) Display	Displays the difference between 20 mA and the value entered for the "Curr. trim 20mA" parameter. Factory setting: 0

11.2.4 Communication

Expert → Communication → HART config

Parameter name	Description
Burst mode (142) Selection	Switch the burst mode on and off. Options: <ul style="list-style-type: none"> ■ On ■ Off
Burst option (143) Entry	Use this parameter to specify what HART command is sent to the master. Options: <ul style="list-style-type: none"> ■ 1 (HART command 1) ■ 2 (HART command 2) ■ 3 (HART command 3) ■ 9 (HART command 9) ■ 33 (HART command 33) Factory setting: 1 (HART command 1)
Current mode (144) Selection	Configure the current mode for HART communication. Options: <ul style="list-style-type: none"> ■ Signaling Measured value transmitted by the current value ■ Fixed Fixed current 4.0 mA (multidrop mode) (measured value only transmitted via HART digital communication) Factory setting Signaling
Bus address (145) Entry	Enter the address for exchanging data via the HART protocol. (HART 5.0 master: Range 0 to 15, where address = 0 calls up the "Signaling" setting; HART 6.0 master: range 0 to 63) Factory setting: 0
Preamble number (146) Entry	Enter the number of preambles in the HART protocol. (Synchronization of the modem modules along a transmission path, each modem module could "swallow" one byte; at least 2 bytes must be preambles.) Input range: 2 to 20 Factory setting: 5

Expert → Communication → HART info

Parameter name	Description
Device type code (105) Display	Displays the numeric ID of the device. For Deltabar M: 33 For Deltapilot: 35 For Cerabar: 25
Device revision (108) Display	Displays the device revision. e.g.: 1
Manufacturer ID (103) Display	Displays the manufacturer number in decimal numerical format. Here: 17 Endress+Hauser
HART revision (180) Display	Displays the HART revision. Here: 6
Descriptor (139) Entry	Enter the tag description (max. 16 alphanumeric characters).
HART message (140) Entry	Enter a message (max. 32 alphanumeric characters). This message is sent via the HART protocol at the request of the master.

Parameter name	Description
HART date (141) Entry	Enter the date of the last change in configuration. Factory setting: DD/MM/YY (date of the final test)

Expert → Communication → HART output

Parameter name	Description
Primary value is (147) Display	Indicates which measured variable is transmitted as the primary process value via the HART protocol. The variable displayed depends on the "measuring mode" selected: – "Pressure" measuring mode: "Meas. pressure" – "Level" measuring mode, "Linear" lin. mode: "Level before lin." – "Level" measuring mode, "Activate table" lin. mode: "Tank content"
Primary value (148) Display	Displays the primary process value. → See also "Primary value is"
Secondary val. is (149) Display	Secondary value. Displays the assignment. The following process values can be displayed depending on the measuring mode selected: – "Meas. pressure" – "Sensor pressure" – "Corrected press." – "Pressure af. damp" – "Sensor temp." – "Level before lin." – "Tank content" – "Flow" – Totalizer 1 – Totalizer 2
Secondary value (150) Display	Displays the secondary process value. → See also "Secondary val. is"
Third value is (151) Display	Third process value. Displays the assignment. → See also "Secondary val. is"
Third value (152) Display	Displays the third process value. → See also "Third val. is"
4th value is (153) Display	4th process value. Displays the assignment. → See also "Secondary val. is"
4th value (154) Display	Displays the 4th process value. → See also "4th value is"

Expert → Communication → HART input

Parameter name	Description
HART input value (155) Display	Displays the HART input value.
HART input stat. (179) Display	Displays the HART input status Bad / Uncertain / Good

Parameter name	Description
HART input unit (156) Selection	Select the HART input value. Options: <ul style="list-style-type: none"> ■ Unknown ■ mbar, bar ■ mmH2O, ftH2O, inH2O ■ Pa, hPa, kPa, MPa ■ psi ■ mmHg, inHg ■ Torr ■ g/cm², kg/cm² ■ lb/ft² ■ atm ■ °C, °F, K, R Factory setting: Unknown
HART input form. (157) Selection	Specify the format for displaying the HART input value. Options: <ul style="list-style-type: none"> ■ x.x (default) ■ x.xx ■ x.xxx ■ x.xxxx ■ x.xxxxx Factory setting: x.x

11.2.5 Application

Expert → Application (Cerabar M and Deltapilot M)

Parameter name	Description
Electr. delta P (158) Entry	For switching the electr. delta P application on or off with an external or constant value. Options: Off External value Constant Factory setting: Off
Fixed ext. value (174) Entry	Use this function to enter the constant value. The value refers to "HART input unit". Factory setting: 0.0

Expert → Application → Totalizer 1 (Deltabar M)



Note!

With the "Flow in %" flow type setting, the totalizer is not available and is not displayed at this position.

Parameter name	Description
Eng. unit totalizer 1 (058) (059) (060) (061) Selection	Select unit for totalizer 1. Options Depending on the setting in the "Flow meas. type" (044) parameter this parameter offers a list of volume, norm volume, standard volume and mass units. When a new volume or mass unit is selected, totalizer-specific parameters are converted and displayed with the new unit within a unit group. When the flow mode is change, the totalizer value is not converted. The Direct Access Code depends on the selection in the "Flow meas. type" (044) parameter: – (058): Flow. meas. type "Mass" – (059): Flow. meas. type "Volume norm. cond." – (060): Flow. meas. type "Volume std. cond." – (061): Flow. meas. type "Volume process cond." Factory setting: m ³
Totalizer 1 mode (175)	Define the behavior of the totalizer. Options: <ul style="list-style-type: none"> ■ Balanced: Integration of all measured flows (positive and negative) ■ Pos. flow only: only positive flows are integrated. ■ Neg. flow only: only negative flows are integrated. ■ Hold: No flow is integrated. The totalizer keeps its current value. Factory setting: Pos. flow only
Totalizer 1 failsafe (176)	Define the behavior of the totalizer in the case of an error. Options: <ul style="list-style-type: none"> ■ Run: Totalizing is continued. ■ Hold: The totalizer is stopped and keeps its current value.
Reset Totalizer 1 (062) Selection	You reset totalizer 1 to zero with this parameter. Selection: <ul style="list-style-type: none"> ■ Abort (do not reset) ■ Reset Factory setting: Abort
Totalizer 1 (063) Display	Displays the total flow value of totalizer 1. You can reset the value with the "Reset totalizer 1" (062) parameter. The "Totalizer 1 overflow" (064) parameter displays the overflow. Example: The value 123456789 m ³ is indicated as follows: – Totalizer 1: 3456789 m ³ – Totalizer 1 overflow: 12 E7 m ³
Totalizer 1 overflow (064) Display	Displays the overflow value of totalizer 1. → See also " Totalizer 1 " (063).

Expert → Application → Totalizer 2 (Deltabar M)



Note!

With the "Flow in %" flow type setting, the totalizer is not available and is not displayed at this position.

Parameter name	Description
Eng. unit totalizer 2 (065) (066) (067) (068) Selection	Select the unit for totalizer 2. → See also "Eng. unit totalizer 1". The Direct Access Code depends on the selection in the "Flow meas. type" (044) parameter: <ul style="list-style-type: none"> – (065): Flow. meas. type "Mass" – (066): Flow. meas. type "Gas norm. cond." – (067): Flow. meas. type "Gas. std. cond." – (068): Flow. meas. type "Volume process cond." Factory setting: m ³
Totalizer 2 mode (177)	Define the behavior of the totalizer. Options: <ul style="list-style-type: none"> ■ Balanced: Integration of all measured flows (positive and negative) ■ Pos. flow only: only positive flows are integrated. ■ Neg. flow only: only negative flows are integrated. ■ Hold: No flow is integrated. The totalizer keeps its current value. Factory setting: Pos. flow only
Totalizer 2 failsafe (178)	Define the behavior of the totalizer in the case of an error. Options: <ul style="list-style-type: none"> ■ Run: Totalizing is continued. ■ Hold: The totalizer is stopped and keeps its current value.
Totalizer 2 (069) Display	Displays the total flow value of totalizer 2. The "Totalizer 2 overflow" (070) parameter displays the overflow. See the example for "Totalizer 1"
Totalizer 2 overflow (070) Display	Displays the overflow value of totalizer 2. See the example for "Totalizer 1".

11.2.6 Diagnosis

Expert → Diagnosis

Parameter name	Description
Diagnostic code (071) Display	Displays the diagnostic message with the highest priority currently present.
Last diag. code (072) Display	Displays the last diagnostic message that occurred and was rectified. Note! <ul style="list-style-type: none"> ■ Digital communication: the last message is displayed. ■ The messages listed in the "Last diag. code" parameter can be deleted via the "Reset logbook" parameter.
Reset logbook (159) Selection	With this parameter, you reset all the messages of the "Last diag. code" parameter and the "Last diag. 1" to "Last diag. 10" event log. Options: <ul style="list-style-type: none"> ■ Abort ■ Confirm Factory setting: Abort
Min. meas. press. (073) Display	Displays the lowest pressure value measured (peakhold indicator). You can reset this indicator by means of the "Reset peakhold" parameter.
Max. meas. press. (074) Display	Displays the highest pressure value measured (peakhold indicator). You can reset this indicator by means of the "Reset peakhold" parameter.

Parameter name	Description
Reset peakhold (161) Selection	You can reset the "Min. meas. press." and "Max. meas. press." indicators with this parameter. Options: <ul style="list-style-type: none"> ■ Abort ■ Confirm Factory setting: Abort
Operating hours (162) Display	Displays the hours of operation. This parameter cannot be reset.
Config. counter (100) Display	Displays the configuration counter. This counter is increased by one every time a parameter or group is changed. The counter counts up to 65535 and then starts again at zero.

Expert → Diagnosis → Diagnostic list

Parameter name	Description
Diagnostic 1 (075) Diagnostic 2 (076) Diagnostic 3 (077) Diagnostic 4 (078) Diagnostic 5 (079) Diagnostic 6 (080) Diagnostic 7 (081) Diagnostic 8 (082) Diagnostic 9 (083) Diagnostic 10 (084)	These parameters contain up to ten diagnosis messages that are currently pending, arranged in order of priority.

Expert → Diagnosis → Event logbook

Parameter name	Description
Last diag. 1 (085) Last diag. 2 (086) Last diag. 3 (087) Last diag. 4 (088) Last diag. 5 (089) Last diag. 6 (090) Last diag. 7 (091) Last diag. 8 (092) Last diag. 9 (093) Last diag. 10 (094)	These parameters contain the last 10 diagnosis messages to occur and be rectified. They can be reset with the "Reset logbook" parameter. Errors which have occurred multiple times are displayed once only.

Expert → Diagnosis → Simulation

Parameter name	Description
<p>Simulation mode (112) Selection</p>	<p>Switch on simulation and select the simulation mode. Any simulation running is switched off if the measuring mode or level type (Lin. mode (037)) is changed.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ None ■ Pressure, → see also this table, "Sim. pressure" parameter ■ Level, → see this table, "Sim. level" parameter ■ Flow, → see this table, "Sim. flow" parameter ■ Tank content, → see this table, "Sim. tank cont." parameter ■ Current, → see this table, "Sim. current" parameter ■ Alarm/warning, → see this table, "Sim. error no." parameter <p>Cerabar M and Deltapilot M:</p> <div style="border: 1px dashed black; padding: 5px; margin-bottom: 10px;"> <p style="text-align: center;">Transducer Block</p> <p style="text-align: right;">– Simulation value level – Simulation value tank content</p> <p style="text-align: right; font-size: small;">P01-xxxxxxx-05-xx-xx-en-015</p> </div> <p>Deltabar M:</p> <div style="border: 1px dashed black; padding: 5px;"> <p style="text-align: center;">Transducer Block</p> <p style="text-align: right;">– Simulation value level – Simulation value tank content</p> <p style="text-align: right; font-size: small;">P01-FMD55xxx-05-xx-xx-en-007</p> </div> <p>Factory setting: None</p>
<p>Sim. pressure (113) Entry</p>	<p>Enter the simulation value. → See also "Simulation mode".</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ "Simulation mode" = Pressure <p>Switch on value: Current pressure measured value</p>
<p>Sim. flow (114) Entry</p>	<p>Enter the simulation value. → See also "Simulation mode (112)".</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ "Meas. mode" = Flow and "Simulation Mode" = Flow
<p>Sim. level (115) Entry</p>	<p>Enter the simulation value. → See also "Simulation mode".</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ "Measuring mode" = Level and "Simulation mode" = Level

Parameter name	Description
Sim. tank cont. (116) Entry	Enter the simulation value. → See also "Simulation mode". Prerequisites: <ul style="list-style-type: none"> ■ "Measuring mode" = Level, "Activate table" lin. mode and "Simulation mode" = Tank content.
Sim. current (117) Entry	Enter the simulation value. → See also "Simulation mode". Prerequisite: <ul style="list-style-type: none"> ■ "Simulation mode"= Current value Factory setting: Current value of the current
Sim. error no. (118) Entry	Enter the diagnostic message number. → See also "Simulation mode". Prerequisite: <ul style="list-style-type: none"> ■ "Simulation mode"= Alarm/warning Switch on value: 484 (simulation active)

Index

C

- Cable specification 34
- Commubox FXA195 anschließen 35

D

- Diaphragm seals, installation instructions 14
- Diaphragm seals, vacuum application 14
- Differential pressure measurement 77
- Differential pressure measurement, installation 23
- Differential pressure measurement, preparatory steps 77
- Differential pressure measurement, Setup menu 78
- Display 43

E

- Electrical connection 32
- Error messages 95

F

- Factory setting 50
- FieldCare 48
- Flow measurement 79
- Flow measurement, installation 19
- Flow measurement, Quick Setup menu 81
- Flow measurement, preparatory steps 80

G

- General structure of the operating menu 41

H

- Hazardous area 4

I

- Incoming acceptance 10
- Installation instructions 26
- Installation instructions for devices with diaphragm seals - PMP55 14
- Installation instructions for devices without diaphragm seals - PMP51, PMC51 11

K

- Keys, local, function 40, 45
- Keys, local, level measuring mode 55
- Keys, local, pressure measuring mode 54

L

- Language, selection 57
- Level measurement 59, 85
- Level measurement, installation 21
- Level measurement, preparatory steps 82
- Linearization 69
- Local display 43
- Locking operation 40, 49

M

- Measuring arrangement for level measurement 13
- Measuring arrangement for pressure measurement ... 12–13
- Measuring layout for flow measurement 20

- Measuring layout for level measurement 21
- Measuring layout for pressure measurement 23
- Measuring mode, selection 57
- Mounting, mounting clamp 28

N

- Nameplate 6

O

- Operating elements, function 40, 45
- Operating elements, position 39
- Operating keys, on-site, Flow measuring mode 56
- Operating keys, position 39
- Overvoltage protection 36

P

- Pipe mounting 16, 24, 29
- Position adjustment 58
- Potential equalization 35
- Pressure measurement, Setup menu 78
- Pressure measuring mode 78

R

- Repair 98
- Repair of Ex-certified devices 98
- Reset 50
- Returning devices 98

S

- Scope of delivery 9
- Separate housing, assembly and mounting 17, 30
- Setup menu flow 81
- Setup menu pressure 78
- Shielding 35
- SIL 4
- Software history 99
- Spare Parts 98
- Storage 10
- Supply voltage 34

T

- Temperature isolator, installation instructions 15

U

- Unlocking operation 40, 49

W

- Wall and pipe-mounting 24
- Wall mounting 16, 29
- Welding recommendation 18

www.endress.com/worldwide

Endress+Hauser 
People for Process Automation

