

# **393/393 FC**

## **CAT III 1500V TRMS Clamp Meter**

### **Users Manual**

July 2021

© 2021 Fluke Corporation. All rights reserved.

Specifications are subject to change without notice.

All product names are trademarks of their respective companies.

## **LIMITED WARRANTY AND LIMITATION OF LIABILITY**

Each Fluke product is warranted to be free from defects in material and workmanship under normal use and service. The warranty period is three years and begins on the date of shipment. Parts, product repairs, and services are warranted for 90 days. This warranty extends only to the original buyer or end-user customer of a Fluke authorized reseller, and does not apply to fuses, disposable batteries, or to any product which, in Fluke's opinion, has been misused, altered, neglected, contaminated, or damaged by accident or abnormal conditions of operation or handling. Fluke warrants that software will operate substantially in accordance with its functional specifications for 90 days and that it has been properly recorded on non-defective media. Fluke does not warrant that software will be error free or operate without interruption.

Fluke authorized resellers shall extend this warranty on new and unused products to end-user customers only but have no authority to extend a greater or different warranty on behalf of Fluke. Warranty support is available only if product is purchased through a Fluke authorized sales outlet or Buyer has paid the applicable international price. Fluke reserves the right to invoice Buyer for importation costs of repair/replacement parts when product purchased in one country is submitted for repair in another country.

Fluke's warranty obligation is limited, at Fluke's option, to refund of the purchase price, free of charge repair, or replacement of a defective product which is returned to a Fluke authorized service center within the warranty period.

To obtain warranty service, contact your nearest Fluke authorized service center to obtain return authorization information, then send the product to that service center, with a description of the difficulty, postage and insurance prepaid (FOB Destination). Fluke assumes no risk for damage in transit. Following warranty repair, the product will be returned to Buyer, transportation prepaid (FOB Destination). If Fluke determines that failure was caused by neglect, misuse, contamination, alteration, accident, or abnormal condition of operation or handling, including overvoltage failures caused by use outside the product's specified rating, or normal wear and tear of mechanical components, Fluke will provide an estimate of repair costs and obtain authorization before commencing the work. Following repair, the product will be returned to the Buyer transportation prepaid and the Buyer will be billed for the repair and return transportation charges (FOB Shipping Point).

THIS WARRANTY IS BUYER'S SOLE AND EXCLUSIVE REMEDY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. FLUKE SHALL NOT BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OR LOSSES, INCLUDING LOSS OF DATA, ARISING FROM ANY CAUSE OR THEORY.

Since some countries or states do not allow limitation of the term of an implied warranty, or exclusion or limitation of incidental or consequential damages, the limitations and exclusions of this warranty may not apply to every buyer. If any provision of this Warranty is held invalid or unenforceable by a court or other decision-maker of competent jurisdiction, such holding will not affect the validity or enforceability of any other provision.

Fluke Corporation  
P.O. Box 9090  
Everett, WA 98206-9090  
U.S.A.

Fluke Europe B. V.  
P.O. Box 1186  
5602 BD Eindhoven  
The Netherlands

# Table of Contents

Title	Page
Introduction .....	1
Contact Fluke .....	1
Safety .....	2
Before You Start .....	2
Fluke Connect™ (393 FC).....	2
Radio Frequency Data.....	3
Fluke Connect™ Mobile App.....	3
Battery .....	4
Features/Controls .....	5
Display .....	6
Power .....	7
Auto Power Off .....	7
Backlight .....	7
Power-On Options .....	7
Basic Measurements .....	9
Hazardous Voltage Indicator .....	9
AC Voltage Measurement with Test Leads .....	9
DC Voltage Measurement with Test Leads .....	9
Resistance/Continuity .....	10
Capacitance.....	10
Amps DC .....	11
Power DC .....	11
Amps AC .....	12
Amps AC Measurement with Jaw.....	12
Amps AC Measurement with iFlex Probe.....	12
Measurement Features .....	14
Display Hold .....	14
Auto Hold.....	14
Min/Max/Avg Measurements .....	15
Inrush Current/Peak Current .....	16
Data Logging (393 FC).....	16
Clear Memory (393 FC).....	16
Firmware Update (393 FC).....	16
Firmware Version .....	17

Maintenance ..... 17

    How to Clean the Case ..... 17

    Environmental ..... 17

    Service ..... 18

Specifications ..... 18

    General..... 18

    Electrical ..... 18

    Mechanical ..... 21

    Environmental ..... 22

## Introduction

The Fluke 393/393 FC CAT III 1500V TRMS Clamp Meter (the Product or Clamp) measures:

- true-rms ac current (up to 1000 Aac with jaw measurement) and voltage (up to 1000 Vac)
- dc current (up to 1000 Adc) and voltage (up to 1500 Vdc)
- dc power
- inrush/peak current
- resistance and continuity
- capacitance
- frequency
- dc millivolts

The detachable iFlex (Flexible Current Probe) expands the measurement range to 2500 Aac. The iFlex provides increased display flexibility and allows measurements of awkward-sized conductors and improved wire access. The illustrations in this manual show the 393 FC.

The Clamp includes these features:

- Audio Polarity indicator
- Visual Continuity
- Reporting/data logging with Fluke Connect™ (393 FC)

## Contact Fluke

Fluke Corporation operates worldwide. For local contact information, go to our website:

[www.fluke.com](http://www.fluke.com).

To register your product, view, print, or download the latest manual or manual supplement, go to our website.

Fluke Corporation  
P.O. Box 9090  
Everett, WA 98206-9090  
+1-425-446-5500

[fluke-info@fluke.com](mailto:fluke-info@fluke.com)

Safety


General Safety Information is in the printed Safety Information document that ships with the Product and at [www.fluke.com](http://www.fluke.com). More specific safety information is listed where applicable.

A **Warning** identifies conditions and procedures that are dangerous to the user. A **Caution** identifies conditions and procedures that can cause damage to the Product or the equipment under test.

Before You Start

Table 1 is a list of the items included with the Product.

Table 1. Standard Equipment

		
Item	Model Number	Description
1	varies	Clamp Meter
2	TL1500DC	1500 V Test Lead Set
3	i2500-18 iFlex	Flexible Current Probe 18 in (46 cm)
4	TPAK80-4-8001	Strap 9 in (23 cm)
5	TPAK80-4-2002C	Magnet
6	37x	Carry Case
not shown		Safety Information

Fluke Connect™ (393 FC)

Fluke Connect™ software (may not be available in all regions) supports the Clamp to wirelessly connect your Clamp with a mobile app. The app shows the measurements and other data on your smartphone or tablet display. You can share this data with your team and save collected measurements and calculations to the Fluke Connect Cloud.

Fluke Connect uses low-power wireless radio technology to connect the Clamp with an app on your smartphone or tablet. The wireless radio does not cause interference with Clamp measurements.

## Radio Frequency Data

### Note



*Changes or modifications to the wireless 2.4 GHz radio not expressly approved by Fluke Corporation could void the user's authority to operate the equipment.*

For complete information about radio frequency data, go to [www.fluke.com/manuals](http://www.fluke.com/manuals) and search for "Radio Frequency Data Class A".

## Fluke Connect™ Mobile App

The Fluke Connect™ app works with Apple and Android mobile products. The app is available for download to your smart device from the Apple App Store and Google Play.

To use the Fluke Connect app:

1. Open the FlukeConnect app on your device.
2. Turn on the Clamp.
3. Push  to activate the radio on the Clamp.  shows on the display.
4. On your smartphone, go to **Settings > Bluetooth**.
5. Verify that Bluetooth is turned on.
6. Go to the Fluke Connect App and in the list of connected Fluke tools, select **393 FC**.

You can now take, save, and share measurements with the app. Go to [www.flukeconnect.com](http://www.flukeconnect.com) for more information about how to use the app.

## Battery

### Warning

To prevent personal injury and for safe operation of the Product:

- The battery door must be closed and locked before you operate the Product.
- Remove all probes, test leads, and accessories before the battery door is opened.
- Replace the batteries when the low battery indicator shows to prevent incorrect measurements.
- When batteries are changed, ensure that the calibration seal in the battery compartment is not damaged. If damaged, the Product may not be safe to use. Return the Product to Fluke for replacement of the seal.


### Caution

To prevent damage to the battery:

- Repair the Product before use if the battery leaks.
- Do not expose battery to heat sources or high-temperature environments such as an unattended vehicle in the sun.
- Always operate in the specified temperature range.
- Do not incinerate the Product and/or battery.

The Product ships with the batteries installed. To replace batteries, see [Figure 1](#).

Figure 1. Battery Replacement







## Features/Controls

Table 2 is a list of features and controls.


**Table 2. Feature/Control Descriptions**

	Item	Description
	1	Jaw
	2	Tactile Barrier
	3	Control Knob
	4	Hold Push >2 s to enable/disable the Auto Hold mode.
	5	Display
	6	Extends the function selection to yellow items on the control knob. Push >2 s to turn on/turn off the backlight.
	7	Min/Max/Avg for dc power, current, voltage, resistance, capacitance, and frequency measurement functions.
	8	INRUSH: push to enter inrush mode. Push a second time to exit inrush mode. Integration time is 100 ms. Push >2 s to enable/disable data logging function.
	9	Turn on the Fluke Connect feature.  turns blue and flashes when paired with the Fluke Connect mobile phone app. When on, push to save a measurement to the Fluke Connect mobile app. Push >2 s to turn off the Fluke Connect feature.
	10	Trigger
	11	Common terminal
	12	Volts/Ohm input terminal
	13	iFlex Current Probe (R-coil) connection

## Display

Table 3 is a list of the display annunciators.

Table 3. Display

 <p>The diagram shows the display of the 393/393 FC multimeter. Numbered callouts point to the following features:</p> <ul style="list-style-type: none"> <li>1: Jaw measurement icon</li> <li>2: iFlex measurement icon</li> <li>3: Fluke Connect icon</li> <li>4: Remaining memory icon (393 FC)</li> <li>5: Inrush measurement icon</li> <li>6: Log mode icon (393 FC)</li> <li>7: Hold mode icon</li> <li>8: MinMax mode icon</li> <li>9: Auto Hold mode icon</li> <li>10: Battery status icon</li> <li>11: Min, Max, or Avg measurement indication</li> <li>12: Zero indication</li> <li>13: Continuity indication</li> <li>14: AC or DC measurement</li> <li>15: Unit of measurement for voltage, current, dc power, and resistance/capacitance measurement</li> <li>16: Unit of measurement for frequency and current measurement</li> <li>17: Peak value of inrush measurement</li> <li>18: Clamp senses a voltage &gt;30 V or a voltage overload (OL)</li> <li>19: Polarity indication</li> </ul>			
Item	Description	Item	Description
1	Jaw measurement	11	Min, Max, or Avg measurement indication
2	iFlex measurement	12	Zero indication
3	Fluke Connect feature is on	13	Continuity indication
4	Remaining memory (393 FC)	14	AC or DC measurement
5	Inrush measurement	15	Unit of measurement for voltage, current, dc power, and resistance/capacitance measurement
6	Log mode is active (393 FC)	16	Unit of measurement for frequency and current measurement
7	Hold mode is active	17	Peak value of inrush measurement
8	MinMax mode is active	18	Clamp senses a voltage >30 V or a voltage overload (OL)
9	Auto Hold mode is active	19	Polarity indication
10	Battery status		

## Power

Two AA batteries supply power to the Clamp:

- To turn on the Clamp, rotate the control knob from **OFF** to a function.
- To turn off the Clamp, rotate the control knob to **OFF**.

## Auto Power Off

The Clamp automatically powers off after 20 minutes of no use. If the Clamp automatically powers off, turn the control knob to OFF and then to a function to resume operation.



To disable auto power off, see [Power-On Options](#).

### Note

*Auto power off is always disabled when you use the Min/Max/Avg, Auto Hold, Fluke Connect, and Data Logging functions.*

## Backlight

The display on the Clamp includes a backlight that improves the readability in dim work areas.

- 393: Push  to toggle on/toggle off the backlight.
- 393 FC: Push  >2 s to toggle on/toggle off the backlight.

The backlight has an auto off feature that turns off the backlight after 2 minutes of no use. To disable the auto off backlight feature, see [Power-On Options](#).

## Power-On Options










Power-on options allow you to customize the controls:

- Disable Auto Power Off
- Disable Auto Backlight Off
- View firmware version and light all LCD segments
- Erase Logging Memory
- Disable Beeper

To select a power-on option:

1. Turn off the Clamp.
2. See [Table 4](#) for option and button sequence.

**Table 4. Power-On Options**

Option	Button Sequence
Disable Auto Power Off	Hold down  as you turn ON Clamp (rotate control knob) and push  for <1 s. Display shows <b>PoFF</b> .
Disable Auto Backlight Off	Hold down  as you turn ON Clamp (rotate control knob) and push  . Display shows <b>LoFF</b> .
View firmware version and light all LCD segments	Any button + ON (rotate control knob)
Erase Logging Memory	Hold down  as you turn ON Clamp (rotate control knob) and push  . Display shows <b>clr?</b> . Push  again. Display shows <b>ErAS</b> . Display shows <b>done</b> when erase is complete.
Disable Beeper	Hold down  as you turn ON Clamp (rotate control knob) and hold  for >1 s. Display shows <b>bEEP</b> .


## Basic Measurements

### Warning

To prevent possible electrical shock, fire, or personal injury:


- Hold the Product behind the tactile barrier.
- Do not measure current while the test leads are in the input jacks.

### Hazardous Voltage Indicator

When the Clamp senses a voltage more than  $\pm 30$  V or a voltage overload (OL),  shows on the display to tell you a hazardous voltage is at the Clamp input.

### AC Voltage Measurement with Test Leads


To measure ac voltage and the frequency:

1. Turn control knob to .
2. Connect the black test lead to the **COM** terminal and the red test lead to the **V $\Omega$**  terminal.
3. Touch the probes to the test points of the circuit.


The display shows the ac voltage and the frequency.

### DC Voltage Measurement with Test Leads

To measure dc voltage:

1. Turn control knob to .
2. Connect the black test lead to the **COM** terminal and the red test lead to the **V $\Omega$**  terminal.
3. Touch the probes to the test points of the circuit.

The display shows the measurement.

4. Push  to toggle on/toggle off the mV function shown in yellow at the control knob position.

The Clamp checks the polarity during a dc voltage measurement. When dc voltage is less than -10 V:

1. Red LEDs blink and continue for 10 s.
2. Beeper sounds and continues for 10 s.
3. **POLARITY** blinks on the display.

## Resistance/Continuity

To measure resistance or continuity:

1. Turn the control knob to  $\Omega$ .
2. Remove power from the circuit to test.
3. Connect the black test lead to the COM terminal and the red test lead to the **V $\Omega$**  terminal.
4. Touch the probes to the test points of the circuit.

The display shows the value.

If the resistance is  $<30 \Omega$ , the beeper sounds continuously to indicate continuity and the green LEDs blink. If the display shows **OL**, the circuit is open.


## Capacitance

The Clamp determines capacitance by charging a capacitor with a known current, measuring the resulting voltage, then calculating the capacitance.

### Note

*A good capacitor stores an electrical charge and may remain energized after power is removed. Before you touch the capacitor or make a measurement, turn all power OFF, use the Clamp to confirm that power is OFF, and carefully discharge the capacitor by connecting a resistor across the leads. Be sure to wear appropriate personal protective equipment.*

To measure capacitance:


1. Turn the control knob to  $\Omega$ .
2. Push  to shift to the  $\leftarrow$  function.
3. Remove the capacitor from the circuit and discharge the capacitor.
4. Connect the black test lead to the **COM** terminal and the red test lead to the **V $\Omega$**  terminal.
5. Touch the probes to the capacitor leads.

The display shows the measurement.

**OL** indicates the capacitor is faulty or the capacitance value is higher than the measurement range. **dsc** indicates the capacitor does not properly discharge.

## Amps DC


To measure dc current:

1. Turn control knob to  $\overline{\overline{A}}$ .
2. Push  to compensate (zero) for outside influences.
3. Position the Clamp jaw around the conductor.

The display shows the value and  $\overline{A}$  to indicate that the measurement is from the jaw. When the current measurement is  $<0.5\text{ A}$ , the center dot in the icon flashes. For current measurements  $>0.5\text{ A}$ , the center dot in the icon is steady.

## Power DC


To measure dc power:

1. Turn control knob to  $\overline{\overline{A}}$ .
2. Push  to compensate (zero) for outside influences.
3. Turn control knob to  $\overline{\overline{VA}}$ .
4. Position the Clamp jaw around the conductor.
5. Connect the black test lead to the **COM** terminal and the red test lead to the **V $\Omega$**  terminal.
6. Touch the probes to the test points of the circuit.

The display shows the measurement of dc power and dc current.

The display also shows  $\overline{A}$  to indicate that the measurement is from the jaw.

### *Note*

Push  to toggle the readout between dc power and dc voltage.


## Amps AC


### Warning

**To prevent electrical shock, do not apply or remove from live hazardous conductors.**

### Amps AC Measurement with Jaw

To measure amps ac:

1. Turn control knob to .
2. Position the Clamp jaw around the conductor.

The display shows the amps ac measurement and frequency and also shows  to indicate that the measurement is from the jaw.

### Amps AC Measurement with iFlex Probe



The high-performance AC Flexible Current Probe uses the Rogowski principle for accurate, non-intrusive measurement of sinusoidal, pulsed, and other complex waveforms. The flexible and lightweight measuring head allows quick and easy installation in hard-to-reach areas and works well with large conductors.


To use the iFlex Probe:

1. Connect the iFlex Probe to the Clamp. See [Figure 2](#).
2. Connect the flexible part of the iFlex Probe around the conductor. If you open the end of the iFlex Probe to make the connection, make sure that you close and latch the coupling. See the detail in [Figure 2](#). You should be able to hear and feel the lock snap into place.

#### Note

*When you measure current, center the conductor in the iFlex Probe. Avoid measurements close to other current-carrying conductors.*

3. Keep the probe coupling >2.5 cm (1 inch) away from the conductor.
4. Turn the control knob to .
5. Push .

The display shows  to indicate that the measurements are from the iFlex Probe. When the current measurement is <0.5 A, the center dot in the icon flashes. For current measurements >0.5 A, the center dot is steady.


The display shows the measurement.



If the iFlex Probe does not work as expected:

- Make sure that the coupling system is connected and closed correctly or look for any damage. If any foreign material is present, the coupling system will not close properly.
- Inspect the cable between the iFlex Probe and the Clamp for any damage.
- Check that the control knob is in the correct position  $\text{iFlex} \begin{matrix} \text{A} \\ \text{A} \end{matrix}$ .

**Figure 2. Flex Probe Setup**



## Measurement Features


This section is about the Clamp features you can use for measurements.

### Warning

To prevent possible electrical shock, fire, or personal injury:

- Do not use the HOLD function to measure unknown potentials. When HOLD is turned on, the display does not change when a different potential is measured.
- Disconnect power and discharge all highvoltage capacitors before you measure resistance, continuity, capacitance, or a diode junction.

### Display Hold

To capture and hold the display reading, push **HOLD**. The display freezes the readings and **HOLD**. The Product periodically beeps to remind you that the measurement is not live. When in HOLD mode, if the Product senses a voltage more than  $\pm 30$  V or a voltage overload (OL),  shows on the display to tell you a hazardous voltage is at the Product input.


When in HOLD mode, push **HOLD** again to resume normal operation with live readings.

### Auto Hold

To capture and hold the display reading automatically:

1. Push **HOLD** >2 s to enable Auto Hold mode.

**AUTO** shows on the display to indicate that Auto Mode is enabled. The display will freeze and blink **HOLD** automatically.

When in Auto Hold mode, the Clamp periodically beeps to remind you that the measurement is not live. If the Clamp senses a voltage more than  $\pm 30$  V or a voltage overload (OL),  shows on the display to tell you a hazardous voltage is at the Clamp input.

When Auto Hold is enabled, the main reading will trigger the hold mode, and the second reading will not display. **HOLD** stops blinking until the main reading triggers the hold mode.

The display updates when the measured value:

- exceeds the threshold value (voltage, capacitance, current, dc power)
- is less than the threshold value (Ohm) and stabilizes within the fluctuation range/delta value.


See [Table 5](#).

**Table 5. Auto Hold Functions**

Function	Threshold	Fluctuation Range/Delta
V ac	10 V	2 V
V dc	10 V	2 V
mV dc	20 mV	5 mV
Ohm	60 kΩ	2.0 Ω/20 Ω/0.20 kΩ
Capacitance	10 μF	2 μF
A dc	10 A	2 A
A ac	10 A for Clamp/25 A for iFlex	2 A for Clamp/5 A for iFlex
dc Power	10.0 kVA	2.0 kVA

- When in Auto Hold mode, push **HOLD** >2 s again to exit the Auto Hold mode.

*Note*

*Auto Power Off is always disabled when you use the Auto Hold function. When Auto Hold is enabled on VA, push  to disable it automatically. Auto hold is disabled when Inrush Current/Peak Current or Min/Max/Ave is enabled.*

## Min/Max/Avg Measurements

Min/Max/Avg mode captures the minimum, maximum, and average readings of a given output signal over an extended time. The Clamp beeps when it senses a new high value or new low value. It applies for both reading except for Inrush Current/Peak Current. Push **HOLD** to pause the reading update (recording continues).

This function works in current, voltage, and frequency modes:

- Push **MIN MAX** to enter the Min/Max/Avg mode.  
The maximum reading shows on the display.
- Continue to push **MIN MAX** to select between the maximum, minimum, average, and live readings.  
The cycle continues each time you push **MIN MAX**.
- To exit Min/Max/Avg mode, push and hold **MIN MAX** for >2 s.


*Note*

*The Min/Max/Avg function does not support Auto Hold and Inrush Current/Peak Current. Auto Power Off is always disabled when you use the Min/Max/Avg, Auto Hold, and Logging functions or Fluke Connect is active.*

## Inrush Current/Peak Current

Inrush Current is surge current that occurs when an electrical device is first powered on. The Clamp can capture this surge current reading. Current spikes from motor drives are one example of such an event. The Inrush function takes samples over a 100 ms period and calculates the starting current envelope.

To measure inrush current:

1. Select the measurement function (ac current, dc current, or iFlex ac current).
2. Center the Jaw or iFlex Probe around the live wire on the device.
3. Push .

Dashes show on the display until the Clamp detects the inrush current. When the inrush current is detected, the measurement and the peak value show simultaneously on the display.



## Data Logging (393 FC)

The Fluke Connect™ app enables you to log the data measurements. This app shows measurements from the connected Clamp on your smartphone or tablet display. The app also saves the measurements in the Product internal memory and to the Fluke Connect Cloud™ storage. With Fluke Connect Cloud storage you can easily share the information with your team.

### Note

*The logging interval is set in the Fluke Connect app. Logging is not available for the inrush mode.*

To log measurements:

1. On the Clamp, push  for >2 s.  
The memory icon indicates how much memory is available.
2. On the Clamp, push  for >2 s to stop logging.

## Clear Memory (393 FC)

See [Power-On Options](#).

## Firmware Update (393 FC)

Firmware updates are available for Clamps that have the Fluke Connect™ feature. The Fluke Connect mobile app shows a notification if a firmware update is available when the unit is connected to the app.

To update:

1. Make sure the Product has at least 50 % battery power available.
2. Make sure you download all the logged data before you update the firmware.
3. In the app, tap **Update** to start the firmware update to the Product.

## Firmware Version

To find the firmware version for the Clamp, see [Power-On Options](#).

## Maintenance

The Product does not require routine maintenance.

### Warning

To prevent possible electrical shock, fire, or personal injury:

- Remove the input signals before you clean the Product.
- Repair the Product before use if the battery leaks. Battery leakage may create a shock hazard or damage the Product.
- Use only specified replacement parts.
- Have an approved technician repair the Product.
- Remove the batteries if the Product is not used for an extended period of time, or if stored in temperatures above 50 °C. If the batteries are not removed, battery leakage may result.

## How to Clean the Case

Wipe the case with a damp cloth and mild detergent.

### Caution

**Do not use abrasives, isopropyl alcohol, or solvents to clean the case or lens/window.**

## Environmental

This Product has electronic printed circuit boards. These components must be disposed of specifically when the Product is at the end of its use. The manufacturer offers to take back the Product from the customer to ensure that the Product is disposed of in an environmentally-friendly manner when it is at the end of its use.

See [Contact Fluke](#) for more information.

## Service

An authorized Fluke Calibration service center should service the Product at two-year intervals to maintain optimum performance. Contact your equipment distributor or authorized Fluke Calibration Service Center for any equipment performance failure or to schedule regular maintenance service. See [Contact Fluke](#) for more information.

Table 6 is a list of the available replacement parts.

**Table 6. Replacement Parts**

Item	Quantity	Fluke Part Number
Battery, AA 1.5 V	2	376756
Battery Door Assembly	1	5266613
TL1500DC Test Lead Set	1	5292172
Flexible Current Probe i2500-10	1	3676410
Flexible Current Probe i2500-18	1	3798105
Magnet Strap	1	4329190
Strap, 9-inch	1	669960
Carry Case	1	5211830

## Specifications

### General

Maximum voltage between any Terminal and Earth Ground

AC..... 1000 V

DC ..... 1500 V

Batteries ..... 2 AA IEC LR6 alkaline

Display..... Dual display with backlight

Automatic Power Off..... 20 minutes

### Electrical

#### Accuracy

Accuracy is specified for 1 year after calibration, at operating temperatures of 18 °C to 28 °C, relative humidity at 0 % to 75 %. Accuracy specifications take the form of:  $\pm$ ([% of Reading] + [Number of Least Significant Digits]).

Temperature Coefficients ..... Add 0.1 x specified accuracy for each °C >28 °C or <18 °C

#### AC Current: Jaw

Range..... 999.9 A

Resolution..... 0.1 A


Accuracy..... 2 % + 5 digits (10 Hz to 100 Hz)  
2.5 % + 5 digits (100 Hz to 500 Hz)

Crest Factor (50/60 Hz) ..... 2.5 @600.0 A  
3.0 @500.0 A  
1.42 @999.9 A  
Add 2 % for C.F. >2

### AC Current: Flexible Current Probe

Range .....	999.9 A 2500 A
Resolution .....	0.1 A ( $\leq 999.9$ A) 1 A ( $\leq 2500$ A)
Accuracy .....	3 % RD + 5 digits (10 Hz to 500 Hz)
Crest Factor (50/60Hz) .....	2.5 @1400 A 3.0 @1100 A 1.42@2500 A Add 2 % for C.F. >2

#### Position Sensitivity



### DC Current

Range .....	999.9 A
Resolution .....	0.1 A
Accuracy .....	2 % RD + 5 digits <sup>[1]</sup>

[1] When using the ZERO (   ) function to compensate for offsets.

### AC Voltage

Range .....	600.0 V 1000 V
Resolution .....	0.1 V ( $\leq 600.0$ V) 1 V ( $\leq 1000$ V)
Accuracy .....	1 % RD + 5 digits (20 Hz to 500 Hz)

### DC Voltage

Range .....	600.0 V 1500 V
Resolution .....	0.1 V ( $\leq 600.0$ V) 1 V ( $\leq 1500$ V)
Accuracy .....	1 % RD + 5 digits

### mV dc

Range .....	500.0 mV
Resolution .....	0.1 mV
Accuracy .....	1 % RD + 5 digits

### Amps Frequency: Jaw

Range .....	5.0 Hz to 500.0 Hz
Resolution .....	0.1 Hz
Accuracy .....	0.5 % RD + 5 digits
Trigger Level .....	5 Hz to 10 Hz, $\geq 10$ A 10 Hz to 100 Hz, $\geq 5$ A 100 Hz to 500 Hz, $\geq 10$ A

### Amps Frequency: Flexible Current Probe

Range .....	5.0 Hz to 500.0 Hz
Resolution .....	0.1 Hz
Accuracy .....	0.5 % RD + 5 digits
Trigger Level .....	5 Hz to 20 Hz, $\geq 25$ A 20 Hz to 100 Hz, $\geq 20$ A 100 Hz to 500 Hz, $\geq 25$ A

### Voltage Frequency

Range .....	5.0 Hz to 500.0 Hz
Resolution .....	0.1 Hz
Accuracy .....	0.5 % RD + 5 digits
Trigger Level .....	5 Hz to 20 Hz, $\geq 5$ V 20 Hz to 100 Hz, $\geq 5$ V 100 Hz to 500 Hz, $\geq 10$ V



### DC Power

Range .....	600.0 kVA (600.0 V dc range) 1500 kVA (1500 V dc range)
Resolution .....	0.1 kVA 1 kVA
Accuracy .....	2 % RD + 2.0 kVA 2 % RD + 20 kVA

### Resistance

Range .....	600.0 $\Omega$ 6000 $\Omega$ 60.00 k $\Omega$
Resolution .....	0.1 $\Omega$ ( $\leq 600.0 \Omega$ ) 1 $\Omega$ ( $\leq 6000 \Omega$ ) 0.01 k $\Omega$ ( $\leq 60.00 \text{ k}\Omega$ )
Accuracy .....	1 % RD + 5 digits

### Capacitance

Range .....	100.0 $\mu\text{F}$ 1000 $\mu\text{F}$
Resolution .....	0.1 $\mu\text{F}$ ( $\leq 100.0 \mu\text{F}$ ) 1 $\mu\text{F}$ ( $\leq 1000 \mu\text{F}$ )
Accuracy .....	1 % RD + 5 digits

### Inrush

Trigger Level .....	5 A
---------------------	-----

### Mechanical

Size (L x W x H) .....	281 mm x 84 mm x 49 mm
Weight (with batteries) .....	520 g
Jaw Opening .....	34 mm
Flexible Current Probe Diameter .....	7.5 mm
Flexible Current Probe Cable Length (head to electronics connector) .....	1.8 m

## Environmental

Operating Temperature .....	-10 °C to 50 °C
Storage Temperature .....	-40 °C to 60 °C
Operating Humidity .....	Non condensing (<10°C) ≤90 % RH (at 10 °C to 30 °C) ≤75 % RH (at 30 °C to 40 °C) ≤45 % RH (at 40 °C to 50 °C)
Operating Altitude .....	2000 m
Storage Altitude .....	12 000 m
Ingress Protection (IP) Rating .....	IEC 60529: IP54 non-operating
Electromagnetic Compatibility (EMC)	
International .....	IEC 61326-1: Portable, Electromagnetic Environment, IEC 61326-2-2 CISPR 11: Group 1, Class A <i>Group 1: Equipment has intentionally generated and/or uses conductively-coupled radio frequency energy that is necessary for the internal function of the equipment itself.</i> <i>Class A: Equipment is suitable for use in all establishments other than domestic and those directly connected to a low-voltage power supply network that supplies buildings used for domestic purposes. There may be potential difficulties in ensuring electromagnetic compatibility in other environments due to conducted and radiated disturbances.</i> <i>Caution: This equipment is not intended for use in residential environments and may not provide adequate protection to radio reception in such environments.</i>
Korea (KCC) .....	Class A equipment (Industrial Broadcast & Communications Equipment) <i>Class A: Equipment meets requirements for industrial electromagnetic wave equipment and the seller or user should take notice of it. This equipment is intended for use in business environments and not to be used in homes.</i>
USA (FCC) .....	47 CFR 15 subpart B. This product is considered an exempt device per clause 15.103.

## Safety

General .....	IEC 61010-1, Pollution Degree 2
Measurement .....	IEC 61010-2-032: CAT III 1500 V / CAT IV 600 V IEC 61010-2-033: CAT III 1500 V / CAT IV 600 V

## Wireless Radio

Radio frequency certification .....	FCC ID: T68-FBLE, IC: 6627A-FBLE
Wireless Radio Frequency Range .....	2400 MHz to 2483.5 MHz
Output Power .....	<100 mW

### SIMPLIFIED EU DECLARATION OF CONFORMITY

Hereby, Fluke declares that the radio equipment contained in this Product is in compliance with Directive 2014/53/EU.  
The full text of the EU declaration is available at the following Internet address:

[www.fluke.com/en-us/declaration-of-conformity](http://www.fluke.com/en-us/declaration-of-conformity)