

## GLOSSARY OF POWER TERMS

**Alternating current** — current that reverses its direction of flow periodically (Hz).

**Ampere** — a unit of measure for the rate of current flow.

**Apparent power** — applied voltage multiplied by current in an AC circuit. This value would not take the power factor into account. Unit is voltamperes (VA).

**Balanced load** — AC power system using more than two wires, where the current and voltage are of equal value in each energized conductor.

**Bandwidth** — the range of frequencies over which an instrument provides accurate measurement.

**Billing consumption** — total amount of energy consumed during a predetermined period (usually 28 to 33 days).

**Consumption** (active energy) — actual electrical energy used measured in kilowatthours (kWh) by the watthour meter, regardless of the power factor.

**Crest factor** — the ratio of the peak value of a waveform (voltage or current) to the RMS value.

**Current transformer** — an instrument accessory which detects current flow without breaking the circuit under test. An AC transformer, usually step-down; typical ratio listing would be 1000:1. This would indicate 1000A on the primary and 1A on the secondary.

**Current transformer ratio** — the ratio of primary amperes divided by secondary amperes.

**Delta connection** — a circuit formed by connecting three electrical devices in series to form a closed loop; most often used in three-phase connections.

**Demand** (active, real, or true power) — the power which is actually consumed by the load. This measurement takes the power factor into account.

**Demand interval** (integration period) — the period of time over which the energy is averaged. Typical demand intervals are 15, 30, or 60 minutes.

**Derating Factor** — a number defined as  $1.414 \times$  average RMS phase current/ peak phase current. This factor, when applied to the rated load of a transformer, gives an indication as to the percent loading that is reasonable when that transformer must service nonlinear loads.

**Displacement power factor** — the difference between apparent power and true power when only the phase relationship of voltage and current at the fundamental are taken into account.

**Distortion factor (%DF)** — Total harmonic Distortion referenced to the total RMS signal (THD-R).

**Distortion power factor** — the difference between apparent power and true power at all harmonic frequencies.

**Frequency** — the number of complete cycles of AC voltage which occurs during one second (Hz).

**Harmonics** — current or voltages which have frequencies that are integer multiples of the fundamental power frequency; common and sometimes dangerous in nonlinear loads.

**Heating effect** — temperature increase in electrical distribution equipment caused by an increase in RMS current.

**Impedance** — the total opposition to alternating current flow in an electrical circuit (Z).

**Inductive reactance** — the force which acts as a resistance in an inductor to limit the flow of current. This force creates a leading power factor in AC circuits.

**Initiator pulses** — electrical impulses generated from utility revenue meters. Each pulse indicates a specific number of watts consumed. These pulses are used within energy analyzers to measure energy consumption and demand.

**K factor** — a number based on the harmonic content of load current that determines the maximum safe loading on a power source.

**K-rated transformers** — a transformer that is rated or designed to serve as the source for a predefined capacity of harmonic current.

**Peak demand** (maximum RMS power) — the highest average load during a specified time interval (kW).

**Phase** — time relationship between current and voltage in AC circuits.

**Potential transformer** — an instrument transformer used to step down high voltage potentials to lower levels acceptable for the input of electrical test instruments.

**Power factor** — the ratio of true power (watts) to apparent power (voltamperes). Expressed in decimal form, e.g., .98.

**Ratchet demand** — determining the billing demand based upon a pre-established peak average demand (usually at 75%, 80%, or 100% of the pre-established peak).

**Reactance** — the opposition to current flow in an AC circuit introduced through inductance or capacitance.

**Reactive compensation power** — the reactive power to be applied to an AC network for power factor correction; adding capacitance in order to bring the voltage and current waveform in phase.

**Reactive power (kvar)** — power which is actually "borrowed" from the load and returned to the power source each cycle; unused power.

**Resolution** — the smallest unit value that an instrument can measure.

**Resonance** — when the inductance in the system and the natural capacitance of the system, or added capacitors, form a tuned circuit resonant at one or more of the harmonic frequencies produced by nonlinear loads.

**RS232** — a computer interface connector used to connect serial devices such as instruments for information transfer.

**Sensitivity** — the smallest input that will provide a specified output.

**Skin effect** — phenomenon in which high harmonic frequencies cause electrons to flow to the outer sides of a conductor, reducing its cross-sectional diameter, and hence its ampacity rating.

---

**Sliding demand** — calculating average demand by averaging the average demand over several successive time intervals, advancing one interval at a time.

**THD (%THD, Total Harmonic Distortion)** — the contribution of all harmonic frequency currents or voltages to the fundamental current or voltage, expressed as a percentage of the fundamental.

**THDF (Transformer Harmonic Derating Factor)** — method of calculating transformer derating established by CBEMA for phase-to-neutral loads.

**True RMS** — capability to accurately measure the value of AC voltage and current having a nonsinusoidal waveform as well as sinusoidal waveforms.

**Unbalanced load** — an AC power system using more than two wires, where the current is not equal in the current-carrying wires due to an uneven loading of the phases.

**Watt** — the measure of real power. It is the power expended when one ampere of direct current flows through a resistance of one ohm.

**Wye connection** — a connection of three components made in such a manner that one end of each component is connected; generally used to connect devices to a three-phase power system.