

PVA-1500 Recovery: 'Pairing Mode'

Pairing Steps:

1. Close Windows Application
2. Disconnect PC wifi.
3. Reset Both Solsensor(SS) and Measurement head(MH) [Unit with MC4 connectors]
4. Turn on MH (it should power on after reset and blink).
5. MH should blink "fast"
6. Press Green Button 4 times(quickly)
7. MH should blink "slow", allow MH to blink slow for about 10 seconds
8. On SS press button 5 times. This clears all pairing information, SS should blink
9. Press SS 3 times to start pairing mode
10. Both MH and SS should go solid after some time. Wait about 20 seconds after solid to allow pairing to be fully complete.
11. Reset both MH and and SS by holding the button down for 6 seconds. Allow MH to power up first. Then have SS power up.
12. Connect with PC,
13. restart windows application.
14. Wait till application shows "Ready" and the SS shows data. If no data after 1 min. Repeat Pairing process steps 1-14.