

777D Dual Directional Coupler

Operating Note

Manual part number: 00777-90004

Printed in USA March 2001

Supersedes: May 2000

Notice

The information contained in this document is subject to change without notice.

Agilent Technologies makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Agilent Technologies shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

Agilent Technologies assumes no responsibility for the use or reliability of its software on equipment that is not furnished by Agilent Technologies.

This document contains proprietary information which is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated to another language without prior written consent of Agilent Technologies.

RESTRICTED RIGHTS LEGEND

Use, duplication, or disclosure by the U.S. Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013 for DOD agencies, and subparagraphs (c)(1) and (c)(2) of the Commercial Computer Software Restricted Rights clause at FAR 52.227-19 for other agencies.

Agilent Technologies, Inc. 1400 Fountaingrove Parkway Santa Rosa, CA 95403-1799, U.S.A.

© Copyright 2000–2001 Agilent Technologies, Inc.

In This Manual...

- Overview, page 1
- **Specifications**, page 3
- **Inspection and Shipping**, page 4
- **Reflectometer Application**, page 5
- **Performance Tests**, page 6
- **Test Record**, page 16

Warranty

Custom systems are warranted by contractual agreement between Agilent Technologies and the customer.

Certification

Agilent Technologies, Inc., certifies that this product met its published specifications at the time of shipment from the factory. Agilent Technologies further certifies that its calibration measurements are traceable to the United States National Institute of Standards and Technology (NIST, formerly NBS), to the extent allowed by the Institute's calibration facility, and to the calibration facilities of other International Standards Organization members.

Warranty

This Agilent Technologies system product is warranted against defects in materials and workmanship for a period corresponding to the individual warranty periods of its component products. Instruments are warranted for a period of one year. During the warranty period, Agilent Technologies will, at its option, either repair or replace products that prove to be defective.

Warranty service for products installed by Agilent Technologies and certain other products designated by Agilent Technologies will be performed at Buyer's facility at no charge within Agilent Technologies service travel areas. Outside Agilent Technologies service travel areas, warranty service will be performed at Buyer's facility only upon Agilent Technologies' prior agreement and Buyer shall pay Agilent Technologies' round trip travel expenses. In all other areas, products must be returned to a service facility designated by Agilent Technologies.

For products returned to Agilent Technologies for warranty service, Buyer shall prepay shipping charges to Agilent Technologies and Agilent Technologies shall pay shipping charges to return the product to Buyer. However, Buyer shall pay all shipping charges, duties, and taxes for products returned to Agilent Technologies from another country.

Agilent Technologies warrants that its software and firmware designated by Agilent Technologies for use with an instrument will execute its programming instructions when properly installed on that instrument. Agilent Technologies does not warrant that the operation of the instrument, or software, or firmware will be uninterrupted or error free.

LIMITATION OF WARRANTY. The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by Buyer, Buyer-supplied software or interfacing, unauthorized modification or misuse, operation outside of the environmental specifications for the product, or improper site preparation or maintenance.

NO OTHER WARRANTY IS EXPRESSED OR IMPLIED. AGILENT TECHNOLOGIES SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTIES OR MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

EXCLUSIVE REMEDIES. THE REMEDIES PROVIDED HEREIN ARE BUYER'S SOLE AND EXCLUSIVE REMEDIES. AGILENT TECHNOLOGIES SHALL NOT BE LIABLE FOR ANY DIRECT. INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER BASED ON CONTRACT, TORT, OR ANY OTHER LEGAL THEORY.

YEAR 2000. Agilent Technologies warrants that each Agilent Technologies hardware, software, and firmware product on Agilent Technologies' Corporate Price List (dated July 1, 1998 or later) delivered under the product's contract of sale will be able to accurately process date data (including, but not limited to, calculating, comparing, and sequencing) from, into, and between the twentieth and twenty-first centuries, and the years 1999 and 2000, including leap year calculations, when used in accordance with the product documentation provided that all other products (that is, hardware, software, firmware) used in combination with such Agilent Technologies product(s) properly exchange date data with it. If the agreement requires that specific Agilent Technologies products must perform as a system in accordance with the foregoing warranty, then that warranty will apply to those Agilent Technologies products as a system, and Customer retains sole responsibility to ensure the year 2000 readiness of its information technology and business environment. The duration of this warranty extends through January 31, 2001.

The remedies available under this warranty will be defined in, and subject to, the terms and limitations of the warranties contained in the contract of sale. To the extent permitted by local law, this warranty applies only to branded Agilent Technologies products and not to products manufacture by others that may be sold or distributed by Agilent Technologies. Nothing in this warranty will be construed to limit any rights or remedies provided elsewhere in the contract of sale with respect to matters other than year 2000 compliance.

Assistance

Product maintenance agreements and other customer assistance agreements are available for Agilent Technologies products.

For assistance, call your local Agilent Technologies Sales and Service Office (refer to "Service and Support" on page vi).

Service and Support

By internet, phone, or fax, get assistance with all your test and measurement needs.

Online assistance: www.agilent.com/find/assist

United States Japan New Zealand Europe

(tel) 1 800 452 4844 (tel) (+81) 426 56 7832 (tel) 0 800 738 378 (tel) (+31) 20 547 2323

(fax) (+81) 426 56 7840 (fax) (+64) 4 495 8950 (fax) (+31) 20 547 2390

 Canada
 Latin America
 Australia

 (tel) 1 877 894 4414
 (tel) (305) 269 7500
 (tel) 1 800 629 485

 (fax) (905) 282 6495
 (fax) (305) 269 7599
 (fax) (+61) 3 9210 5947

Asia Call Center Numbers

Country	Phone Number	Fax Number
Singapore	1-800-375-8100	(65) 836-0252
Malaysia	1-800-828-848	1-800-801664
Philippines	(632) 8426802 1-800-16510170 (PLDT Subscriber Only)	(632) 8426809 1-800-16510288 (PLDT Subscriber Only)
Thailand	(088) 226-008 (outside Bangkok) (662) 661-3999 (within Bangkok)	(66) 1-661-3714
Hong Kong	800-930-871	(852) 2506 9233
Taiwan	0800-047-866	(886) 2 25456723
People's Republic of China	800-810-0189 (preferred) 10800-650-0021	10800-650-0121
India	1-600-11-2929	000-800-650-1101

Safety and Regulatory Information

Review this product and related documentation to familiarize yourself with safety markings and instructions before you operate the instrument. This product has been designed and tested in accordance with international standards.

WARNING

The WARNING notice denotes a hazard. It calls attention to a procedure, practice, or the like, that, if not correctly performed or adhered to, could result in personal injury. Do not proceed beyond a WARNING notice until the indicated conditions are fully understood and met.

CAUTION

The **CAUTION** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like, which, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a **CAUTION** notice until the indicated conditions are fully understood and met.

Instrument Markings

<u></u>	When you see this symbol on your instrument, you should refer to the instrument's instruction manual for important information.
7	This symbol indicates hazardous voltages.
	The laser radiation symbol is marked on products that have a laser output.
\sim	This symbol indicates that the instrument requires alternating current (ac) input.
Œ	The CE mark is a registered trademark of the European Community. If it is accompanied by a year, it indicates the year the design was proven.
(F)	The CSA mark is a registered trademark of the Canadian Standards Association.
1SM1-A	This text indicates that the instrument is an Industrial Scientific and Medical Group 1 Class A product (CISPER 11, Clause 4).
	This symbol indicates that the power line switch is ON.
ტ	This symbol indicates that the power line switch is OFF or in STANDBY position.

Safety Earth Ground



This is a Safety Class I product (provided with a protective earthing terminal). An uninterruptible safety earth ground must be provided from the main power source to the product input wiring terminals, power cord, or supplied power cord set. Whenever it is likely that the protection has been impaired, the product must be made inoperative and secured against any unintended operation.

Before Applying Power

Verify that the product is configured to match the available main power source as described in the input power configuration instructions in this manual. If this product is to be powered by autotransformer, make sure the common terminal is connected to the neutral (grounded) side of the ac power supply.

Overview

Description

The Agilent 777D is a dual directional coupler. It is designed for use in 50-ohm coaxial systems. In this coupler, coupling attenuation (ratio of output power from secondary arm to main line input) is specified as mean coupling. The mean coupling of each auxiliary arm is stamped on its nameplate opposite the appropriate auxiliary arm. The variation in coupling is within ± 0.4 dB of the mean, and the mean coupling is within ± 0.5 dB of -20 dB. In addition, the variation in ratio of the two auxiliary arm coupling factors is within 0.5 dB. Complete specifications are given in Table 1 on page 3.

Uses of the coupler include reflectometer measurements, simultaneous forward and reverse power monitoring, and closed loop leveling applications.

Mounting

Each coupler is supported by four plastic feet (part number 0361-0207). The feet are inserts in 8-32 tapped holes (1/4-in deep) and may be removed to mount the coupler. Lateral dimensions between mounting holes are given in Figure 1 on page 1.




Figure 1 Lateral Dimensions of Tapped Mounting Holes

Connectors

Type N connectors installed on 777D directional couplers with serial numbers 3088 and above are stainless steel for long wear and are compatible with connectors whose dimensions conform to MIL-C-39012 or MIL-C-71B (see Figure 2).




Figure 2 Type N Connector Dimensions

CAUTION

Do *not* mate with Type N male connectors with a pin diameter greater than 0.066 inches, as a discontinuity producing excess SWR will be formed and large diameter male pins may damage the female connector.

Agilent 777D directional couplers with serial numbers 3087 and below were equipped with Type N male connectors with center pin diameter greater than 0.070 inches. Many of these couplers have been modified with new connectors. However, check the dimensions of all male pins before mating Type N connectors.

Specifications

Specifications Table 1

Characteristic	Value
Frequency Range	1.9 to 4.0 GHz
Primary Line Insertion Loss	≤0.75 dB
Minimum Directivity ¹	30 dB
Nominal Coupling Attenuation (each secondary arm)	20 dB
Accuracy of Coupling (each secondary arm)	± 0.5 dB
Maximum Coupling Variation (each secondary coupling value)	± 0.4 dB
Auxiliary Arm Tracking ²	Equal to or less than 0.5 dB
Maximum Primary Line SWR ¹	1.2
Maximum Secondary Line SWR	1.3
Maximum Power Handling Capacity	50 W cw or 10 kW peak
Primary Line Connectors ³	Agilent compatible Type N connectors, one male and one female
Secondary Line Connectors ³	Agilent compatible Type N connectors, female
Accessories Available	Agilent 11511A Type N Female Shorting Jack Agilent 11512A Type N Male Shorting Plug
Dimension	8-7/8 in. x 2-1/2 in. x 1-1/8 in (225 mm x 64 mm x 29 mm)
Net Weight	1.5 lb (700 g)

^{1.} Measured with a sliding load.

^{2. 0.5} dB maximum change in coupling curve of one secondary arm relative to the other.

^{3.} Connectors mate with all connectors whose dimensions conform to MIL-C-71B or MIL-C-39012

Inspection and Shipping

Initial Inspection

Inspect the coupler for shipping damage as soon as it is unpacked. Check for broken connectors; inspect surfaces for dents and scratches. Check electrical performance using procedures in **Performance Tests** on page 6. If the coupler is damaged in any way, or fails to operate properly, notify the carrier and your nearest Agilent Technologies Sales and Service Office. In the event of mechanical damage, the packing material and carton should be held for carrier's inspection. For assistance of any kind, including instruments under warranty, contact the nearest Agilent Technologies Sales Office.

Repackaging for Shipment

The same type containers and materials used in factory packaging can be obtained through any Agilent Technologies office.

If the 777D is being returned to Agilent Technologies for servicing, attach a tag indicating the type of service required, return address, model number and full serial number. Also, mark the container *FRAGILE* to assure careful handling.

In any correspondence refer to the instrument by model number and full serial number.

Using Other Packaging

The following general instructions should be used when repackaging with commercially available materials:

- Wrap the 777D in heavy paper or plastic. (If shipping to an Agilent Technologies service office or center, attach a tag indicating the type of service required, the return address, model number and full serial number.)
- 2. Use a strong shipping container. A double-wall carton made of 350 pound test material is adequate.
- Use enough shock absorbing material (three to four inch layer) around all sides of the instrument to provide firm cushion and prevent movement inside the container.
- 4. Seal the shipping container securely, and mark it *FRAGILE* to assure careful handling.
- 5. In any correspondence refers to the instrument by model number and full serial number.

Reflectometer Application

Description

Figure 3 illustrates a typical setup for making reflectometer measurements. The forward output, of the coupler is used for leveling the sweep oscillator. The output of the reverse arm that is proportional to the reflections from the device under test is displayed on an SWR meter. The device under test is connected to the main line output of the coupler.




Figure 3 Typical Reflectometer Setup

Equipment Considerations

The Agilent 423B crystal detectors are suitable for use as the detectors. A SWR meter and oscilloscope are suitable for use as the calibrated display instruments. If a permanent record of the measurements is required, choose a recorder that is suitable for use with the SWR meter.

Performance Tests

The procedures in the follow tests functions check the 777D performance for incoming inspection and periodic evaluation. The specifications in Table 1 on page 3 are the performance standards.

Test Equipment Required

The test instruments and accessories required to make the performance tests are listed in Table 2. Test instruments can be used provided their performance equals or exceeds the Critical Specifications listed.

Table 2 Recommended Test Equipment

Instrument	Critical Specifications
Sweep Oscillator	Frequency: 1.9 to 4.0 GHz Residual FM: <3 kHz rms leveled output capability Power output: ≥25 mW into 50 ohms Amplitude Modulation: square-wave, 950 to 1050 Hz
10 dB Attenuator (2)	Frequency Range: 1.9 to 4.0 GHz Attenuation: 10 dB ±0.5 dB SWR: ≤1.15 Connectors: APC-7*
Coaxial Short	Type N male and Type N female
Short	APC-7*
Sliding Load	Frequency Range: 1.9 to 4.0 GHz
X-Y Recorder	Range: Variable from 10 mV to 100 mV Input Impedance: ≥100K ohms Accuracy: ±3% of full scale
Network Analyzer & Harmonic Frequency Converter	
Polar Display Unit	
Phase Gain Indicator	
Reflection-Transmission Test Unit	Frequency Range: 1.9 to 4.0 GHz
Flexible Arm Frequency Range: 1.9 to 4.0 GHz Impedance: 50 ohms Reflection Coefficient: ≤0.11 Connectors: APC-7*	
Coaxial Termination (2)	Frequency Range: 1.9 to 4.0 GHz Impedance: 50 ohms Reflection Coefficient: ≤0.05 Connectors: Type N male

Table 2 Recommended Test Equipment

Instrument	Critical Specifications
Adapter (3)	APC-7* to Type N Frequency Range: 1.9 to 4.0 GHz Impedance: 50 ohms Reflection Coefficient: ≤0.03
Swivel Adapter (2)	Frequency Range: 1.9 to 4.0 GHz SWR: ≤1.2 Connectors: Must mate with APC-7
* Registered Trademark: Amphe	enol RF Division, Danbury, Connecticut

Directivity Test

Specification Minimum directivity: 30 dB.

Description Refer to Figure 4 for test setup and Table 2 on page 6 for test equipment.

The 777D under test is connected as a reflectometer to the network analyzer. The system is calibrated with a coaxial short for a reflection coefficient of 1. The short is removed and the 777D is terminated with a sliding load. The network analyzer test channel gain is increased by 30 dB making the calibration of the polar display's outer graticule circle equal to the directivity specification.

NOTE

If the sliding load was a perfect termination, any energy from the coupler's reverse arm would be due only to the directivity signal; however, the energy from the coupler's reverse arm, and thus the indication on the Polar Display, is due to the directivity signal plus the reflection from the sliding load.

The Sweep Oscillator is set to sweep the frequency band of interest very slowly. The sliding load is phased causing its reflected vector to rotate about the tip of the directivity vector. The center of the circle caused by phasing the sliding load must be within the outer graticule circle.




Figure 4 Directivity Test Setup

Equipment

The directivity test equipment includes the following:

- Sweep oscillator
- Network analyzer
- Harmonic frequency converter
- Sliding load
- Coaxial short
- APC-7 to Type N adapter (2)
- Swivel adapter (2)

Procedure

- 1. Connect equipment as shown in Figure 4 with the 777D terminated in a coaxial short.
- 2. Phase lock the network analyzer over the frequency band of interest.
- 3. Adjust the network analyzer test channel gain and amplitude vernier controls to locate the trace on the outer graticule circle.
- 4. Remove the coaxial short and terminate the 777D with the sliding load.
- Increase the network analyzer test channel gain by 30 dB.
- 6. Set the sweep oscillator to very slowly sweep the frequency range of interest.
- 7. Phase the sliding load while observing the polar display. The center of the circle caused by phasing the sliding load must be within the outer graticule circle.
- 8. Repeat steps (1) through (9) at other frequencies to cover the 777D operating range. Reverse the 777D and test the other coupled arm.

Coupling Attenuation and Coupling Variation Test

Specification Coupling at

Coupling attenuation: 20 dB ±0.5 dB Maximum coupling variation: ±0.4 dB

Description

Refer to Figure 5 for test setup and Table 2 on page 6 for test equipment.

The equipment shown in Figure 5 is calibrated for a transmission measurement with the Flexible Arm, Attenuators, and APC-7 Adapters connected in a through path. The Network Analyzer test channel gain and amplitude vernier controls are adjusted for a zero dB meter indication at the lowest frequency of .the band to be swept. The X-Y Recorder Y axis sensitivity is adjusted so that 0.2 dB equals approximately one inch with zero dB at the center. Calibration lines are drawn in 0.2 dB increments to ± 0.8 dB by adjusting the Network Analyzer amplitude vernier control. The 777D coupled arm is inserted in the test setup. The Network Analyzer test channel gain is increased 20 dB and the coupling response is drawn on the X-Y recorder. Coupling attenuation and coupling variation are determined from the X-Y Recorder graph.




Figure 5 Coupling test and Primary Line Insertion Loss Test Setup

Equipment

- Sweep Oscillator
- Reflection-Transmission Test Unit
- Network Analyzer
- Harmonic Frequency Converter
- X-Y Recorder
- Flexible Arm
- 10 dB Attenuator (2)
- **Coaxial Termination**
- APC-7 to Type N Adapter (2)

Procedure

- 1. Connect equipment as shown in Figure 5 with the flexible arm, attenuators, and APC-7 to Type N adapters connected in a through-transmission path.
- 2. Phase lock the network analyzer over the frequency band of interest.
- 3. Adjust the network analyzer test channel gain and amplitude vernier controls for a zero dB 8413A meter indication at the lowest frequency of the band to be swept.
- 4. Adjust the X-Y recorder's Y axis sensitivity so that 0.2 dB (10 mV) equals approximately one inch with zero dB at the center.
- 5. Record calibration lines in 0.2 dB increments to ± 0.8 dB by adjusting the network analyzer amplitude vernier control. Return the amplitude vernier control to the zero dB setting.
- 6. Insert the 777D coupled arm in the setup.
- 7. Increase the network analyzer test channel gain 20 dB. The zero dB calibration line now equals 20 dB.
- 8. Record the 777D coupling response. Determine the minimum and maximum points on this trace in dB.
- 9. Coupling attenuation (mean coupling) = Maximum + Minimum/2 and must be $20 \text{ dB} \pm 0.5 \text{ dB}$.
- 10. Coupling variation = Maximum Minimum/2 and must be ≤ 0.4 dB.

Primary Line Insertion Loss Test

Specification

≤0.75 dB.

Description

Refer to Figure 5 on page 10 for test setup and Table 2 on page 6 for test equipment.

The equipment shown in Figure 5 is calibrated for a transmission measurement with the flexible arm, attenuators, and APC-7 to Type N adapters connected in a through path. The network analyzer test channel gain and amplitude vernier controls are adjusted for a zero dB 8413A meter indication at the lowest frequency of the band to be swept. The X-Y recorder Y axis sensitivity is adjusted so that 0.2 dB equals approximately one inch with zero dB in the upper portion of the graph. A zero dB calibration line is drawn and a calibration line at -0.75 dB is drawn by adjusting the Network Analyzer amplitude vernier control. The 777D primary line is inserted in the setup (secondary line connectors terminated). A test trace is drawn on the X-Y Recorder. The test trace must be within the two calibration traces.

Procedure

- 1. Connect equipment as shown in Figure 5 on page 10 with flexible arm, attenuators, and APC-7 to Type N adapters connected in a through transmission path.
- 2. Phase lock the network analyzer over the frequency band of interest.
- 3. Adjust the network analyzer test channel gain and amplitude vernier controls for a zero dB meter indication at the lowest frequency of the band to be swept.
- 4. Adjust the X-Y recorder Y axis sensitivity so that 0.2 dB (10 mV) equals approximately one inch with zero dB in the upper portion of the graph.
- 5. Record a zero dB calibration line. Adjust the network analyzer amplitude vernier control for a –0.75 dB meter indication and record the –0.75 dB calibration line. Return the network analyzer amplitude vernier control to the zero dB setting.
- 6. Insert the 777D primary line in the setup.
- 7. Record the insertion loss test trace. The test trace must be within the two calibration lines.

Primary and Secondary Line SWR

Specification Maximum Primary Line SWR: ≤1.2

Maximum Secondary Line SWR: ≤1.3

NOTE


The SWR and directivity characteristics of the 777D are interdependent; therefore, a satisfactory directivity check should indicate satisfactory SWR.

Description

Refer to Figure 6 on page 14 for test setup and Table 2 on page 6 for test equipment.

SWR is measured using a network analyzer, polar display unit, and test set. The test setup is calibrated for a reflection coefficient of 1. Gain is inserted in the test channel to obtain the appropriate full scale calibration for the 777D connector being measured. A swept frequency measurement of the 777D connector is made, which includes the ambiguity due to directivity of the 8743A test set. If the sum of 777D connector SWR and test set directivity exceeds 1.22 for secondary line connectors or 1.12 for primary line connectors, single frequency measurements are made with test set directivity calibrated out. Main line connector SWR is measured at single frequencies with both test set directivity calibrated out and with the main line termination reflection calibrated out.

.



* TERMINATE PORTS NOT BEING MEASURED

Figure 6 SWR Test Setup

Equipment

- Sweep oscillator
- Reflection-transmission test unit
- Network analyzer
- Harmonic frequency converter
- Coaxial short
- Coaxial termination
- APC-7 to Type N adapter (2)

Procedure To calibrate the equipment

- 1. Connect equipment as shown in Figure 6 with appropriate adapter and coaxial short connected to the unknown port.
- 2. Phase lock the Network Analyzer over the desired frequency band.
- 3. Push and hold the beam CTR push-button and adjust the horizontal and vertical position controls to place the dot in the center of the graticule.
- 4. Obtain equal reference and test channel electrical lengths by adjusting the line stretcher to collapse the trace to a dot or smallest cluster.

- 5. Adjust the network analyzer phase vernier, test channel gain and amplitude vernier controls to place the dot or cluster for a reference indication of r = 1 < 180 degrees.
- 6. For primary line connectors, increase the network analyzer test channel gain by 25 dB. The network analyzer is now calibrated for a full-scale reflection coefficient of 0.058 (SWR = 1.12). For secondary line connectors increase the network analyzer test channel gain by 20 dB. The network analyzer is now calibrated for a full-scale reflection coefficient of 0.1 (SWR = 1.22).

To perform a measurement

- 1. For swept frequency measurements, proceed as follows:
 - a. Remove the coaxial short and connect 777D connector to the test set UNKNOWN port. The displayed trace (combination of 777D SWR and test set directivity) should be within the outer graticule circle. If the displayed trace is outside the outer graticule circle at any frequency, make single frequency measurements with test set directivity calibrated out as follows:
- 2. For single frequency measurements with test set directivity calibrated out, proceed as follows:
 - a. Set the sweep oscillator to the desired single frequency.
 - b. Remove the 777D under test and connect a sliding load to the appropriate adapter on the test set UNKNOWN port.
 - c. Slide the load and adjust the network analyzer horizontal and vertical position controls until the circle rotates about the center of the CRT.
 - d. Remove the sliding load and connect 777D connector to be measured to the test set UNKNOWN port.
 - e. For the 777D secondary line connectors the display must be within the outer graticule circle. For primary line connectors, calibrate out termination reflection as follows:
- 3. For primary line connectors, perform step i and the following:
 - a. Terminate the 777D primary line with the sliding load.
 - b. Slide the load and with a grease pencil mark the center of the circle on the display. The reflection coefficient represented by this mark must be within the outer graticule circle.

Test Record

Table 3 is a performance test record. This table may be used during the test to record the test values obtained, and it provides a permanent record of the test values for use at a later time during periodic evaluation.

Table 3 Performance Test Record

Model 777D		Tested by
Dual-Directional Coupler		Date
Serial Number		
Directivity	≥30 DB Incident Port Reflected Port	·
Coupling Attenuation	20 dB ±0.5 dB Incident Port Reflected Port	
Coupling Variation	\leq ± 0.4 dB Incident Port Reflected Port	
Primary Line SWR	≤1.2 Input Port Output Port	
Secondary Line SWR	≤1.3 Incident Port Reflected Port	
Primary Line Insertion Loss	$\leq \pm 0.75 \text{ dB}$	

Although input power can be applied to either main line port, for this test record the ports are identified as follows when holding the 777D so that the name plate can be read:

Input Port	= Main line port to the left	
Output Port	= Main line port to the right	
Incident Port	= Coupled port to the left	
Reflected Port	= Coupled port to the right	