

## Phase Sequence Tester

**TRANSCAT**

▶ Visit us at [Transcat.com!](http://Transcat.com!)

35 Vantage Point Drive // Rochester, NY 14624 // Call 1.800.800.5001




**Checks phase sequence and phase status**

Tests up to 690VAC and displays graphical phase orientation on the large LCD

### Features:

- 40 to 690VAC rated test range for testing phase orientation of three phase power sources over 15 to 400Hz frequency range
- Graphical multiline LCD indicates phase orientation (clockwise or counter-clockwise) and whether each of the three phases is live
- Durable housing is double molded
- Easy to open alligator clips with wide jaws
- Tests phase orientation of three phase power sources
- No battery required
- Dimensions: 5.1 x 2.7 x 1.25" (130 x 69 x 32mm); Weight: 4.5oz (130g)
- Complete with cable, three large color coded alligator clips, and pouch case



### Ordering Information:

480400 .....Phase Sequence Tester

**TRANSCAT**

▶ Visit us at [Transcat.com!](http://Transcat.com!)

35 Vantage Point Drive // Rochester, NY 14624 // Call 1.800.800.5001