

TEKTRONIX S-52
INSTRUCTION
MANUAL

Serial Number _____



S-52

FOR REFERENCE PURPOSES ONLY
**PULSE
GENERATOR
HEAD**

TEK INTER-OFFICE COMMUNICATION

TO John Martin 94-540 DATE June 25, 1991
FROM Frank Gray, 50-PAT
SUBJECT GIDEP permit request

In response to the request to grant permission to the Government Industry Exchange Program (GIDEP) to reproduce Tektronix operator, service and instruction manuals, Tektronix, Inc. hereby grants such permission for distribution of such documents to any GIDEP user that is a full participant in the Metrology Data Interchange Data Base of GIDEP provided that all copies of the original work include the entire copyright notice and ownership statement exactly as it appears in the original, together with the Legend "Reproduced with permission."

This permission has been approved by the Intellectual Property Committee of Tektronix, and a copy of this memo may be provided to GIDEP to provide the requested permission.


Francis I. Gray
Group Patent Counsel

imp

TABLE OF CONTENTS

	Page		Page
SECTION 1 SPECIFICATION		SECTION 5 PERFORMANCE CHECK/ADJUSTMENT	
General Information	1-1	Introduction	5-1
Electrical Characteristics	1-1	Equipment Required	5-1
Environmental Characteristics	1-2	Performance Check Procedure	5-1
Mechanical Characteristics	1-3	Adjustment Procedure	5-7
SECTION 2 OPERATING INSTRUCTIONS		SECTION 6 ELECTRICAL PARTS LIST	
General Information	2-1	Abbreviations	
Installation		Parts Ordering Information	
General	2-1	Special Notes and Symbols	
Head Installation	2-1	Index	
Extender Cable Installation	2-1	Electrical Parts List	
First Time Operation			
Procedure	2-3		
 		SECTION 7 DIAGRAMS	
SECTION 3 CIRCUIT DESCRIPTION		Symbols	
General Information	3-1	Component Locations	
Block Diagram	3-1	Troubleshooting Waveforms	
Circuit Description		Diagrams	
Period Generator	3-2		
BCD Counter (16 Count)	3-2		
BCD to Decimal Converter	3-2		
T.D. Reset	3-2		
T.D. Bias Current	3-3	SECTION 8 MECHANICAL PARTS LIST	
T.D. State Comparator	3-3	Mechanical Parts Information	
85 ns Lead Time and T.D. Trigger	3-3	Mechanical Parts List	
Tunnel Diode	3-3	Standard Accessories	
		Mechanical Parts Illustration	
SECTION 4 MAINTENANCE		CHANGE INFORMATION	
Introduction	4-1	Abbreviations and symbols used in this manual are based on or taken directly from IEEE Standard 260 "Standard Symbols for Units", MIL-STD-12B and other standards of the electronics industry. Change information, if any, is located at the rear of this manual.	
Obtaining Replacement Parts	4-1		
Parts Removal and Replacement	4-1		
Parts Location	4-2		
Troubleshooting			
General Information	4-2		
Checking The Snap-off Diode	4-2		
Checking the Tunnel Diode	4-3		




Fig. 1-1. S-52 Pulse Generator Head.

SECTION 1 SPECIFICATION

Change information, if any, affecting this section will be found at the rear of this manual.

General Information

The S-52 Pulse Generator Head provides a step pulse output for use with fast rise sampling oscilloscope systems. The S-52, which provides a pretrigger output signal and a fast positive pulse output signal at 50 Ω impedance, is also useful with Time Domain Reflectometry (TDR) systems.

The pretrigger output signal is available from front and rear connectors. When the S-52 is installed in the 7S12 TDR unit, the pulse output trigger time is controlled by the TDR unit. When installed in other sampling units, the internal pretrigger lead time is about 85 ns.

Operating power for the S-52 is obtained when the unit is installed into the sampling head compartment (or con-

nected via an interconnecting cable) of Tektronix sampling instruments such as the 7S12, 7S11, Types 3S2, 3S5, or 3S6. The S-52 can also be powered from the Type 285 Power Supply.

Electrical Characteristics

The following characteristics apply over an ambient temperature range of 0°C to +50°C after a 10 minute warmup, for an S-52 calibrated at a temperature between +20°C and +30°C. The required operating voltages are applied to the S-52 when it is connected or installed into the sampling head compartment or powered by a sampling head power supply.

ELECTRICAL CHARACTERISTICS

Characteristics	Performance Requirement	Supplemental Information
PULSE OUTPUT		
Risetime into 50 Ω	25 ps or less	
Amplitude into 50 Ω	At least 200 mV, positive going	
Aberrations	+7%, -7%, total of 10% P-P within the first 1.8 ns of the step edge with the reference level at 1.8 ns from the step edge; +2%, -2%, total of 4% P-P after the first 2.5 ns with the reference level at 3.0 μ s from the step edge	
Pulse Duration	At least 350 ns	
Period	8.3 μ s within 0.8 μ s.	
Baseline Level	55 mV to 120 mV terminated in 50 Ω	
Source Impedance		50 Ω , nominal
PRETRIG OUT (Front Panel)		
Amplitude into 50 Ω	At least 1.0 V, positive-going	
Rise Rate	600 mV/ns	
Pulse Duration	4 ns within 2 ns	

Specification—S-52

Characteristic	Performance Requirement	Supplemental Information
Pretrigger to Pulse Output Time	85 ns within 5 ns	
Pretrigger to Pulse Output Jitter	10 ps or less (With 7S11, 7T11, and 7000-series oscilloscope system, excluding the sampling oscilloscope jitter)	
Pretrigger Out (Rear Panel)		
Amplitude into 50 Ω	At least 1.0 V, positive-going	
Rise Rate	600 mV/ns	
Pulse Duration	4 ns within 2 ns	
PULSE OUTPUT Display Jitter	10 ps or less (With 7S12, S-6, and 7000-series oscilloscope system)	

ENVIRONMENTAL CHARACTERISTICS

Temperature		
Non-operating		-40°C to +65°C
Operating		0°C to +35°C
Altitude		
Non-operating		To 50,000 feet
Operating		To 15,000 feet
Vibration (Non-operating)		15 minutes along each axis at 0.015 inch. Vary the frequency from 10 to 55 to 10 Hz in 1-minute sweeps. Three minutes at any resonant point or at 55 Hz.
Shock (Non-operating)		Two shocks each of 500 g's (2 ms duration), 750 g's (1 ms duration) and 1000 g's (0.5 ms duration), in each direction and along each major axis for a total of 36 shocks.
Transportation		Meets National Safe Transit Committee type of test when packaged as shipped by factory.

MECHANICAL CHARACTERISTICS

Characteristics	Description
Finish	Anodized aluminum front panel, extruded aluminum blue-vinyl painted cabinet with aluminum castings front and rear.
Weight	Approximately 8 oz.
Dimensions	
Height	About 2 inches
Width	About 1 3/4 inches
Length	About 4 inches

STANDARD ACCESSORIES

The accessories supplied with the S-52 Pulse Generator Head are listed in Section 8 Mechanical Parts List.

SECTION 2

OPERATING INSTRUCTIONS

Change information, if any, affecting this section will be found at the rear of this manual.

General Information

This section of the manual provides the basic information required to operate the S-52 Pulse Generator Head. It also includes installation and first time operation instructions.

The S-52 may be powered by any Tektronix instrument having a sampling head compartment, such as the Tektronix 7S12, 7S11, or Types 3S2, 3S5, 3S6, or 286; or, the unit may be powered separately by a Tektronix Type 285 Power Supply. The S-52 may be connected to a head compartment by one of two accessory extender cables. This permits short-length coaxial cables to be used between the PULSE OUTPUT connector and the load.

The pretrigger output pulse allows a sequential sampling system to display the main pulse without using a delay line in the signal path. The pretrigger pulse is available at both the rear and the front panel connectors.

The S-52 is normally used with the Tektronix 7S12 Time Domain Reflectometry (TDR) unit. When the S-52 is used with the Tektronix 7S12, the pretrigger to pulse output time is determined by the 7S12.

The S-52 is also useful with other Tektronix sampling instruments.

INSTALLATION

General

Since the S-52 Pulse Generator Head can be powered by Tektronix instruments containing sampling compartments or sampling head extender cables, many combinations of instruments are possible. Three installations are shown in Fig. 2-1. Part (A) shows the S-52 installed in the pulse generator compartment of the Tektronix 7S12 TDR Sampling Unit. The 7S12 can be used in any 7000-series oscilloscope. Part (B) shows the S-52 installed in the Channel B compartment of the Type 3S2 Sampling Unit. This leaves Channel A of the sampling unit available to operate a sampling head. Part (C) shows the S-52 installed in the head compartment of the 285 Power Supply.

With (A), (B), or (C) method of installation, the S-52 can be plugged into the sampling unit or power supply as shown, or operated remotely on a special extender cable. Three and six foot extender cables are available. Order the three foot extender cable by Tektronix Part No. 012-0124-00, or the six foot extender cable by Tektronix Part No. 012-0125-00. Contact your local Tektronix Field Engineer or Representative for price and availability of these optional accessories.

Head Installation

To insert the S-52 into a compartment of the sampling unit or power supply, proceed as follows:

1. Pull the latch knob outward from the front panel (the latch knob will push out normally when the unit is inserted, if the knob is left free to move).
2. Insert the unit slowly into the compartment, so the two plastic guides enter the rear connector opening.
3. Push the S-52 completely into the compartment.
4. Push the latch knob to lock the unit in place.


To remove the S-52 from the compartment, pull the latch knob away from the front panel, then pull the unit from the compartment.

Extender Cable Installation


To use the S-52 on an extender cable, install as follows:

1. Pull the latch knob located on the head end of the extender outward from the panel (the latch knob will push out normally when the extender is inserted if the knob is free to move).
2. Insert the extender cable head end slowly into the desired compartment in the sampling unit so the two plastic guides in the compartment engage the unit.


Operating Instructions—S-52



(A) Installed in a Pulse Generator Compartment



(B) Installed in a Type 3S2 Sampling Head Compartment



(C) Installed in Type 285 Power Supply Compartment

Fig. 2-1. S-52 Installation information.

3. Push the head completely into the compartment.
4. Push the latch knob to lock the extender cable head end in place.
5. Connect the S-52 to the other end of the extender cable in a similar manner, and set the latch knob to hold it in place.
6. To remove the S-52 from the extender cable, pull the latch knob on the front panel of the S-52, and remove the unit from the extender cable.
7. To remove the extender cable head from the sampling unit compartment, pull the latch knob outward from the front of the panel, then pull the extender cable free.

Powering the S-52 with the Type 285 Power Supply allows both channels of a dual-trace sampling unit (such as the Type 3S2) to be used for sampling heads.

FIRST TIME OPERATION

This First Time Operation uses a Type 564B with Types 3T2, 3S2, S-6, and S-52 as shown in Fig. 2-1B. If you are using equipment shown in Fig. 2-1A, follow the First Time Operation information given in the 7S12 instruction manual.

Substitute equipment for the First Time Operation can include any Tektronix 560 Series oscilloscope with a 3S-series dual trace sampling unit containing one sampling head, and 3T-series sampling time base unit.

Procedure

1. With the Type 564B Power Switch off, insert a Tektronix Type 3S2 Sampling Unit into the vertical compartment (left) and a Tektronix Type 3T2 Random Sampling Unit into the horizontal plug-in compartment.
2. Insert the S-6 into Channel A (left) of the Type 3S2, leaving the latch free to move. Once the S-6 is seated, push the latch to lock it in place.
3. Insert the S-52 into Channel B (right) of the Type 3S2, leaving the latch free to move. Once the S-52 is seated, push the latch to lock it in place.

4. Connect the S-52 PULSE OUTPUT through a 50 Ω semi-rigid cable, 6 inch (Tektronix Part No. 015-1017-01), to the S-6 Loop Thru input (lower) connector (carefully form the semi-rigid cable to make this connection).

NOTE

Connectors at both ends of the coaxial cable should be firmly connected to mating connectors or accessories. Tighten slightly more than finger tight using a 5/16 inch wrench. A good connection is necessary to minimize reflections at the junction of connectors.

Terminate the Loop Thru (upper) connector in 50 Ω (3 mm termination, Tektronix Part No. 014-1004-00), using an adapter (Tektronix Part No. 015-1011-00).

5. Connect the S-52 PRETRIG OUT to the 50 Ω Trigger Input of the Type 3T2, using a BSM to BNC 50 Ω coaxial cable (Tektronix Part No. 012-0128-00, 10 inch length).
6. Set the Type 564 Intensity control fully counter-clockwise.
7. Connect the Type 564 to the power line and set the Power switch to On.
8. Set the instrument controls as follows:

Type 564

Upper and Lower Screen Non-store

Type 3S2

Display Mode	CH A
Normal-Smooth	Normal
Horiz. Plug-In Compatibility	Sampling, 3T-Series (behind front panel)
Channel A controls	
Position	Midrange
DC Offset	Midrange (5 turns from one end)
Units/Div	100
Variable	Cal
Invert	Pushed In
Dot Response	Midrange
Channel B controls	Optional

Type 3T2

Time Position	Fully Clockwise
Horiz Position	Midrange

Operating Instructions—S-52

Samples/DIV (behind front panel)	Variable	
Samples/Div	9 o'clock position	
Display Mode	Normal	
Start Point	With Trigger	
Range	100 ns	} 10 ns/div
Display Mag	X1	
Time Magnifier	X1	
Variable	Cal	
Trigger Source	Ext	
Trigger Sensitivity	Fully clockwise	
Recovery Time	Centered	
Trig Polarity	(+)	

10. After a five minute warmup time, set the Type 564 Intensity control for normal trace brilliance. Adjust Astigmatism and Focus controls for best focus.

11. Center the trace on the graticule with the Type 3S2 DC Offset control.

12. Adjust the Type 3T2 Trigger Sensitivity control for a stable triggered display of the S-52 output pulse leading edge (about 200 mV amplitude). Change the Type 3T2 Time Magnifier to X20 (500 ps/div). Use the Time Position control to position the leading edge to the left side of the display. Use the Type 3S2 DC Offset control to position the top of the pulse at the graticule centerline. See Fig. 2-2.

13. Remove the 50 Ω termination from the S-52 Loop Thru output (upper) connector and note that the pulse amplitude increases by about two times.




Fig. 2-2. PULSE OUTPUT leading edge (50 Ω terminated).




Fig. 2-3. Display with unterminated "Test Line".

14. Add a short length of 50 Ω coaxial cable to the same connector. (This example uses a 500 ps, 50 Ω , semi-rigid coaxial cable with a length of about 4 inches). See Fig. 2-3. The open line shows a reflection coefficient (ρ) of about +1.

15. Terminate the end of the "Test Line" in 50 Ω . A precision termination firmly connected to mating connectors at the end of the "Test Line" will allow a minimum reflection at the termination point. Fig. 2-4 shows a reflection due to a loose connector.




Fig. 2-4. Display with "Test Line" showing a reflection due to an incorrectly installed termination.

With a fixed pretrigger lead time in the S-52, the Type 3T2 Time Position control allows the start of the time window to be set over the operating range of the control. The time per division is set by the Time Magnifier and the Display Magnifier. Use the DC Offset and the mV/Div controls on the Type 3S2 to obtain the desired vertical deflection factor and offset voltage. The S-52 is useful to analyze reflections in coaxial cable up to about 150 feet.

For basic principles and measurement information about TDR displays, read the Tektronix Measurement Concept Series booklet titled "Time Domain Reflectometry Measurements", Tektronix Part No. 062-1244-00.

Using the S-52 in the 7S12 TDR Unit, the lead time is calibrated in the 7S12 for time and distance.

SECTION 3 CIRCUIT DESCRIPTION

Change information, if any, affecting this section will be found at the rear of this manual.

General Information

This section of the manual contains the electrical description of the S-52 Pulse Generator Head circuits.

The S-52 requires +15 V and -12.2 V input power. The input power is obtained when the instrument is connected to the pulse generator compartment connector of a TDR Sampling unit, to one compartment connector of a sampling unit, or to the Type 285 Power Supply.

Refer to the schematic diagram in Section 7 of the manual as necessary when using the Circuit Description.

BLOCK DIAGRAM

The Block Diagram, Figure 3-1 shows the major circuit blocks of the S-52. When the S-52 is used with the 7S12 TDR Sampling Unit, the pulse generator trigger and the inhibit voltage are provided from the 7S12 to the 85 ns Lead Time and the T.D. Trigger block. A brief description of each block follows, starting with the 0.5 μ s Period Generator block.

The Period Generator block contains a free-running oscillator with a period of about 0.5 μ s. The positive output excursion of the Period Generator drives the BCD Counter.




Fig. 3-1. S-52 Block Diagram.

Circuit Description—S-52

The BCD Counter (16 count) is driven from the Period Generator and produces BCD signals to the BCD to Decimal Converter.

With the 16 count input signals (16 periods), the BCD to Decimal Converter produces negative output signals occurring at periods 2, 3 through 6, 8 and 9. Period 2 signal drives the T.D. (tunnel diode) State Comparator. Periods 3 through 6 signal drives the T.D. Reset. Period 8 signal drives the 85 ns Lead Time and T.D. Trigger circuits. Period 9 signal drives the T.D. State Comparator.

Periods 3 through 6 signal to the T.D. Reset circuit resets the Tunnel Diode. In the absence of any signal during period 7, the circuit applies the bias current from the T.D. Bias Current circuit to arm the Tunnel Diode. After the pretrigger and PULSE OUTPUT occur (at period 8), the period 9 signal causes the T.D. Reset circuit to reset the Tunnel Diode and the T.D. Bias Current circuit, reducing the available arming bias current. This low arming bias is applied to the Tunnel Diode by the T.D. Reset circuit in the absence of any input signal during periods 6 and 10 through 16.

Period 2 signal to the T.D. State Comparator allows the T.D. Bias Current circuit to increase the bias (applied through the T.D. Reset) until the Tunnel Diode changes to its high state. The high state of the Tunnel Diode drives the T.D. State Comparator. This in turn causes the T.D. Bias Current circuit to hold this new bias current, used for arming the Tunnel Diode during period 7. (This high state of the Tunnel Diode, useful to determine the next reset current value, produces a pulse at the output; but in the absence of a pretrigger signal, this signal output is not useful as the output pulse.)

Period 8 signal from the BCD to Decimal Converter drives the 85 ns Lead Time & T.D. Trigger circuits to initiate a positive pretrigger signal to the front and rear panel connectors of the S-52. The circuit operates in one of two ways: (A) if the S-52 is used in the 7S12, the Inhibit Voltage from the 7S12 inhibits the trigger flow within the circuit. The 7S12 uses the Pretrigger Out signal (rear panel), and supplies the Pulse Generator Trigger to the circuit. The delay time between the S-52 Pretrigger Out (rear panel) and the Pulse Generator Trigger back to the S-52 is set by the 7S12; and (B) in the absence of the Inhibit Voltage and the Pulse Generator Trigger signal (if the S-52 is not used with the 7S12), the internally connected trigger flow drives the T.D. Trigger circuits producing a trigger signal, delayed by 85 ns, to the Tunnel Diode.

The PULSE OUTPUT signal is produced after the Tunnel Diode arming bias is applied during period 7 by the T.D. Reset, and the Tunnel Diode is triggered in period 8

from the 85 ns Lead Time & T.D. Trigger circuit. The Trigger signal causes the Tunnel Diode to change to its high state. The PULSE OUTPUT signal ends when the Tunnel Diode is reset by the T.D. Reset at the start of period 9.

CIRCUIT DESCRIPTION

Period Generator

The Period Generator consists of U30E and associated components. The generator is connected as a colpitts oscillator with a period of about 0.5 μ s. The positive-going output signal at U30E collector drives the BCD Counter, U10 pin 14.

BCD Counter (16 Count)

The BCD Counter (U10) is a 4 bit binary counter connected to provide divide by 2, 4, 6, and 8 outputs to drive the BCD to Decimal Converter U20.

BCD to Decimal Converter

The BCD to Decimal Converter (U20) accepts the four outputs from the BCD counter to pins 15 ($\div 2$), 14 ($\div 4$), 13 ($\div 8$), and 12 ($\div 16$), and converts each BCD combination up to 10 (out of a total of 16) to its decimal equivalent. Four decimal output signals are used from pins 2, 3 through 6, 9 and 10. These occur at periods 2, 3 through 6, 8, and 9 respectively. These output signals drive the following circuits to control the Tunnel Diode operation. Period 2 signal drives the T.D. State Comparator circuit. Periods 3 through 6 and Period 9 signals drive the T.D. Reset circuit. Period 9 signal also drives the T.D. Bias Current circuit. Period 8 signal drives the 85 ns Lead Time and T.D. Trigger circuit.

T.D. Reset

The input signal to the T.D. Reset circuit are the periods 3 through 6 and 9 signals from U20 pins 3 through 6 and 10. The output, from the Q86 and Q88 circuit, operates to apply or disconnect the bias current to the Tunnel Diode.

Periods 3 through 6 signal at U20 pins 3 through 6 (a low signal during period 1) through R32 turns on U30C. Conduction of U30C turns on Q80, which changes the bias of Q86 and Q88, so that Q86 is on and Q88 is off. With Q88 off, the Tunnel Diode current path is open, which resets the Tunnel Diode. Then in the absence of any input signals during period 7, the states of U30C, Q80, Q86, and Q88 are reversed, with Q88 on. Q88 applies the current set by Q90 in the T.D. Bias Current circuit to the Tunnel Diode. This current arms the Tunnel Diode. Further operations of this circuit occur after the pretrigger and PULSE OUTPUT of period 8. Period 9 signal (a low signal during period 9) couples through CR21 and R32 to turn on U30C.

As in periods 3 through 6, the conduction of U30C turns on Q80, which changes the bias of Q86 and Q88 so that Q86 is on and Q88 is off. With Q88 off, the Tunnel Diode current path is open, which resets the Tunnel Diode. Then in the absence of any input signals in period 10, the states of U30C, Q80, Q86, and Q88 are reversed, with Q88 on. Q88 applies a reduced current to the Tunnel Diode. This reduced current is set by Q90 in the T.D. Bias Current circuit.

T.D. Bias Current

The input signals to the T.D. Bias Current circuit are the period 9 signal at U20 pin 10, and the output of the T.D. State Comparator circuit at Q74 collector. The output supplies bias current to the T.D. Reset circuit at the emitters of Q86 and Q88.

Period 9 signal at U20 pin 10 (a low signal during period 9) couples through CR26 and R38 turns on U30D. Conduction of U30D discharges C90 through CR91 to a voltage set by CR93. C90 charge path through R90, CR90, and R74 is open, by the conduction of Q74 in the T.D. State Comparator circuit. This reverse biases CR90. With the voltage across C90 low, current in Q90 is reduced. This reduces the bias current to the T.D. Reset circuit at the emitters of Q86 and Q88. Further operations of the T.D. Bias Current circuit occur after the reduced bias is applied to the Tunnel Diode (by Q88) in period 10, and Q74 in the T.D. State Comparator circuit is reverse biased in period 2. With Q74 off at the start of period 2, CR90 turns on and C90 charges, with the charge path through R74, CR90, and R90. As C90 charges, current through Q90 increases, which increases the bias current through Q88 to the Tunnel Diode. The Tunnel Diode bias current is increased until the Tunnel Diode changes to its high state, which turns on Q74. Q74 reverse biases CR90 and the charge on C90 is held (except for a very small Q90 base current through R90) to control the arming bias current in period 7. Trig Level control R90 sets the arming bias current to a value below the peak current for the Tunnel Diode. This allows an adjustment for Trigger level requirements.

T.D. State Comparator

The input signals to the T.D. State Comparator circuit are the period 2 signal at U20 pin 5, and the Tunnel Diode voltage coupled through R75 to Q74 base. The output of the comparator at Q74 collector drives the T.D. Bias Current circuit.

Period 2 signal at U20 pin 5 (a low signal during period 2) couples through CR28 to turn off U30B. With U30B off, current through R26 turns on Q72. Conduction of Q72 turns off Q74. This allows C90 in the T.D. Bias Current circuit to charge until the Tunnel Diode changes to its high state. The Tunnel Diode voltage across R75 turns on Q74 to terminate C90 charge, and holds Q74 on for the remainder of period 2.

85 ns Lead Time & T.D. Trigger

The circuit is driven by the Period 8 signal from U20 pin 9. If the S-52 is used with the 7S12, two additional inputs provided by the 7S12 are the Inhibit Voltage and the Pulse Generator Trigger signal.

When period 8 signal at U20 pin 9 (a low signal during period 8) goes low, the negative-going signal reverse biases U30A. CR40 is reverse biased, which allows Q40 to turn on. Q40 drives Q50 with positive feedback via C40 to turn on. Q40 produces a fast rise positive signal at Q50 collector. This signal is coupled through C54 and CR54 to Pretrig output connector P52 on the rear panel, and also through C52 to the PRETRIG OUT connector on the front panel.

U10 pin 9 is coupled through CR30 to the collector of U30A to prevent operation during period 5.

Also in the absence of the Inhibit Voltage and Pulse Generator Trigger (the S-52 is not used with the 7S12), the fast rise positive signal at Q50 collector couples through C60 to turn on Q60. With Q60 on, its collector goes low, causing the charge on C62 to forward bias CR66 through L62 and LR64. Operation of L62, LR64, R64 and C66 keeps CR66 forward biased for about 85 ns. At the end of the 85 ns period, CR66 (a snap-off diode) opens and causes a fast positive pulse through C65, R65-R68, and the 2 mil diameter lead wire inductor to the Tunnel Diode. C60 is set during calibration for proper delay.

When the S-52 is used with the 7S12 TDR Unit, the Inhibit Voltage from the rear connector pin 5 forward biases CR60 and keeps Q60 turned on, preventing the internal trigger signal at Q50 collector from having any effect on Q60. The 7S12 is driven by the Pretrig output signal at P52 and produces a Pulse Generator Trigger Signal to the rear connector pin 2. The delay from the Pretrig output signal time to the Pulse Generator is determined by the 7S12. Before the Pulse Generator Trigger Signal occurs, a negative voltage is applied to pin 2, (from the 7S12) coupled through LR64 to forward bias snap-off diode CR66. Then the Pulse Generator Trigger signal, a positive signal, reverse biases CR66, which causes a fast positive pulse through C65, R65-R68, and the 2 mil diameter lead wire inductor to trigger the Tunnel Diode.

Tunnel Diode

The Tunnel Diode reset current is set by the T.D. Reset Current circuit, and applied by the T.D. Reset circuit through R88, R65, R68 and the 2 mil diameter connecting wire inductor. When the Tunnel Diode is triggered, it changes from its low state to its high state, thus initiating the PULSE OUT signal. The end of the PULSE OUT signal is determined by the T.D. Reset circuit (period 9) when the Tunnel Diode changes back to its low state.

SECTION 4 MAINTENANCE

Change information, if any, affecting this section will be found at the rear of this manual.

Introduction

This section is a maintenance guide for the S-52 Pulse Generator Head. Information is included for parts ordering, parts removal and replacement, disassembly and assembly.

Obtaining Replacement Parts

All parts used in the S-52 can be purchased directly through your local Tektronix Field Office or representative. However, replacement for standard electronic items can be obtained locally. Consult the Electrical or Mechanical Parts List to determine the value, tolerance and rating required.

NOTE

When selecting replacement parts, it is important to remember that the physical size and shape of a component may affect its performance at high frequencies. After repair, the S-52 Pulse Generator Head may require re-calibration.

Parts Removal and Replacement

Housing and Rear Panel. To remove the S-52 from its housing, loosen the four retaining screws on the rear panel. Slide the rear panel off, and remove the housing by sliding it to the rear. With the housing and rear panel removed, the unit can be connected to an extender cable for access to adjustment controls and circuit test points for calibration. Two lengths of extender cables are available from your local Tektronix Field Office or representative. Order by Tektronix Part No. 012-0124-00 for the three-foot length and Tektronix Part No. 012-0125-00 for the six-foot length extender cable.

To install the S-52 in its housing, align the upper and lower corners of each side circuit board with the channels in the sampling head body which contain the zigzag springs. Push the S-52 gently into the housing until it contacts the front panel. Be sure that the white plastic pawl in the locking knob is properly aligned as the S-52 is slid into the housing. Attach the rear casting, making sure that the hole on one side fits over the pretrigger signal output connector. Insert the four long mounting bolts and tighten them securely. To ensure that the mounting bolts align with the front panel, hold the S-52 in its normal horizontal position; start the lower bolts, then turn the S-52 over and start the remaining two bolts.

Circuit Boards. To remove the Timing board (on the instrument right side) gently pull the board outward from the Control board.

To remove the Trigger board (on the instrument left side) gently pull the board outward from the Control board. To remove the trigger coaxial lead from the front panel, use a 5/16 inch end wrench to hold the nut located behind the front panel. Then use a 9/32 inch end wrench to remove the coaxial cable retaining nut. Once this nut is removed, gently pull the coaxial cable, together with the connector center pin, from the connector. Remove the connector shell, by first loosening the nut located behind the front panel with the 5/16 inch end wrench. To install the Trigger board, reverse the procedure. (When inserting the coaxial cable, be sure that the outer braid is not shorted to the center conductor).

For most maintenance on the Control board, it is not necessary to remove it from the front panel. If necessary to remove the board, carefully unsolder the two mil diameter tunnel diode connecting wire soldered to a wire connector post near the lower allen head screw holding the circuit board in place. Remove the two allen head screws holding the control board in place and remove the board. To install the Control board, reverse the procedure. Be sure the two spiral pins are flush with the connector holder before tightening the 5/16 inch allen screws. Also use extreme care in soldering the 2 mil diameter wire to the wire connector post.

Tunnel Diode CR69. Do this replacement in a clean, flat work area, since the tunnel-diode is easily lost due to its small size. Keep foreign material away from the diode when it is exposed. The tunnel diode is located behind the front panel directly behind the PULSE OUTPUT connector.

1. Remove the knurled screw from the back of the block connected to the front panel while the screw is pointed upward, to prevent the loss of the tunnel diode, or the spring underneath the tunnel diode. The tunnel diode and the spring are contained in the knurled hollow screw, and they will separate from the screw. See Fig. 4-1.

2. Carefully check that the 2 mil diameter wire is properly soldered to the center pin resistor (R69 assembly). Also see that the wire is properly aligned so that it will not




Fig. 4-1. Tunnel Diode assembly showing the spring and tunnel diode separated from the knurled hollow screw.

touch the metal block or ground when the tunnel diode assembly is inserted in the next step.

3. Insert the new tunnel diode assembly, which contains the tunnel diode, spring, and the knurled hollow screw into the block connected to the front panel while the screw is pointed upward. Tighten the knurled screw until the tunnel diode is properly seated.

R69 Assembly. R69 is part of the center conductor of the input connector assembly. To replace the assembly, use the following procedure.

1. Remove the tunnel diode assembly according to the instructions under the heading "Tunnel Diode CR69".

2. Carefully unsolder the two mil diameter wire (connected to R69) from the two 2.7 Ω resistors.

CAUTION

Do not check Tunnel Diode CR69 with an ohmmeter or curve tracer. Its duty cycle capabilities and the power dissipation may be exceeded. Also, before inserting a new Tunnel Diode, check that the circuit is operating properly.

3. Use a 5/16 inch wrench to remove the nut on the PULSE OUTPUT connector on the front panel. Remove the block assembly with the control board from the front panel.

4. Use a 7/32 inch end wrench to remove the connector and resistor (R69) from the block assembly.

5. To install, reverse the procedure. Be sure to position the 2 mil diameter wire in a position so it will not be twisted when the connector assembly is installed into block.

Parts Locations

Photos of the Timing, Control and Trigger circuit boards with the component locations are shown in Section 7. Mechanical Parts Illustration in Section 8 shows location of the mechanical parts.

TROUBLESHOOTING

General Information

As an aid to troubleshooting, use the troubleshooting conditions listed on the schematic diagram page in Section 7. First, determine whether the sampling unit or P1 supply is providing the proper power to the S-52. The waveform conditions are given using the Pretrig Out pulse trigger the test oscilloscope. If necessary, use the internal triggering (if no Pretrig Out signal) to isolate the inoperable circuit. Information about checking the Snap-off Diode the Tunnel Diode follows. Note that the Tunnel Diode waveforms and also the Tunnel Diode troubleshooting waveforms are shown in Section 7.

Checking the Snap-Off Diode

The delay time of the trigger pulse is caused by improper operation of the Snap-off diode CR66 in the trigger circuit. By using a Sampling Oscilloscope, the Lead control C60 allows the adjustment of the delay to 8 ns. For troubleshooting, a real time oscilloscope can be used to check the voltage across the diode. The waveform shown in Fig. 4-2 was taken using a P6053 10X probe, 7A16 A




Fig. 4-2. Snap-off Diode CR66 troubleshooting waveform.

fier, 7B50 Time Base, and 7504 Oscilloscope. The S-52 is used on an extender and powered from a Type 285 Power Supply. If the S-52 is powered from the Pulse Generator compartment of the 7S12, the waveform will be different and the check will not be valid.

The Snap-off diode is mounted in small metal clips on the Trigger board at the left side of S-52. The diode is marked with a dot on the cathode end which is ungrounded.

Checking the Tunnel Diode

Tunnel Diode CR69 should not be checked with an ohmmeter or curve tracer, as its duty cycle capabilities and power dissipation may be exceeded. The following steps should be taken to check CR69.

1. Check the PULSE OUT, using the troubleshooting waveforms shown in Section 7. Using the troubleshooting conditions given with the waveforms, check that the Pulse OUT display is similar to the normal condition shown in waveform 14A.

2. If the PULSE OUT display is similar to 14B waveform (open) or 14C (T.D. does not turn on), CR69 is defective.

NOTE

Waveforms were taken at point 13 and 14 with conditions as follows:

(A) Normal, Waveform 13A and 14A.

(B) Possible open T.D., Waveform 13B and 14B.

(C) T.D. not changing state, Waveform 13C and 14C.

Each of these conditions should indicate defective CR69, however, check that the knurled screw holding the Tunnel Diode is tightened properly, and that the 2 mil diameter lead wire to R69 is not shorted. If the PULSE OUT display is not similar to any of the above, remove the tunnel diode and perform step 3.

3. After a defective Tunnel Diode has been removed, use the following procedure to ensure that the S-52 circuits are operating properly, to avoid damage to a replacement Tunnel Diode.

a. With small clip leads connected to a 1N3130, 50 mA Tunnel Diode, substitute this in the circuit for CR69. Connect the anode end to the junction of R67 and R88 and the cathode to ground.

b. Check the S-52 circuits, making any repairs necessary until displayed PULSE OUTPUT waveform is restored, similar to waveform 14A.

c. Remove the 1N3130 and install CR69.

SECTION 5

PERFORMANCE CHECK ADJUSTMENT

Change information, if any, affecting this section will be found at the rear of this manual.

Introduction

This section of the manual contains the Performance Check and the Adjustment Procedure. When the Performance Check Procedure is completed, the instrument is checked to the "Performance" information given in Section 1. The tolerance and waveforms given in the Adjustment Procedure should be considered only as adjustment guides and not as instrument specifications.

Equipment Required

The following test equipment, or its equivalent, is required for both the Performance Check and the Adjustment Procedure of the S-52. All test equipment must be calibrated. If other equipment is substituted, it must meet or exceed the limits stated in the equipment list.

1. Test oscilloscope Tektronix 7000-Series (7504 used in this procedure), required for use with plug-in units, items 2, 3, and 4.

2. Sampling Unit, Tektronix 7S11. *3-170*

3. Sampling Time Base, Tektronix 7T11. *NO*

4. TDR Sampling Unit, Tektronix 7S12. *NO*

5. Sampling Head, S-6. *Req. 2.5*

6. Type 285 Power Supply for S-50 Series Heads. *yes*

7. Sampling Head Extender, 3-foot. Tektronix Part No. 012-0124-00.

8. 50 Ω coaxial cable, semi-rigid 1 ns, Tektronix Part No. 015-1023-00.

9. 50 Ω coaxial cable, 3 mm, U-shaped, semi-rigid. Tektronix Part No. 015-1017-01.

10. 50 Ω coaxial cable, 750 ps signal delay, 3 mm, semi-rigid. Tektronix Part No. 015-1017-00.

11. Two 50 Ω coaxial cables, 18-inch, RG58, BSM Female to BNC Male. Tektronix Part No. 012-0127-00.

12. 50 Ω coaxial cable, 18-inch with BNC connectors. Tektronix Part No. 012-0076-00.

13. Three Adapters 3 mm Male to BNC Female. Tektronix Part No. 015-1018-00.

14. Adapter, BSM Male to BNC Female. Tektronix Part No. 103-0036-00.

15. 50 Ω termination, 3 mm. Tektronix Part No. 015-1004-00.

16. 5X attenuator, BNC. Tektronix Part No. 011-0060-01.

PERFORMANCE CHECK PROCEDURE

Introduction

The Performance Check provides a means of rapidly checking the S-52 without adjusting any internal controls. Failure to meet any of the requirements given in the procedure indicates a need for internal checks or adjustments, and the user should refer to the Adjustment Procedure in this section.

Partial Performance Check

Less than the complete performance check may be desired if the S-52 is used with the 7S12 and the S-6 exclusively. For example, the front panel PRETRIG OUT is not used in normal operation of the 7S12, S-6, and S-52. For this partial performance check, refer to steps 8 through 11.

Performance Check/Adjustment—S-52

Preliminary Procedure

a. Install the 7S11 with the S-6 Sampling Head in the Right Vert compartment and the 7T11 in the A Horiz compartment of the 7504 Oscilloscope.

b. Install the S-52 Pulse Generator Head in the Type 285 Power Supply.

c. Set the controls as follows:

7504 Indicator Oscilloscope

A Intensity	CCW
B Intensity	CCW
Vertical Mode	Right
Horizontal Mode	A

7S11 with S-6

Delay	Midrange
+Up	Pushed in
DC Offset ± 1 V and Fine	Midrange
mVolts/Div	100
Variable	Pushed in
Dot Response	Midrange
Normal	Pushed in

7T11

Time Position and Fine	Fully clockwise
Random	Pushed in
Sweep Range	.5 μ s
Time/Div	20 ns
Variable	Pushed in
Scan	Midrange
Rep	Pushed in
Slope +	Pushed in
Trig Level	Midrange
Stability	Fully clockwise
Trig Amp X1	Pushed in
50 Ω V Max	Pushed in

d. Turn the Type 285 and the Oscilloscope power on. After about a five minute warmup time, advance the A Intensity until a free-running trace is observed. Center the trace on the CRT with the 7S11 DC Offset control.

1. Check PRETRIG OUT (Front Panel) Amplitude and Duration

a. Connect the Type 285 Trigger Out through a BSM to BNC coaxial cable (18 inch) and BNC to 3 mm adapter to the 7T11 Trig Input. Connect the S-52 PRETRIG OUT signal through a BSM to BNC coaxial cable (18 inch), a




Fig. 5-1. Pretrigger Out.

BNC 5X attenuator and a BNC to 3 mm adapter to S-6 Loop Thru (lower) connector. Terminate the upper Loop Thru connector with a 3 mm 50 Ω termination.

b. Set the 7T11 Trig Level for a stable display and use the Time Position control to position the PRETRIG OUT display to the left edge of the graticule. Change the 7T11 Time/Div to 2 ns for a display of the PRETRIG OUT signal. See Fig. 5-1.

c. Check the PRETRIG OUT amplitude to be at least one volt positive-going.

d. Check the PRETRIG OUT duration at the 50% amplitude point to be 4 ns within 2 ns.

2. Check PRETRIG OUT (Front Panel) Rise Rate

a. Change the 7T11 Time/Div to 500 ps. Set the 7S11 mV/Div to 50. Use the Time Position control to position the rising portion of the PRETRIG OUT signal on the CRT.

b. Check that a portion of the rise is greater than 600 mV (2.4 divisions) in 1 ns. See Fig. 5-2.

3. Check Pretrigger Out (Rear Panel) Amplitude and Duration

a. Interchange the two trigger cables to the S-6 and S-52 front panel connectors.




Fig. 5-2. Waveform of Pretrigger Out leading edge showing Rise Rate. (5X attenuator used in signal path.)

b. Change the following controls:

	7S11
mV/Div	100
	7T11
Sweep Range	.5 μ s
Time/Div	20 ns

c. Set the 7T11 Trig Level for a stable display and use the Time Position control to position the Pretrigger Out display to the left edge of the graticule. Change the 7T11 Time/Div to 2 ns for a display of the Pretrigger Out signal. See Fig. 5-1.

d. Check the Pretrigger Out amplitude to be at least one volt positive-going.

e. Check the Pretrigger Out duration at the 50% amplitude point to be 4 ns within 2 ns.

4. Check Pretrigger Out (Rear Panel) Rise Rate

a. Change the 7T11 Time/Div to 500 ps. Set the 7S11 mV/Div to 50. Use the Time Position control to position the rising portion of the Pretrigger Out signal on the CRT.

b. Check any portion of the rise to be greater than 600 mV (2.4 divisions) in 1 ns. See Fig. 5-2.

5. Check PRETRIG OUT to PULSE OUTPUT Time Interval

a. Remove the coaxial cable from between the Type 285 Trigger Out connector and the 5X attenuator.

b. Remove the coaxial cable from the S-52 PRETRIG OUT connector and connect it to the Type 285 Trigger Out connector.

c. Install BSM to BNC female and 3 mm to BNC female adapters on the S-52 connectors, and connect a BNC coaxial cable from the S-52 PRETRIG OUT connector to the 5X attenuator on the S-6.

d. Change the 7T11 Time/Div to 10 ns. Set the 7S11 mV/Div to 100 mV. Use the Time Position control to position the rising portion of the PRETRIG OUT display to the left edge of the graticule.

e. Remove the coaxial cable from the PRETRIG OUT connector and connect the cable to the PULSE OUTPUT connector of the S-52. Do not adjust any controls.

f. Check the position of the leading edge of the displayed PULSE OUTPUT signal to be 85 ns within 5 ns from the left edge of the graticule. See Fig. 5-3.




Fig. 5-3. Double exposure photo showing the PRETRIG OUT to PULSE OUTPUT time interval.

Performance Check/Adjustment--S-52

6. Check PRETRIG OUT to PULSE OUTPUT Jitter

a. Remove the cables, adapters and attenuator from the S-52, the Type 285 Trigger Out and the S-6 lower input connectors.

b. Install a Sampling Head Extender cable between the Type 285 and the S-52.

c. Connect a 750 ps, 3 mm, semi-rigid coaxial cable (Tektronix Part No. 015-1017-00) from the S-52 PULSE OUTPUT to the S-6 lower input.

d. Connect the BSM to BNC coaxial cable from the 7T11 Trig Input connector to the S-52 PRETRIG OUT connector.

e. Change the following controls:

7T11

Sequential	Pushed in
Sweep Range	50 ns
Time/Div	5 ns
Time Position	Fully clockwise

f. Set the 7T11 Trig Level for a stable display of the leading edge of the PULSE OUTPUT signal. Change the Time/Div to 200 ps, and use the Time Position control to position the leading edge to the center of the graticule.

g. Use the DC Offset to center the display vertically, and change the mV/Div to 10. Then change the 7T11 Time/Div to 20 ps, and use the Time Position control to position the center portion of the leading edge of the PULSE OUTPUT signal on the CRT.

h. Determine the displayed jitter by observing 90% of the dot density on the rising portion. See Fig. 5-4.

i. Check that the displayed jitter is not more than 14 ps. The maximum displayed jitter value was calculated by using the 10 ps jitter for the 7T11 and 10 ps for S-52 in the following formula:

$$\text{Displayed jitter} = \sqrt{(\text{S-52 jitter})^2 + (\text{7T11 jitter})^2}$$

NOTE

If the displayed jitter exceeds 14 ps, determine whether the sampling system is operating properly (see the 7T11 manual if necessary), and select a Trig Level setting that will produce the least jitter. The S-52 displayed jitter with the 7S12 is checked in step 11.




Fig. 5-4. Typical waveform to observe jitter in step 6.

7. Check PULSE OUTPUT Period

a. Change the following controls:

7S11

mV/Div 100

7T11

Sweep Range 50 μ s
Time/Div 1 μ s
Scan 9 o'clock position

b. Set the 7T11 Trig Level control for a stable display and use the Time Position control to display two pulses. Note that the desired pulses have the wider top, and are not preceded by a sharply rising foot. See Fig. 5-5.

c. Check that the PULSE OUTPUT period is 8.3 μ s within 0.8 μ s.

8. Check PULSE OUTPUT Duration, Amplitude and Baseline Level

a. Set the 7S11 mV/Div switch at 50 and the 7T11 Time/Div switch at .2 μ s.

b. Adjust the 7T11 Time Position control to place the pulse on the CRT. See Fig. 5-6.

c. Check that the PULSE OUTPUT duration is at least 350 ns.




Fig. 5-5. Waveform showing PULSE OUTPUT period.




Fig. 5-6. Waveform showing PULSE OUTPUT duration, amplitude and baseline level.

d. Check that the PULSE OUTPUT amplitude from the baseline level to the pulse top is at least 200 mV.

e. Check that the baseline level (the voltage prior to the displayed PULSE OUTPUT signal) is between 55 mV and 120 mV.

f. Remove the connections to the S-52, S-6 and the 7T11 and remove the 7S11 and the 7T11 from the oscilloscope.

9. Check PULSE OUTPUT Risetime

a. Install a 7S12 in the two center compartments of the oscilloscope and install the S-6 in the Sampling compartment and the S-52 in the Pulse Generator compartment of the 7S12.

b. Connect the U-shaped semi-rigid coaxial line (Tektronix Part No. 015-1017-01) from the S-52 PULSE OUTPUT connector to the S-6 lower input connector. The S-6 upper connector is terminated with 50 Ω .

c. Set the controls as follows:

7S12

mp	Push in
mp/Div	200
mp/Div Variable	Release
Time-Distance multiplier	X.1
Time/Div	20 ps
Time-Distance dial	0
Rep	Push in
Scan	Clockwise
DC Offset	Display step
Fine (Zero Set)	Display step

d. Adjust the mp/DIV Variable control so that the 0% and the 100% levels of the incident pulse are 5 div apart. Use the following procedure to locate the 0% (100% is in parenthesis) level for the incident pulse. This procedure is necessary whenever a level is not clearly defined.

1. Find the knee reference point at the start (end) of the step where the rate of change of the slope is maximum (the radius of curvature is least). See Fig. 5-7 for this waveform.

2. At a distance of one risetime before (after) the knee reference point in step 1, place the center of a zone which is one risetime in width. The S-6, S-52 and 7S12 system risetime is 35 ps.

3. Determine the average level of the waveform within the zone and use it for the 0% (100%) reference level.

e. Check that the system displayed incident pulse risetime from the 10% level to the 90% level is 35 ps or less.




Fig. 5-7. Risetime measurement (T_r) information (upper) and typical risetime display (lower). Note that Reference point 1 and 2 are selected at the corners where the rate of change of the slope is maximum (where the radius of curvature is least).

NOTE

This displayed risetime is given for the system consisting of the S-6 and S-52 and setup as given. This system risetime is faster than the calculated risetime (39 ps) using the S-6 risetime as 30 ps and the S-52 as 25 ps in the following formula:

$$T_r(\text{displayed}) = \sqrt{T_r^2(S-52) + T_r^2(S-6)}$$

10. Check PULSE OUTPUT Aberrations

a. Change the Time/Div to 200 ps. Use the Time Distance knob to position the leading edge of the PULSE OUTPUT to the center of the CRT. Then set the mV/Div Variable control for a 5 division display amplitude.

b. Change the mV/Div to 50. With the Time Distance knob, position the leading edge of the PULSE OUTPUT to




Fig. 5-8. First 1.8 ns aberrations information (upper) and typical display (lower).

the left side of the CRT. Use the DC Offset control to set the top of the pulse (at the 1.8 ns point from the pulse leading edge) to the center graticule line (see Fig. 5-8).

c. Check that the aberrations are within +7%, -7%, total of 10% within 1.8 ns of the step edge.

d. Set the Time-Distance Multiplier at X1, the Time/Div switch at 50 ns and turn the Time-Distance and Fine (Zero-Set) controls fully clockwise.

e. Place the top of the pulse on the graticule centerline. Use the portion of the pulse that is 300 ns (6 div) from the start of the pulse for the reference level.

f. Set the Time-Distance Multiplier at X.1 and the Time/Div switch at 500 ps. Adjust the Time-Distance control to position the point which is 2.5 ns from the start of the pulse at the graticule center. See Fig. 5-9.

g. Check that the aberrations are within +2%, -2%, total of 4% after 2.5 ns.

Performance Check/Adjustment—S-




Fig. 5-9. Aberrations after the first 2.5 ns information (upper) and typical display (lower).

11. Check Display Jitter

- Change the mV/Div to 20 and set the Time/Div switch at 20 ps.
- Use the DC Offset and the Time Distance knob to center the middle portion of the PULSE OUTPUT leading edge on the CRT. See Fig. 5-4 for a similar display.
- Check that the jitter is less than 10 ps.

ADJUSTMENT PROCEDURE

Introduction

The Adjustment Procedure contains all the adjustments required in the instrument. Troubleshooting information is contained in the Maintenance Section and the Diagrams Section. All S-52 controls are shown in the Diagrams section on the circuit board callouts.

Partial Adjustment

Less than the complete Adjustment Procedure may be desired if the S-52 is used with the 7S12 and S-6 exclusively. Perform this partial procedure as follows:

a. Remove the S-52 from its housing and install it on the Sampling Head Extender.

b. Omit step 1 (Adjustment Procedure following); C is not used when the S-52 is operated with the 7S12.

c. In place of step 2, use the setup and display used in the Performance Check step 11, and adjust Trig Level R for minimum jitter.

d. If tunnel diode CR69 has been replaced, a change in the length of the 2 mil diameter lead wire to the tunnel diode may be required. To check and/or adjust this lead wire, set up the display as given in the Performance Check step 10 (Check PULSE OUTPUT Aberrations). Then follow adjustment step 3 parts c through e.

Preliminary Procedure

1. Assemble the equipment as follows: Install the 7S with the S-6 Sampling Head (equipment list item 2) in the right vertical compartment, and the 7T11 (item 3) in the A Horiz compartment of the 7504 Indicator Oscilloscope (item 1). Install the Sampling Head Extender (item 4) into the Type 285 Power Supply.

2. Remove the S-52 from its housing (see the Maintenance Section), and install it onto the Sampling Head Extender.

3. Set the controls as follows:

7504 Indicator Oscilloscope

A Intensity	CCW
B Intensity	CCW
Vertical Mode	Right
Horizontal Mode	A

7S11 with Type S-6 Sampling Head (Right vertical plug-in compartment)

Delay	Midrange
+Up	Pushed in
DC Offset ± 1 V and Fine	Midrange
mVolts/Div	100
Variable	Pushed in
Dot Response	Midrange
Normal	Pushed in

Performance Check/Adjustment—S-52

7T11
(A horizontal plug-in compartment)

Time Position and Fine	Fully clockwise
Random	Pushed in
Sweep Range	.5 μ s
Time/Div	5 ns
Variable	Pushed in
Scan	Midrange
Rep	Pushed in
Slope +	Pushed in
Trig Level	Midrange
Stability	Fully clockwise
Trig Amp X1	Pushed in
50 Ω 2 V Max	Pushed in

4. Turn on the Type 285 and the Oscilloscope power. After about five minutes warmup, advance the A Intensity until a free-running trace is observed. Center the trace on the CRT with the 7S11 DC Offset control.

1. Adjust Leadtime C60

a. Connect the Type 285 Trigger Out through a BSM to BNC coaxial cable (18 inch) and a BNC to 3 mm adapter to the 7T11 Trig Input. Connect the S-52 PRETRIG OUT signal through BSM to BNC adapter, a BNC coaxial cable, a 5X attenuator, a BNC to 3 mm adapter to S-6 Loop Thru (lower) connector. Terminate the upper Loop Thru connector with a 50 Ω termination.

b. Set the 7T11 Trig Level control for a stable display of the PRETRIG OUT signal.

c. Change the 7T11 Time/Div to 10 ns and use the Time Position control to position the rising portion of the PRETRIG OUT display to the left edge of the graticule. See Fig. 5-3.

d. Without moving the position, trigger controls, or other setup conditions, install a BNC to 3 mm adapter to the S-52 PULSE OUTPUT connector; change the BNC cable connector from the BNC to BSM adapter (at the PRETRIG OUT connector) to the BNC to 3 mm adapter connected to the PULSE OUTPUT connector.

e. Adjust C60 to position the leading edge of the displayed PULSE OUTPUT 85 ns from the left edge of the graticule. Refer to Fig. 5-3.

2. Adjust Trig Level R90

a. Disconnect the connectors from the S-52. Remove the 5X attenuator and the BNC to 3 mm adapter from the

S-6 Loop Thru (lower) connector. Disconnect the trigger cable from the Type 285 Trigger Out connector.

b. Connect the S-52 PULSE OUTPUT signal through a 750 ps semi-rigid coaxial cable to the S-6 Loop Thru (lower) input connector.

c. Use a BSM to BNC coaxial cable (18-inch) and a BNC to 3 mm adapter to connect the S-52 PRETRIG OUT signal to the 7T11 Trig Input connector.

d. Change the following controls:

7T11

Sequential	Pushed in
Sweep Range	50 ns
Time/Div	1 ns

e. Set the 7T11 Trig Level for a stable display of the leading edge of the PULSE OUTPUT signal. Change the Time/Div to 50 ps, and use the Time Position control to position the leading edge to the center of the graticule.

f. Adjust Trig Level R90 for minimum jitter on the rising portion.

3. Adjust 2 Mil Diameter Lead Wire (To Tunnel Diode)

NOTE

This step may be required only when tunnel diode CR69 has been replaced (For CR69 replacement and troubleshooting information see the Maintenance Section.)

a. Change the following controls:

7T11

Sweep Range	50 μ s
Time/Div	200 ps

7S11

mV/Div	50
--------	----

b. Adjust the 7S11 mV/Div Variable control for a 5 division display. Change the 7S11 mV/Div to 10, and use

the DC Offset control to position the top of the pulse to the graticule centerline. See Fig. 5-8 for aberration display information.

c. Delete the balance of this step if the aberrations are within +2%, -10%, total of 10% within 1.8 ns of the pulse step (with reference point 1.8 ns from step), including the first 50 ps which is effective in this adjustment.

d. If the first 50 ps of the pulse shows an overshoot or undershoot, turn the Type 285 power off, remove the timing board, and use a small soldering iron to reduce or increase the length of the 2 mil diameter lead wire. See the

terminal board parts location photo for the location of the lead wire.

CAUTION

Due to the small diameter of the wire, care must be taken in soldering the 2 mil diameter wire to parallel resistors R65-R68. After soldering, visually check that the 2 mil wire is not shorted to chassis ground.

e. Install the timing board, turn the Type 285 power on, and observe the first 50 ps of the pulse top. Repeat part d until the first 50 ps of the pulse is within the aberration limits given in part c.

PARTS LIST ABBREVIATIONS

BHB	binding head brass	int	internal
BHS	binding head steel	lg	length or long
cap.	capacitor	met.	metal
cer	ceramic	mtg hdw	mounting hardware
comp	composition	OD	outside diameter
conn	connector	OHB	oval head brass
CRT	cathode-ray tube	OHS	oval head steel
csk	countersunk	P/O	part of
DE	double end	PHB	pan head brass
dia	diameter	PHS	pan head steel
div	division	plstc	plastic
elect.	electrolytic	PMC	paper, metal cased
EMC	electrolytic, metal cased	poly	polystyrene
EMT	electrolytic, metal tubular	prec	precision
ext	external	PT	paper, tubular
F & I	focus and intensity	PTM	paper or plastic, tubular, molded
FHB	flat head brass	RHB	round head brass
FHS	flat head steel	RHS	round head steel
Fil HB	fillister head brass	SE	single end
Fil HS	fillister head steel	SN or S/N	serial number
h	height or high	S or SW	switch
hex.	hexagonal	TC	temperature compensated
HHB	hex head brass	THB	truss head brass
HHS	hex head steel	thk	thick
HSB	hex socket brass	THS	truss head steel
HSS	hex socket steel	tub.	tubular
ID	inside diameter	var	variable
inc	incandescent	w	wide or width
		WW	wire-wound

PARTS ORDERING INFORMATION

Replacement parts are available from or through your local Tektronix, Inc. Field Office or representative.

Changes to Tektronix instruments are sometimes made to accommodate improved components as they become available, and to give you the benefit of the latest circuit improvements developed in our engineering department. It is therefore important, when ordering parts, to include the following information in your order: Part number, instrument type or number, serial or model number, and modification number if applicable.

If a part you have ordered has been replaced with a new or improved part, your local Tektronix, Inc. Field Office or representative will contact you concerning any change in part number.

SPECIAL NOTES AND SYMBOLS

- | | |
|-----------------|---|
| X000 | Part first added at this serial number |
| 00X | Part removed after this serial number |
| *000-0000-00 | Asterisk preceding Tektronix Part Number indicates manufactured by or for Tektronix, Inc., or reworked or checked components. |
| Use 000-0000-00 | Part number indicated is direct replacement. |

INDEX OF ELECTRICAL PARTS LIST

Title	Page No.
CHASSIS	6-1
A1 TIMING Circuit Board Assembly	6-1
A2 TD CONTROL Circuit Board Assembly	6-3
A3 TRIGGER Circuit Board Assembly	6-4

SECTION 6

ELECTRICAL PARTS LIST

Values are fixed unless marked Variable.

Ckt. No.	Tektronix Part No.	Serial/Model No. Eff	Disc	Description
----------	-----------------------	-------------------------	------	-------------

CHASSIS

Semiconductor Device, Diode

CR69	*153-0040-00			Diode Holder assembly
------	--------------	--	--	-----------------------

Connector

J50 ¹ J60	131-0631-00			Receptacle, electrical
-------------------------	-------------	--	--	------------------------

Resistor

R69	*131-1023-02			Contact, electrical (48 Ω , 1%)
-----	--------------	--	--	--

A1 TIMING Circuit Board Assembly

	*670-1320-00			Complete Board
--	--------------	--	--	----------------

Capacitors

Tolerance $\pm 20\%$ unless otherwise indicated.

C9	283-0182-00	51 pF	Cer	400 V	5%
C10	283-0065-00	0.001 μ F	Cer	100 V	5%
C11	283-0065-00	0.001 μ F	Cer	100 V	5%
C107	283-0111-00	0.1 μ F	Cer	50 V	
C109	283-0111-00	0.1 μ F	Cer	50 V	

¹See Mechanical Parts List for replacement parts.

A1 TIMING Circuit Board Assembly (cont)

Ckt. No.	Tektronix Part No.	Serial/Model No. Eff	Disc	Description
Semiconductor Device, Diodes				
CR21 VR109	*152-0185-00 152-0279-00		Silicon Zener	Replaceable by 1N4152 1N751A 400 mW, 5.1 V, 5%
Inductor				
L10	108-0317-00		15 μ H	
Transistor				
Q32	151-0190-00		Silicon	NPN TO-92 2N3904
Resistors				
Resistors are fixed, composition, $\pm 10\%$ unless otherwise indicated.				
R9	317-0241-00		240 Ω	$\frac{1}{8}$ W 5%
R10	317-0202-00		2 k Ω	$\frac{1}{8}$ W 5%
R12	317-0432-00		4.3 k Ω	$\frac{1}{8}$ W 5%
R20	315-0302-00		3 k Ω	$\frac{1}{4}$ W 5%
R22	317-0752-00		7.5 k Ω	$\frac{1}{8}$ W 5%
R26	317-0153-00		15 k Ω	$\frac{1}{8}$ W 5%
R27	317-0511-00		510 Ω	$\frac{1}{8}$ W 5%
R28	317-0752-00		7.5 k Ω	$\frac{1}{8}$ W 5%
R30	317-0432-00		4.3 k Ω	$\frac{1}{8}$ W 5%
R31	317-0202-00		2 k Ω	$\frac{1}{8}$ W 5%
R32	317-0621-00		620 Ω	$\frac{1}{8}$ W 5%
R33	317-0752-00		7.5 k Ω	$\frac{1}{8}$ W 5%
R34	317-0223-00		22 k Ω	$\frac{1}{8}$ W 5%
R35	317-0912-00		9.1 k Ω	$\frac{1}{8}$ W 5%
R36	317-0103-00		10 k Ω	$\frac{1}{8}$ W 5%
R37	317-0242-00		2.4 k Ω	$\frac{1}{8}$ W 5%
R38	317-0201-00		200 Ω	$\frac{1}{8}$ W 5%
R106	317-0162-00		1.6 k Ω	$\frac{1}{8}$ W 5%
R107	317-0271-00		270 Ω	$\frac{1}{8}$ W 5%
R108	317-0331-00		330 Ω	$\frac{1}{8}$ W 5%
R109	308-0236-00		85 Ω	3 W WW 5%
Integrated Circuits				
U10	156-0101-00			Four bit binary counter. Replaceable by T.I. SN74L93N
U20	156-0111-00			BCD to dec decoder. Replaceable by T.I. SN74145N
U30	156-0048-00			Linear. Replaceable by RCA CA3046

A2 TD CONTROL Circuit Board Assembly

Ckt. No.	Tektronix Part No.	Serial/Model No. Eff	Disc	Description
	*670-1319-00			Complete Board

Capacitors

Tolerance $\pm 20\%$ unless otherwise indicated.

C60	283-0178-00		0.1 μ F	Cer	100 V	+80%—
C65	283-0181-00		1.8 pF	Cer	100 V	
C87	283-0028-00		0.0022 μ F	Cer	50 V	
C90	283-0065-00		0.001 μ F	Cer	100 V	
C101	283-0203-00		0.47 μ F	Cer	50 V	
C102	283-0203-00		0.47 μ F	Cer	50 V	

Semiconductor Device, Diodes

CR90	*152-0185-00		Silicon		Replaceable by 1N4152
CR91	*152-0185-00		Silicon		Replaceable by 1N4152
CR93	*152-0185-00		Silicon		Replaceable by 1N4152

Transistors

Q72	151-0190-00		Silicon	NPN	TO-92	2N3904
Q74	151-0190-00		Silicon	NPN	TO-92	2N3904
Q80	151-0188-00		Silicon	PNP	TO-92	2N3906
Q86	151-0188-00		Silicon	PNP	TO-92	2N3906
Q88	151-0188-00		Silicon	PNP	TO-92	2N3906
Q90	151-0254-00		Silicon	NPN	TO-98	2N5308

Resistors

Resistors are fixed, composition, $\pm 10\%$ unless otherwise indicated.

R60	317-0823-00	XB050000	82 k Ω	$\frac{1}{8}$ W		
R65	317-0027-00		2.7 Ω	$\frac{1}{8}$ W		
R66	317-0101-00		100 Ω	$\frac{1}{8}$ W		
R67	317-0680-00		68 Ω	$\frac{1}{8}$ W	(nominal value)	Sel
R68	317-0027-00		2.7 Ω	$\frac{1}{8}$ W		
R71	317-0361-00		360 Ω	$\frac{1}{8}$ W		
R72	317-0222-00		2.2 k Ω	$\frac{1}{8}$ W		
R74	317-0222-00		2.2 k Ω	$\frac{1}{8}$ W		
R75	317-0103-00		10 k Ω	$\frac{1}{8}$ W		
R80	321-0202-00		1.24 k Ω	$\frac{1}{8}$ W		Prec
R81	317-0751-00		750 Ω	$\frac{1}{8}$ W		

A2 TD CONTROL Circuit Board Assembly (cont)

Ckt. No.	Tektronix Part No.	Serial/Model No. Eff	Disc	Description
Resistors (cont)				
R85	317-0161-00		160 Ω	$\frac{1}{8}$ W 5%
R86	321-0185-00		825 Ω	$\frac{1}{8}$ W Prec 1%
R87	317-0121-00		120 Ω	$\frac{1}{8}$ W 5%
R88	317-0047-00		4.7 Ω	$\frac{1}{8}$ W 5%
R89	321-0224-00		2.1 k Ω	$\frac{1}{8}$ W Prec 1%
R90	311-1279-00		500 Ω , Var	
R91	321-0047-00		30.1 Ω	$\frac{1}{8}$ W Prec 1%
R96	301-0221-00		220 Ω	$\frac{1}{2}$ W 5%
R97	301-0271-00		270 Ω	$\frac{1}{2}$ W 5%
R98	317-0430-00		43 Ω	$\frac{1}{8}$ W 5%

A3 TRIGGER Circuit Board Assembly

*670-1321-00

Complete Board

CapacitorsTolerance $\pm 20\%$ unless otherwise indicated.

C40	281-0616-00		6.8 pF	Cer 200 V	
C44	283-0186-00		27 pF	Cer 50 V	5%
C52	283-0069-00		15 pF	Cer 50 V	
C54	283-0069-00		15 pF	Cer 50 V	
C60	281-0123-00		5-25 pF, Var	Cer 100 V	
C62	283-0000-00		0.001 μ F	Cer 500 V	
C66	283-0111-00		0.1 μ F	Cer 50 V	
C103	283-0203-00		0.47 μ F	Cer 50 V	
C105	283-0203-00		0.47 μ F	Cer 50 V	

Semiconductor Device, Diodes

CR40	*152-0185-00	Silicon	Replaceable by 1N4152
CR54	*152-0185-00	Silicon	Replaceable by 1N4152
CR60	*152-0233-00	Silicon	Tek Spec
CR62	*152-0185-00	Silicon	Replaceable by 1N4152
CR63	*152-0185-00	Silicon	Replaceable by 1N4152
CR66	*152-0252-00	Silicon	Snap-off Tek made

Inductors

L62	*108-0088-00	3.2 μ H
LR64	*108-0299-00	0.25 μ H (wound on a 62 Ω , $\frac{1}{4}$ W, 5% resistor)

ConnectorP52¹¹See Mechanical Parts List for replacement parts.

A3 TRIGGER Circuit Board Assembly (cont)

Ckt. No.	Tektronix Part No.	Serial/Model No. Eff	Disc	Description
Transistors				
Q40	*151-0269-00		Silicon	NPN TO-106 Selected from SE3005
Q50	*151-0271-00		Silicon	PNP TO-18 Tek Spec
Q60	*151-0269-00		Silicon	NPN TO-106 Selected from SE3005

ResistorsResistors are fixed, composition, $\pm 10\%$ unless otherwise indicated.

R40	317-0303-00		30 k Ω	$\frac{1}{8}$ W	5%
R42	317-0103-00		10 k Ω	$\frac{1}{8}$ W	5%
R44	317-0513-00		51 k Ω	$\frac{1}{8}$ W	5%
R50	317-0623-00		62 k Ω	$\frac{1}{8}$ W	5%
R52	317-0822-00		8.2 k Ω	$\frac{1}{8}$ W	5%
R53	317-0511-00		510 Ω	$\frac{1}{8}$ W	5%
R54	317-0242-00		2.4 k Ω	$\frac{1}{8}$ W	5%
R56	317-0301-00		300 Ω	$\frac{1}{8}$ W	5%
R60	317-0103-00		10 k Ω	$\frac{1}{8}$ W	5%
R62	317-0822-00		8.2 k Ω	$\frac{1}{8}$ W	5%
R64	317-0360-00		36 Ω	$\frac{1}{8}$ W	5%
R103	317-0101-00		100 Ω	$\frac{1}{8}$ W	5%
R105	317-0101-00		100 Ω	$\frac{1}{8}$ W	5%

SECTION 7

DIAGRAMS AND CIRCUIT BOARD ILLUSTRATIONS

Symbols and Reference Designators


Electrical components shown on the diagrams are in the following units unless noted otherwise:

- Capacitors = Values one or greater are in picofarads (pF).
 Values less than one are in microfarads (μ F).
 Resistors = Ohms (Ω)

Symbols used on the diagrams are based on USA Standard Y32.2-1967.


Logic symbology is based on MIL-STD-806B in terms of positive logic. Logic symbols depict the logic function performed and may differ from the manufacturer's data.

The following special symbols are used on the diagrams:





The following prefix letters are used as reference designators to identify components or assemblies on the diagrams.

A	Assembly, separable or repairable (circuit board, etc.)	LR	Inductor/resistor combination
AT	Attenuator, fixed or variable	M	Meter
B	Motor	Q	Transistor or silicon-controlled rectifier
BT	Battery	P	Connector, movable portion
C	Capacitor, fixed or variable	R	Resistor, fixed or variable
CR	Diode, signal or rectifier	RT	Thermistor
DL	Delay line	S	Switch
DS	Indicating device (lamp)	T	Transformer
F	Fuse	TP	Test point
FL	Filter	U	Assembly, inseparable or non-repairable (integrated circuit, etc.)
H	Heat dissipating device (heat sink, heat radiator, etc.)	V	Electron tube
HR	Heater	VR	Voltage regulator (zener diode, etc.)
J	Connector, stationary portion	Y	Crystal
K	Relay		
L	Inductor, fixed or variable		




















R96 may be mounted on the back. R97, R98 and CR93 may be mounted above the board.



Troubleshooting Conditions


Power is obtained from Type 285 Power Supply, or sampling head compartment. Use a sampling Head Extender so that the S-52 case can be removed. Trigger the Test Oscilloscope from the Pretrig Out pulse to show time relationship.



Note 1. See Troubleshooting information in Section 4

Troubleshooting waveforms were obtained with 7A12, 7B70, and 7704. Signals for waveforms #14 was coaxially connected and 50 Ω terminated, and all others were connected with P6053 10 X probe with a short ground lead. DC coupling was used for all waveforms.

SCHEMATIC
Sht. 8 of 3



A1 TIMING BOARD (RIGHT)


A2 TO CONTROL BOARD (CENTER)

A3 TRIGGER BOARD (LEFT)

552 PULSE GENERATOR HEAD

SCHEMATIC SH-30F3

CONTROL BOARD (CENT)



A3 Pulse Board (Left)

SCHEMATIC
472

FIGURE AND INDEX NUMBERS

Items in this section are referenced by figure and index numbers to the illustrations which appear either on the back of the diagrams or on pullout pages immediately following the diagrams of the instruction manual.

INDENTATION SYSTEM

This mechanical parts list is indented to indicate item relationships. Following is an example of the indentation system used in the Description column.

Assembly and/or Component
Detail Part of Assembly and/or Component
mounting hardware for Detail Part
Parts of Detail Part
mounting hardware for Parts of Detail Part
mounting hardware for Assembly and/or Component

Mounting hardware always appears in the same indentation as the item it mounts, while the detail parts are indented to the right. Indented items are part of, and included with, the next higher indentation.

Mounting hardware must be purchased separately, unless otherwise specified.

PARTS ORDERING INFORMATION

Replacement parts are available from or through your local Tektronix, Inc. Field Office or representative.

Changes to Tektronix instruments are sometimes made to accommodate improved components as they become available, and to give you the benefit of the latest circuit improvements developed in our engineering department. It is therefore important, when ordering parts, to include the following information in your order: Part number, instrument type or number, serial or model number, and modification number if applicable.

If a part you have ordered has been replaced with a new or improved part, your local Tektronix, Inc. Field Office or representative will contact you concerning any change in part number.

Change information, if any, is located at the rear of this manual.

ABBREVIATIONS AND SYMBOLS

For an explanation of the abbreviations and symbols used in this section, please refer to the page immediately preceding the Electrical Parts List in this instruction manual.

SECTION 8

MECHANICAL PARTS LIST

FIGURE 1 EXPLODED & STANDARD ACCESSORIES

Fig. & Index No.	Tektronix Part No.	Serial/Model No.		Q † Y	Description
		Eff	Disc		
1 2 3 4 5					
1-1	386-1337-13			1	PANEL, rear
-2	211-0141-00			4	mounting hardware: <i>(not included w/panel)</i> SCREW, 4-40 x 3.25 inches, PHS
-3	380-0233-00			1	HOUSING
-4	131-0555-00			4	housing includes: CONTACT
-5	670-1320-00			1	CIRCUIT BOARD ASSEMBLY—TIMING A1
	388-1874-00			1	circuit board assembly includes: CIRCUIT BOARD
-6	136-0252-04			47	SOCKET, pin connector
-7	136-0263-03			7	SOCKET, pin connector
-8	670-1319-00			1	CIRCUIT BOARD ASSEMBLY—T.D. CONTROL A2
	388-1873-00			1	circuit board assembly includes: CIRCUIT BOARD
-9	131-0591-00			7	TERMINAL, pin, 0.835 inch long
-10	131-0594-00			4	TERMINAL, pin, feed-thru, 1.485 inches long
-11	136-0252-04			18	SOCKET, pin connector
	214-1081-00			2	PIN, spring, spiral
-12	211-0162-00			2	mounting hardware: <i>(not included w/circuit board assembly)</i> SCREW, 2-56 x 0.188 inch, SHS
-13	333-1396-00			1	PANEL, front
-14	386-1338-09			1	SUBPANEL, front
-15	670-1321-00			1	CIRCUIT BOARD ASSEMBLY—TRIGGER A3
	388-1875-00			1	circuit board assembly includes: CIRCUIT BOARD
-16	136-0263-00			8	SOCKET, pin connector
-17	136-0350-00			3	SOCKET, transistor, 3 pin, low profile
-18	344-0108-00			2	CLIP, diode
-19	175-1264-00			1	CABLE ASSEMBLY, w/connector
	352-0133-00			1	HOLDER, connector
-20	131-0741-00			1	CONNECTOR, block
-21	131-0631-00			1	CONNECTOR, receptacle, w/hardware
-22	220-0531-00			1	mounting hardware: <i>(not included w/connector)</i> NUT, hex., 0.25-32 x 0.312 inch

FIGURE 1 EXPLODED & STANDARD ACCESSORIES (cont)

Fig. & Index No.	Tektronix Part No.	Serial/Model No.		Q † Y	Description
		Eff	Disc		
1-	152-0507-00			1	DIODE-HOLDER ASSEMBLY
	-			-	diode-holder assembly includes:
	-			1	DIODE
-23	213-0194-00			1	THUMBSCREW, 0.25-32 x 0.328 inch long
-24	214-1073-01			1	SPRING, helical compression
-25	131-1023-02			1	CONTACT, electrical, w/resistor & wire lead
-26	175-1039-00			1	CABLE ASSEMBLY
	-			-	cable assembly includes:
-27	131-0579-00			1	CONNECTOR, coaxial, w/hardware
-28	384-0687-00	B010100	B039999	1	SHAFT, latch
-29	214-1226-01	B010100	B039999	1	SPRING, helical compression
-30	105-0066-00	B010100	B039999	1	STRIKE, latch
	105-0338-00	B040000		1	LATCH ASSEMBLY
	-			-	latch assembly includes:
	354-0163-00			1	RING, retaining
	384-0687-01			1	SHAFT, extension, latch
	105-0336-00			1	STRIKE, latch

STANDARD ACCESSORIES

015-1023-00	1	COAXIAL LINE, 50 Ω (not shown)
070-1101-01	1	MANUAL, instruction (not shown)

Fig. 1 EXPLODED
Sht. 10F2





Fig. 1 EXPLODED
Sht. 2 of 2



MANUAL CHANGE INFORMATION

At Tektronix, we continually strive to keep up with latest electronic developments by adding circuit and component improvements to our instruments as soon as they are developed and tested.

Sometimes, due to printing and shipping requirements, we can't get these changes immediately into printed manuals. Hence, your manual may contain new change information on following pages.

A single change may affect several sections. Sections of the manual are often printed at different times, so some of the information on the change pages may already be in your manual. Since the change information sheets are carried in the manual until ALL changes are permanently entered, some duplication may occur. If no such change pages appear in this section, your manual is correct as printed.

S-52 EFF SN B060000-up

ELECTRICAL PARTS LIST AND SCHEMATIC CORRECTION

A1 TIMING Circuit Board Assembly

ADD:

CR10	152-0141-02	Silicon	1N4152
------	-------------	---------	--------

