

Supplement

Title: 771 I.S. Supplement Issue: **6**
Part Number: 2567301 Issue Date: 4/10
Print Date: Sept. 2006 Page Count: 3
Revision/Date:

This supplement contains information necessary to ensure the accuracy of the above Instruction Sheet.

TRANSCAT

 Visit us at Transcat.com!

35 Vantage Point Drive // Rochester, NY 14624 // Call 1.800.800.5001

Change #1, 40733

Under ***Battery Replacement***, add the following under the **Warning**:



To avoid battery leakage, which could damage the Meter, remove the batteries from the Meter when not used for an extended period.

Under ***Specifications***, change the following:

From: **Storage Temperature** -25 to 70 °C

To: **Storage Temperature** -25 °C to 60 °C

From: **EMI, RFI, EMC**

Meets all applicable requirements in EN 61326-1

To: **EMI, RFI, EMC**

Meets all applicable requirements in EN 61326-1.
For EMC field strengths of 1 V/m up to 3 V/m, add 1 mA to specifications.

Change #2, 41823, 44219

Under **Specifications**, change the following:

From: **Working hours** 45 hours

To: **Battery Life** 40 hours

Change #3, 42176

Under **Maintenance**, following the **Warning** add:

Note

Dirt or debris on the surface of the sensor in the clamp jaw will impact the precision of measurements. For best performance, clean the sensor surfaces with a soft cloth and a solution of Isopropyl Alcohol as needed.

Change #4, 43111

Under **Specifications**, add the following:

AC Noise Rejection: ≥ 5 Hz, the Meter's reading is mean value of the measured current

Change #5, 44209

Under ***Specifications***, add the following:

Diameter of Measurable Conductor: 4.5 mm max

Change #6, 54643

Under ***Specifications***, add the following:

Pollution Degree: 2

TRANSCAT[®]



Visit us at Transcat.com!

35 Vantage Point Drive // Rochester, NY 14624 // Call 1.800.800.5001